



**System Manager III
Programming Guide
V3.26.00**

Version december 2023

Programming Guide Qbus System Manager

© Qbus NV

All rights reserved. No part of this publication may be reproduced in any form or by any means, graphic, electronic or mechanical, by photocopying, recording or with storage and retrieval systems, without the written permission of Qbus NV.

Despite the care taken in the preparation of this document, the publisher and the author accept no liability for errors or omissions or for damages resulting from the use of information contained in this document or from the use of associated programs and source codes. Under no circumstances will the publisher and the author be held liable for lost profits, commercial damage or any other consequential damage caused directly or indirectly or alleged to be caused directly or indirectly by this document.

Printed September 2023, Erpe-Mere.

Version control

version	Date	Author	Change
v1	June 2022	ML	Translated from dutch version, English printscreens
v2	October 2022	ML	Update for QDG04SA, Dali labels, ...
v3	Januari 2023	ML	Update for LQS06SA, audiolink, new switches, ...
V4	May 2023	ML	Update for new module types, update TH parameters and heat curve, ...
V5	September 2023	ML	Update for Zigbee®-products, new ANA01, minor features, ...
V6	December 2023	ML	Update for Niko-Zigbee®-modules, Find & replace I/O name

Content

1. Introduction to the Qbus Automation System.....	7
1.1 Description of the Qbus Automation System.....	7
1.1.1 Limitations of the Qbus system.....	8
1.1.2 Planning your installation.....	9
1.1.3 Types of controllers.....	11
2. Installation of the Qbus System Manager	14
2.1 Where can you find the Qbus System Manager?	14
2.2 System Manager Hardware Requirements	14
2.3 Starting Qbus System Manager.....	14
2.4 Configure Qbus System Manager.....	15
2.4.1 Communication with the Controller.....	17
2.4.2 Other Setup Options	20
3. Taskbar Qbus System Manager	33
3.1 Open and Save.....	33
3.2 Extract data from the controller.....	34
3.2.1 Restore QDB from SD	34
3.2.2 Events	34
3.2.3 Module scanning.....	37
3.3 Send data to the controller.....	37
3.4 Programming modules.....	39
3.5 I/O's.....	43
3.5.1 Toggle (Bistable).....	44
3.5.2 Push button	44
3.5.3 Dimmer1B / Dimmer2B	44
3.5.4 Shutter1B / Shutter2B	44
3.5.5 Intermittent	44
3.5.6 Intelligent Thermostat	45
3.5.7 Audio – Audiolink	54
3.5.8 Sequencer.....	55
3.5.9 Timers	55
3.5.10 (Energy) meter	59
3.5.11 Universal function.....	61
3.5.12 Stepper I/O.....	61
3.5.13 I/O properties	62
3.6 Editing scenes	65
3.6.1 Simulation	66
3.6.2 Multi-link	68
3.7 Setting time schedules (Clock times or Weekly program)	70
3.8 Control table selection	71
3.9 Infrared samples.....	73
3.9.1 Creating infrared samples.....	73
3.9.2 Assign I/O's to the sampled infrared codes.	74
3.9.3 Sending infrared code via the IRG04.....	77
3.10 Creating Logical Functions.....	79
3.10.1 Binary Logic (If – Then – Else with ON/OFF)	79
3.10.2 Analogue Logic (If – Then – Else with all values and operations x,/,+,-,<,>=)	80
3.11 Choosing an alarm	84
3.12 Conversion table	88
3.13 Grid editor (Global editing)	91
3.14 Importing a QDB	97
4. Configuration of the Qbus modules	99
4.1 Configuring Input Modules.....	100
4.1.1 INP02/04	100
4.1.2 INP08/INP16	101
4.1.3 INP08/230	101

4.1.4	INA02 (module type 0013)	102
4.2	Configure I/O modules.....	106
4.2.1	Configuring Relay Modules (REL02SA/230, REL04(SA), REL08) ...	106
4.2.2	Roller shutter module with positioning (ROL02P, ROL01PSA and ROL04PSA)	108
4.2.3	Dimmer modules (DIM02SA/500U, DIM04SA/500U)	111
4.2.4	Constant Light Control (CLC01).....	113
4.2.5	Analog dimmer module (ANA04/ANR04SA).....	115
4.3	Configuring switches (SWC0X/XX and Tastu)	117
4.4	Replacing a module	122
4.5	DIS02IT (Eol 2017)	123
4.5.1	Configuring the DIS02 IT	123
4.5.2	Using the DIS02 IT	124
4.6	ViZiR Room Controller (Eol 08/2019).....	125
4.6.1	Configuring the ViZiR Room Controller	125
4.6.2	Using the ViZiR Room Controller	128
4.7	Touch Display (DIS/Gx) Module type 0008	130
4.7.1	Configuring the Tastu display	130
4.7.2	Using the Tastu display.....	132
4.8	Configure 5.8" touch screen (TSC5.8)	133
4.9	Configure motion detector (MDX01 or SEN04MLT)	134
4.9.1	Specifications	134
4.9.2	Configuration parameters	134
4.10	Configure SMS module – SMS01 (Eol 2017)	136
4.10.1	Install SIM card	136
4.10.2	Install Phone Numbers.....	136
4.10.3	Configuring Commands	137
4.11	Configuring the Audio Module - SER10 (Eol)	139
4.11.1	Select audio system	139
4.11.2	Assign Sources and Zones	140
4.11.3	Assigning I/O's	140
4.10.4	Audio I/O's in scenes	142
4.12	Configure the SER485/DMX module (module type 0002).....	143
4.13	The QDI01 (Dali 1): Configure module type 0006 (Eol 2021).....	149
4.14	SER485/Modbus interface: Module type 0003	154
4.15	SER485/APIEN: Weather station module type 0001	155
4.16	SEN01X modules.....	156
4.16.1	SEN01T: serial numbers 700300 to 704999.....	156
4.16.2	SEN01NTC: serial numbers 705000-708999	157
4.16.3	SEN01M: Serial Numbers 710000-749999	158
4.17	Dali broadcast module QDBC02SA module type 0009.....	159
4.18	Constant Voltage Driver CVD04SA module type 000C.....	160
4.19	Configure Wireless Interface QWI/ZB (Zigbee®) Module Type 0047.	161
4.19.1	QWZ-REL02/230.....	162
4.19.2	QWZ-PPE01	165
4.19.3	QWZ-RAD	167
4.19.4	QWZ-TH.....	169
4.19.5	Zigbee® Niko 552-7200x switches	170
4.19.6	Zigbee® Niko 552-7210x relay with push button	171
4.19.7	Zigbee® Niko 170-33505 socket	172
4.20	Configure Wireless Interface QWI/EW (Easy Wave)Module Type 000A174	
4.20.1	QWE-REL01/230 and QWE-REL01/230PF relay module	175
4.20.2	QWE-PP01/BE power plug	176
4.20.3	QWE-SWC04/55 4-way push button	176
4.20.4	QWE-INP04/bat 4-way input module	178
4.20.5	QWE-INP02/230 2-way input module	179
4.20.6	QWE-PB/button and QWE-PB/wrist and QWE-PB/neck and QWE-RC01 1- button pushbuttons	180

4.20.7	QWE-RC04/metal 4-button hand-held transmitter	180
4.20.8	QWE-SWC01/call and QWE-SWC01/reset 1-key pushbuttons	181
4.20.9	QWE-SEN01MW motion detector with light cell	181
4.20.10	QWE-MC01/white window or door contact	182
4.21	QDM01 Configure Dali1 and Dali2 module (Type 0011)	183
4.22	QDG04SA Configure Dali1 module (Type 0012)	185
4.23	Configuring module SenMoLi (type 0045) and SenMax (type 0046) ..	187
5.	Remote connection	189
5.1	Qbus Control	189
5.2	EQOweb web server	196
5.3	Port Forwarding	200
6.	Measuring (energy) via Qbus	201
6.1.	Energy Counter Module	201
	Step 1: Insert Serial Number	201
	Step 2: create I/O's and assign them	202
	Step 3: Logic	203
6.2.	EMM03 (Module type 0017)	206
6.3	Configuring Luqas, the smart energy management module (LQS06SA) type 001B209	
6.3.1	Controlling a Smart Grid heat pump	209
6.3.2	Controlling 2 relay I/O's	210
6.3.3	Charging station setup	210
6.3.4	Setup	211
6.4	Counters	212
	Logic	212

1. Introduction to the Qbus Automation System


This chapter provides an introduction to the Qbus home and building automation system, a brief description of the system and its limitations, and instructions on how to plan the installation. It also describes the various controllers - the brain of the Qbus system.

1.1 Description of the Qbus Automation System

With the Qbus system, various electrical products in a home can be controlled, either manually or automatically and remotely (with an IR remote control, via SMS or on the internet). As the block diagram indicates, a central control unit (controller) communicates via a special two-wire bus with numerous input and I/O modules (I/O modules) in the home. The Controller:

- perpetuates the operation of the bus;
- ensures simultaneous two-way communication between the controller and the Qbus modules on the bus;
- powers the Qbus modules on the bus;
- stores the time-based input and I/O sequences according to the status of the input modules and sends commands to I/O's to change their status based on the I/O sequences, remote commands, or manual commands;
- can also be a separate communication link over the ethernet with internet-based contacts for remote control and monitoring.

I/O modules monitor the communication bus for commands from the controller to change the I/O status and report their status and the change of status to the controller, based on operations in the I/O modules.



1.1.1 Limitations of the Qbus system


When installing the Qbus automation system, you must take the following restrictions into account.

- a. The size of the installation is limited by:
 - **The number of modules that can be powered by the controller** depends on the maximum power that can be delivered on the bus of the corresponding controller:
 - CTD10, CTD40, CTDMax: Maximum 1000mA per bus. The actual number of modules is limited here and can be expanded by software via an expansion card.
 - CTD01Em (with Ethernet): Maximum 100mA on the bus (~9 Qbus modules)
 - CTD01 (with and without Ethernet): Maximum 250mA on the bus (~20 Qbus modules)
 - CTD01E+ (only with Ethernet): Maximum 500mA on the bus (~40 Qbus modules)
 - CTD02E (only with Ethernet): Maximum 500mA on each bus (~40 Qbus modules per bus)
 - CTD03E (only with Ethernet): Maximum 500mA on each bus (~40 Qbus modules per bus). In order to utilize the maximum power of the CTD03E, equal to 1500mA, the CTD must be placed on a ventilated distribution board in an area where the ambient temperature is $< 25^{\circ}\text{C}$.
 - **The number of available I/O's:** Each controller has 388 available I/O's, 91 scenes and 99 clock times. The Qbus system works with addresses; 1 controller has 388 addresses; Depending on the type of I/O, 1 or more addresses are used:
 - a monostable, bistable, timer or meter I/O uses 1 address
 - a dimmer and a roller shutter use 2 addresses
 - a thermostat I/O and HVAC I/O uses 4 addresses.
 - an RGB I/O uses a minimum of 2 addresses but can use up to 5 addresses (Using RGB I/O's in the Cloud uses 2, 3 or 4 addresses)
 - The maximum length of a branch measured from the controller: The length of each bus is limited to a maximum of 200 meters, which means that the module furthest away from the controller is 200 meters. We strongly recommend laying the bus in a loop, ie: the start and end of the loop come together in the controller. In this case (with a closed loop) we can increase the total length to 400 meters. If communication on the bus is not optimal when using the maximum distance (depending on the total load on the loop), add an RC circuit (220 ohms combined with 100 nF) at the end of the bus. Normally RC circuits are not needed.
- b. Other installation requirements.
 - The wiring must be done by means of a cable with at least $2 \times 1 \text{ mm}^2$ conductors as a bus cable. The green shielded EIB cable ($4 \times 0.5 \text{ mm}^2$) is also allowed when the conductors are routed in pairs to obtain a cross section of at least $2 \times 1 \text{ mm}^2$.
 - The bus can be mounted in any architecture (closed loop, tree, star, ...) provided the conditions in terms of distance and cross-section are met. The bus can be tapped to a length of about 30 m. Normally an RC circuit is not necessary, but you can add one (220 ohms combined with 100 nF) if you find that communication is not optimal.
 - Since the bus has no polarity, it is not possible to connect consumers incorrectly.
 - Qbus modules with a thermostat sensor (SEN01T, SEN01NTC, SWC04T, SWC04T/SU, SWC02T/SU, SWC0102T, ViZiR, DIS and TSC5.8) should not be placed close to heating or heat sinks to ensure correct thermostat operation.
 - MDI01, SEN01M or SEN04 should be placed in the best location to obtain maximum viewing angle coverage (110 degrees - 7 meters away), NOT in a location close to a heating or heat sink.

1.1.2 Planning your installation

Determine required number of I/O's and inputs

Based on the building floor plan, the desired I/O's (relays, dimmers, motors, valves, etc.) and input devices to control the I/O's (switches, input modules, motion detectors, infrared sensors, temperature sensors, displays, touch screens, etc.) must be determined. Number each room on the floor plan and determine the required I/O's and entrances for each room. We propose to use different codes and colors for the various functions of the modules: as you can see in the example below, we use red for 230 V modules, green for modules on the bus and blue for potential-free inputs.



This gives you an overview of the installation requirements, which you need to order the right products and install the modules in the right places.


Determining the Wiring Method

The cabling of the installation is of the utmost importance. As indicated above, the bus can be mounted in any architecture (closed loop, tree, star, etc.), provided the conditions for distance and cross-section are fulfilled.

- The maximum length of a branch, measured from the controller, is limited to 200 meters, which means that the module furthest away from the controller is 200 meters. We strongly recommend looping the bus which means that the top and bottom of the loop meet in the controller. In this case (with a closed loop) we can increase the total length to 400 meters.
- The wiring must be done by means of a cable with at least 2x1 mm² conductors as a bus cable. The green shielded EIB cable (4 x 0.5mm²) is also allowed when the conductors are routed in pairs to obtain a cross section of at least 2 x 1 mm².


The bus can be tapped to a length of about 30 m. Normally an RC circuit is not necessary, but you can add one (220 ohms combined with 100 nF) if you find that communication is not optimal.

All individually controlled 230 V circuits must be connected separately to the appropriate I/O modules (dimmer, relay) on the distribution board.



The modules on the bus must all be connected to the bus – preferably in closed loop to ensure optimal distance.

The potential-free modules must be connected in star form to the distribution board.



Tips

- When ordinary push buttons are to be connected to the Qbus system (instead of the Qbus SWCxx smart switches), input modules on DIN rails in the housing (INP08, INP16) or input modules on the bus (INP02, INP04) can be used.
- The DIN-rail input modules are the cheapest option in purchase price per connected input, but additional wiring and installation costs are required because all potential-free devices (ordinary push buttons, magnetic contacts for doors or windows, PIR sensors, ...) have to be star-shaped connected to the distribution board.
- In order to optimize the total cost of the installation and flexibility in the future, it is recommended to work with input modules on the bus. These INP02 and INP04 devices require less time for wiring and installation, and can always be replaced in the future by another Qbus module on the bus (motion detectors, touch screen, smart switch, ...).
- If communication on the bus is not optimal when using the maximum distance (depending on the total load on the loop), add an RC circuit (220 ohms combined with 100 nF) at the end of the bus. Normally RC circuits are not needed.
- Check for short circuits before activating the controller.

1.1.3 Types of controllers

Depending on the installation you have in mind, you can choose a different type of controller.

CTD10	<p>The controller supplies the power and data required to all connected modules.</p> <p>Characteristics:</p> <ul style="list-style-type: none"> • 2 bus connection max. 2 x 1000mA • Ethernet connection • Maximum 10 modules allowed on the bus. Expandable per 15 modules (max. 4x) up to CTDmax • 388 I/O's • Boolean logic (and/or/if-then-else) and analog logic (+,-,x,/,<,>,<=,>=) • 99 clock times, each with max. 15 I/O's or 1 scene • 91 scenes • Presence simulation • Astronomical Clock • 16 GB SD card with 10 memory banks available (for 10 system configurations) • Width: 4 modules (DIN) • Supplied with DIN rail power supply (4 modules)
CTD40	<p>The controller supplies the power and data required to all connected modules.</p> <p>Characteristics:</p> <ul style="list-style-type: none"> • 2 bus connection max. 2 x 1000mA • Ethernet connection • Maximum 40 modules allowed on the bus. Expandable per 15 modules (max. 2x) up to CTDmax • 388 I/O's • Boolean logic (and/or/if-then-else) and analog logic (+,-,x,/,<,>,<=,>=) • 99 clock times, each with max. 15 I/O's or 1 scene • 91 scenes • Presence simulation • Astronomical Clock • 16 GB SD card with 10 memory banks available (for 10 system configurations) • Width: 4 modules (DIN) • Supplied with DIN rail power supply (4 modules)
CTDMax	<p>The controller supplies the power and data required to all connected modules.</p> <p>Characteristics:</p> <ul style="list-style-type: none"> • 2 bus connection max. 2 x 1000mA • Ethernet connection • No limitation on the number of modules allowed on the bus. • 388 I/O's • Boolean logic (and/or/if-then-else) and analog logic (+,-,x,/,<,>,<=,>=) • 99 clock times, each with max. 15 I/O's or 1 scene • 91 scenes • Presence simulation • Astronomical Clock • 16 GB SD card with 10 memory banks available (for 10 system configurations) • Width: 4 modules (DIN) • Supplied with DIN rail power supply (4 modules)

CTD01Em (microcontroller with Ethernet)	<p>The controller supplies the power and data required to all connected modules.</p> <p>Characteristics:</p> <ul style="list-style-type: none"> • 1 bus connection max. 1 x 100mA (for ~9 Qbus modules) • USB connection • 388 I/O's • Boolean logic (and/or/if-then-else) and analog logic (+,-,x,/,<,>,<=,>=) • 99 clock times, each with max. 15 I/O's or 1 scene • 91 scenes • Presence simulation • Astronomical Clock • 8 GB SD card with 10 memory banks available (for 10 system configurations) • Width: 4 modules (DIN) • Supplied with DIN rail power supply (4 modules)
CTD01 (mini controller with USB)	<p>The controller supplies the power and data required to all connected modules.</p> <p>Characteristics:</p> <ul style="list-style-type: none"> • 1 bus connection max. 1 x 250mA (for ~20 Qbus modules) • USB connection • 388 I/O's • Boolean logic (and/or/if-then-else) and analog logic (+,-,x,/,<,>,<=,>=) • 99 clock times, each with max. 15 I/O's or 1 scene • 91 scenes • Presence simulation • Astronomical Clock • 8 GB SD card with 10 memory banks available (for 10 system configurations) • Width: 4 modules (DIN) • Supplied with DIN rail power supply (4 modules)
CTD01E (mini controller with USB and Ethernet)	<p>The controller supplies the power and data required to all connected modules.</p> <p>Characteristics:</p> <ul style="list-style-type: none"> • 1 bus connection max. 1 x 250mA (for ~20 Qbus modules) • USB connection • Ethernet connection • 388 I/O's • Boolean logic (and/or/if-then-else) and analog logic (+,-,x,/,<,>,<=,>=) • 99 clock times, each with max. 15 I/O's or 1 scene • 91 scenes • Presence simulation • Astronomical Clock • 8 GB SD card with 10 memory banks available (for 10 system configurations) • Width: 4 modules (DIN) • Supplied with DIN rail power supply (4 modules)
CTD01E+ (basic controller with USB and Ethernet)	<p>The controller supplies the power and data required to all connected modules.</p> <p>Characteristics:</p> <ul style="list-style-type: none"> • 1 bus connection max. 1 x 500mA (for ~40 Qbus modules) • USB connection • Ethernet connection • 388 I/O's • Boolean logic (and/or/if-then-else) and analog logic (+,-,x,/,<,>,<=,>=) • 99 clock times, each with max. 15 I/O's or 1 scene • 91 scenes • Presence simulation • Astronomical Clock • 8 GB SD card with 10 memory banks available (for 10 system configurations) • Width: 4 modules (DIN) • Supplied with DIN rail power supply (4 modules)

CTD02E (Full Controller with USB and Ethernet)	<p>The controller supplies the power and data required to all connected modules.</p> <p>Characteristics:</p> <ul style="list-style-type: none"> • 2 bus connections max. 2 x 500mA (for ~80 Qbus modules) • USB connection • Ethernet connection • 388 I/O's • Boolean logic (and/or/if-then-else) and analog logic (+,-,x,/,<,>,<=,>=) • 99 clock times, each with max. 15 I/O's or 1 scene • 91 scenes • Presence simulation • Astronomical Clock • 8 GB SD card with 10 memory banks available (for 10 system configurations) • Width: 6 modules (DIN) • Supplied with DIN rail power supply (4 modules)
CTD03E (Maxi Controller with USB and Ethernet)	<p>The controller supplies the power and data required to all connected modules.</p> <p>Characteristics:</p> <ul style="list-style-type: none"> • 3 bus connections max. 3 x 500mA (for ~120 Qbus modules) • USB connection • Ethernet connection • 388 I/O's • Boolean logic (and/or/if-then-else) and analog logic (+,-,x,/,<,>,<=,>=) • 99 clock times, each with max. 15 I/O's or 1 scene • 91 scenes • Presence simulation • Astronomical Clock • 8 GB SD card with 10 memory banks available (for 10 system configurations) • Width: 6 modules (DIN) • Supplied with DIN rail power supply (4 modules)

2. Installation of the Qbus System Manager

2.1 Where can you find the Qbus System Manager?

The Qbus System Manager is the software you will use to configure the Qbus system. In the Qbus System Manager you can create I/O's (on/off, timers, sequences, scenes, clock times, alarm systems, ...) and determine how those I/O's will be controlled (which button on a switch/motion detector etc. activates each I/O) . All those settings are stored in a .qdb (Qbus DataBase) file.

The Qbus System Manager is available free of charge. You can download the latest version from our website <https://www.qbus.be/en/support/software/system-manager-iii> Click on "Download" to download the latest version of the System Manager. Once the System Manager has been downloaded and run, you will have a shortcut to the program on your desktop.

ATTENTION: the SYSTEM MANAGER III is ONLY used to program CTD controllers (CTD10, CTD40, CTDMax, CTD01Em, CTD01, CTD01E, CTD02E, CTD03E), AND IS NOT COMPATIBLE with CTL controllers (CTL16, CTL32, CTL64, CTL256). The configuration software for CTL controllers is the Serial Manager II, which can be downloaded at <https://www.qbus.be/en/support/software/serial-manager-ii>

2.2 System Manager Hardware Requirements

Before installing the software, make sure that your PC meets the following requirements.

- Supported Operating Systems: Windows 7, Windows 8, Windows 10, Windows 11
- Processor: 1Ghz Pentium or equivalent recommended
- RAM: minimum 1GB, preferably 4GB
- Hard disk: 100 MB free space
- Screen: 1024x768 (minimum) 1680x1050 or higher (recommended)
- Ports: USB or Ethernet port or WiFi available


2.3 Starting Qbus System Manager

After the first start-up of the Qbus System Manager application, the following screen appears where you can choose a language by clicking on a flag. Then click OK.




2.4 Configure Qbus System Manager


In the System Manager menu bar, click "Utilities" and then "Setup" to configure the communication between the System Manager and the Controller.




You will then see the following screen:



In this screen you will see several tabs – click on the “Connection” tab to be able to connect to the Controller. The following screen will then be displayed:



When the correct IP address has been entered, by clicking on the button “Read Settings” in this screen you can see the status of the Controller in the first tab such as the temperature of the CTD, the load on each bus, the voltage on the bus,...If this is not visible, the correct communication method must first be chosen – see next point below.



2.4.1 Communication with the Controller

Go to the “Connection” tab in the Setup screen.

There are two ways to communicate with the Controller (CTD):

1. over Ethernet: Only if the CTD has an Ethernet port – CTD10, CTD40, CTDMax, CTD01Em, CTD01E, CTD01E+, CTD02E, CTD03E.
2. via USB: possible with the following 'older' CTDs: CTD01Em, CTD01, CTD01E, CTD01E+, CTD02E, CTD03E

If you wish to communicate via USB, click on the USB option in the setup screen. Make sure that the selected communication ports are set (default from COM1: to COM8:)

There are 2 ways to connect to the CTD via an Ethernet cable:


1. If you are connecting to the CTD through a router, you must connect the controller to the router using a straight Ethernet cable (supplied with the CTD - usually yellow). **It is important that the Ethernet cable is plugged in before the CTD is powered up.** You will also need a straight cable to connect your computer to the router. If you have a wireless router, you can establish a wireless connection with your computer to this router.
2. If you connect the ethernet port of the CTD directly to your computer, a straight ethernet cable will suffice in most cases. However, if the computer is a bit older, a crossover network cable (not included) is required. **It is important that the Ethernet cable is plugged in and the computer is powered before the CTD is powered up.**

With a correct physical connection, the left LED on the Ethernet port will light up green and the right LED will flash green when there is data traffic.

To operate the device via Ethernet, an IP address must be assigned.

When a device is powered up, it will only search for an IP address if there is already a good physical connection. When the CTD is connected via a router, this router has integrated DHCP, which ensures that each connected device is given an IP address.

To assign the correct IP address to the CTD, uncheck the USB and check the Ethernet option in the setup screen, then click "Search for CTD's and settings...".



When you click on "Search for CTD's and settings...", the System Manager will search for CTD's in your network via UDP broadcast. If the table remains completely empty, select the network interface in which the controller is located. When the desired CTD has been found, double click on the desired line to establish communication. If successful, the settings screen disappears, the correct IP address is entered in the "IP address or host name" field of the setup screen and the connection is established. If you connect through a router, you will get an IP address that usually starts with 192.168. When you connect to the Controller directly from your computer (without a router with DHCP server), you will get an IP address that starts with 169.254


The (Not-)connected status is always visible at the top right. Clicking on this icon connects or disconnects the USB/Ethernet connection to the controller.


ATTENTION!!

- The local communication of the System Manager always takes place via port 8445, which is entered in the "setup" window, in the "Port" field next to the IP address.

Remark: Connect the network cable first, then power up the controller to request an IP address via DHCP. Of course, direct connection to a PC is possible, in which case a crossover cable is sometimes required (purchased separately at an IT specialist store).

Remark: you can give a fixed IP address to the Controller. In the TCP/IP Settings screen you can enter the desired IP address and then click on "Set IP / Gateway / DNS". This is usually more interesting because in the event of a power failure, the CTD and other IP address can be assigned. Be sure to use an IP address that is not yet in use. If necessary, use the "PING" button to test this.



To set a password for the Ethernet connection:


The screenshot shows a software window titled 'Properties' with a sub-tab labeled 'Password'. Inside the window, there is a section labeled 'Password' containing three input fields and a button. The first row is labeled 'Old user / password' and has two adjacent text boxes. The second row is labeled 'New user / password' and has two adjacent text boxes. Below the second row, the text 'Retype the new password' is followed by a single text box. To the right of these fields is a button labeled 'Send new password to the current connection'.

The devices are delivered without a password. When the devices are connected to the Internet and you want to make changes over the Internet, a password must be set for security. To set a password, enter the old password and the new password twice and send it to the interface. This is done via the screen shown above; when you have entered a password twice, click on the option "send new password to the current connection".

If it is your first time using the software, we recommend that you continue with chapter [3.4](#) and [3.3](#). Afterwards you can view the further detail of the setup screen.

2.4.2 Other Setup Options

2.4.2.1 Global Settings



In the “General Settings” tab of the setup screen, you can specify whether you want your controller to automatically switch between summer and winter time, and initialize the System Manager III and controller in different languages (so you can read menus, instructions, etc. on e.g. a TSC5.8 or DIS02 in the corresponding language).

2.4.2.1.1 Daytime, Location

With this option you can select your place of residence. You will then get the list of sunrises and sunsets for each day of the year at the selected place (click on the "List" button to see the exact times). You can adjust these times in a range from -60 minutes to +60 minutes if, for example, you do not find your own place in the drop-down list.

You can assign an I/O to this time of day. If you create a fictitious I/O "_Daytime", this I/O will be active when it is actually daytime in your hometown. You can therefore use this I/O "_Daytime" for logic functions (e.g. if _Daytime = off then Garden_lighting = on).

ATTENTION!!

This function will only work from the next day or after the controller is rebooted, or when you reboot the controller. Via “Read settings” the current sunrise and sunset time are displayed (Today: ...).

2.4.2.1.2 Dimmer-Daytime


Here you can create or select a bistable I/O. This will ensure that each dimmer can have a separate start value according to the status of this dimmer daytime.

2.4.2.1.3 Module Verify Error Address

The "module verify error address" function in the setup screen is an I/O that will intervene if an error is detected in a module on the bus.


You can set your CTD to scan all Qbus modules that have a decimal 6-digit serial number at a certain time. You will then be warned if there is a problem with one of your modules.

You must first add analog logic to set the time of the scan. Go to the Logic button in the System

Manager taskbar, click on the  next to the drop-down box, draw "logic" and then choose that you want to create an analogous logic.

Automatically you will get a few logical lines with I/O's that you have created. When you mark the first I/O used (if XXXX), you can click the "Time" button to add a clock to the logic. When you click on the time, you can set a specific time on the right at which the logic should be executed.

Now you can select at what time the scan should take place - preferably at night, of course.



Then click on the I/O after the → in the "THEN" line and click on the menu "Other" in the list of I/O's on the right-hand side. Here you can select the action "- Module Scan -" by double clicking on it. Clear the "ELSE" condition by clicking "ELSE" and clicking the "Delete Line" button. After transmitting the data, you programmed the controller to wake up every night at 3:00 AM to do a module scan.

You must also indicate which modules you wish to scan. In the module list, when you click on the CTD name or on a specific group of modules (relays, dimmers, ...), you can select in the grid on the right whether you want to scan it with the process described above. The default for each module is checked

The screenshot shows the 'Modules CTD' window in the Qbus System Manager. The left pane displays a tree view of modules under 'CTD' and 'Relays'. The right pane shows a table of modules with columns: Nr, Name, Serial number, Scan, and n/a. The table lists various modules like '1F BR 3 CLOSET', '1F D1', '1F MBR CLOSET', etc., with their serial numbers and scan status.

Nr	Name	Serial number	Scan	n/a
1	1F BR 3 CLOSET	952895	<input checked="" type="checkbox"/>	<input type="checkbox"/>
2	1F D1	113152	<input checked="" type="checkbox"/>	<input type="checkbox"/>
3	1F MBR CLOSET	952538	<input checked="" type="checkbox"/>	<input type="checkbox"/>
4	1F R1	058630	<input checked="" type="checkbox"/>	<input type="checkbox"/>
5	1F R2	058557	<input checked="" type="checkbox"/>	<input type="checkbox"/>
6	1F R3	058636	<input checked="" type="checkbox"/>	<input type="checkbox"/>
7	1F R4	058617	<input checked="" type="checkbox"/>	<input type="checkbox"/>
8	1F R5	058640	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
9	1F R6	058611	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
10	1F SHRING AREA	952975	<input checked="" type="checkbox"/>	<input type="checkbox"/>
11	1F STAIRCASE	952974	<input checked="" type="checkbox"/>	<input type="checkbox"/>
12	1F WALKWAY 01	952971	<input checked="" type="checkbox"/>	<input type="checkbox"/>
13	1F WALKWAY 02	952970	<input checked="" type="checkbox"/>	<input type="checkbox"/>
14	1F WALKWAY 03	952967	<input checked="" type="checkbox"/>	<input type="checkbox"/>
15	2F CLOST	953974	<input checked="" type="checkbox"/>	<input type="checkbox"/>
16	2F DRYING	650843	<input checked="" type="checkbox"/>	<input type="checkbox"/>
17	2F GUST RM SW	651500	<input checked="" type="checkbox"/>	<input type="checkbox"/>
18	2F_STAIR	472948	<input checked="" type="checkbox"/>	<input type="checkbox"/>
19	DIM02SA_36	119168	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
20	ENT PAV SW 2F	651530	<input checked="" type="checkbox"/>	<input type="checkbox"/>
21	GARAGE 1	962346	<input checked="" type="checkbox"/>	<input type="checkbox"/>
22	GARAGE 2	952892	<input checked="" type="checkbox"/>	<input type="checkbox"/>
23	GF DIM 1	113188	<input checked="" type="checkbox"/>	<input type="checkbox"/>
24	GF_COURTYARD	952889	<input checked="" type="checkbox"/>	<input type="checkbox"/>
25	GF_COURTYARDD_ENT	952893	<input checked="" type="checkbox"/>	<input type="checkbox"/>
26	GF_EENTRANCCE_LOBBY	650844	<input checked="" type="checkbox"/>	<input type="checkbox"/>
27	GF_ENTRANCE	651511	<input checked="" type="checkbox"/>	<input type="checkbox"/>
28	GF_MAIN_EENT	962328	<input checked="" type="checkbox"/>	<input type="checkbox"/>

If you have selected a certain I/O in the module verify error address, that I/O will be activated when at least one problem is detected with one of the scanned modules.

If you want to know the status of your scanned module, click the download arrow in the System

Manager , then click the down arrow at "Module scanning".

The screenshot shows the 'Download data' window in the Qbus System Manager. The window has a 'Restore QDB from SD' button and an 'Events' section. The 'Events' section includes a table of events with columns: from, to, Sector start, Sector end, and Nr. The 'Module scanning' section shows a dropdown menu for 'No Mod.Scan Sectors' and a download arrow icon.

from	to	Sector start	Sector end	Nr
26/01/21 15:24:32	29/01/21 15:49:40	1	81	47
29/01/21 16:02:44	24/02/21 14:54:44	82	1384	8
28/02/21 15:27:40	15/03/21 11:30:16	1535	2241	0
02/05/21 09:43:16	17/05/21 14:58:44	4261	4414	47
14/01/22 12:08:48	14/01/22 13:06:04	4416	4415	47
07/03/22 16:28:15	12/04/22 10:59:12	4435	4448	30
12/04/22 12:10:44	12/04/22 12:14:32	32767	32767	47
12/04/22 13:04:56	23/05/22 15:54:28	1	23	22

2.4.2.1.4 Default parameters/mode

ware | SD Card | SWC Colours | Qbus-Cloud

Default parameters / mode

Q Default parameters

Dimmers/RGB+ | Timers | Up/Down | Thermostat

Dimmers

DimMin
Minimum dimming level 33%

DimMax
Maximum level 100%

DimStart

☐ Memory function - Use last status (if greater than 20%)

Level when pressed shortly or when activated in binary logic (Dimmer-Daytime=On) 100%

Level when pressed shortly or when activated in binary logic (Dimmer-Daytime=Off) 100%

Fade In - Out

Speed to fade in when executing via scene 5 sec

Speed to fade out when executing via scene or TimeOff 5 sec

TimeOff

Automatic fade out when pressed shortly 0 Sec.

Events

Save events for this I/O on SD Yes

Default

In this form it is possible to set the default values of various I/O types. Any new I/O created from now on will be created with these parameters. These settings will remain active on the computer and will therefore apply to any new configuration.

If you wish to adjust a parameter for all (or several selected) existing I/O's, you can easily do this via 'grid editor'. More information about this can be found in section [3.12](#)

2.4.2.2 Heating/Cooling Settings

CTD 000059 connected

☐ Communicatie Logging [Read the settings](#)

Status | Global settings | Connection | **Heating/Cooling** | Software | SD Card | SWC Colours | Qbus-Cloud

Classic boiler

Regimes | Source | Heating curve 1 | +

Thermostat (Prog.Sel.)

Controllable by clock and scene?

	Name	Colour
<input type="checkbox"/>	NO CLOCK	Colour 7: White
<input type="checkbox"/>	FREEZE	Colour 3: Blue
<input checked="" type="checkbox"/>	ECONOMY	Colour 4: Orange
<input checked="" type="checkbox"/>	COMFORT	Colour 1: Red
<input checked="" type="checkbox"/>	NIGHT	Colour 2: Green

Default

Default

This color settings only affect the SWC0x and Tastu Display (alarm colors and color of schemes). The color on this screen is only an approximate indication. All new colors have to be sent manually to the desired switches. Afterwards, the selected switches need a power reset.


In the “Heating/Cooling” tab of the setup screen, you can change the main settings for your thermostat programs. You can set 5 thermostat programs in the Qbus system. The default settings are No Clock (Manual), Freeze, Economy, Comfort and Night. While programming a thermostat in a switch, a DIS02, a ViZiR or a TSC5.8, ... (see [3.5.6- Thermostats](#) for more information) you can set the temperature level for each program. However, in the setup screen you can define the names for each program.

If you uncheck the box “Controllable by clock time and scene”, the thermostat that is in this thermostat program will not be able to change by a call from scenes or clock times. eg. An anti-freeze program that you only activate when you are on vacation and that only switches on the heating when the room temperature falls below 5 °C. If your thermostat is set to the anti-freeze program, it will stay on that program even if you forgot to turn off a clock that always turns the heating on in your bathroom at 6:00 AM.


It is also possible to adjust the fixed color of a thermostat's regime. The changes will only take effect after the desired switches have been designated, the colors have been sent and the module is reset via the 'SWC Colours' tab.

The color settings are further explained in point [2.4.2.3](#)

In the Source tab you can already get an overview of your heating installation.




If you work with classic boilers, you can visualize with up to 4 boilers. The parameters 'Delta T' and 'x Min' are still purely informative. Later they will be used to automatically create the logic lines.




When a boiler with a buffer tank is chosen, the screen above will be displayed. The parameters of the heating curve will also be used later to automatically create analog logic.


A final visualization is that of a water-water heat pump. Here one can visualize all I/O's related to such a configuration:



An unlimited number of heating curves can also be visualized as shown below.




2.4.2.3 SWC colours



In this tab “SWC Colors” it is possible to set the 8 standard colours yourself. These 8 colours are the basic colours of the LEDs that are used on all intelligent switches in thermostat mode and as alarm code.

For older SWCs it is recommended to use 'White (old)'. For the new switches where the white is rather pink, 'White' must be selected. Only by marking the desired switches and clicking the send arrow on the right side, the switches will get the new color setting. The module must also be hard reset afterwards.

2.4.2.4 Software Upgrade



Via the first upload arrow it is possible to manually install a new Controller software. However, this will not (much) be necessary. If such new software is available, it will be added to the latest version of the System Manager. As soon as this new version is opened and you are connected to a Controller that does not yet have this latest version, an automatic message will be displayed and you can let this software upgrade.

It is now also possible to update the firmware of the modules that are connected to the bus (only new modules with a new Dual Core Chip have this function).

Via the bottom arrow a form will open, where the upgradeable modules are visible and you can optionally upload the firmware to the modules.

The most recent upgrade files are always installed with the installation of the SMIII, but every time the Module FW upgrade is performed, it will be checked online for newer versions. Any new versions are saved on the computer and can later be used offline.

Modules that have a firmware smaller than the available version will be marked for upgrade. This can be unchecked or even checked to force an upgrade. When clicking the up arrow, the upgrade procedure will start. This can take up to about 2 minutes per module.


When a module shows 'Boot' in the version, then the module only runs in bootstrap. The module will no longer perform any functions. It is still possible to upload the new firmware, so that the module will work perfectly again.

2.4.2.5 SD Bank Information

The SD card on the Qbus CTD has 10 memory banks. This means that you can save up to 10 configurations for your Qbus system on the SD card.

ALL data is stored separately for each bank. So the configuration, the list of modules, the events and the backup of the QDB file are saved separately per bank.

By clicking on the SD card tab, you can give these configurations different names – e.g. summer, winter, vacation, ...




You can use analog logic (see [3.10.2](#)) to switch automatically between different SD banks, e.g. based on date and time (from summer to winter), or manually switch with a push button or by activating a scene. Note that you must have separate .qdb files with their own specific configurations to load into the various SD banks (for example, you create a "summer" configuration (e.g. summer.qdb) and a "winter" configuration (winter.qdb) and loads the summer configuration in SD Bank 1 and the winter configuration in SD Bank 2).

With the button 'Restore QDB from SD' the backup of the configuration file from the SD card can be transferred to the computer. After this action, you will be asked to unzip and open this QDB. After possibly saving the current data, the restored configuration will open immediately.

The button "Format SD" prepares a new SD card for use in the controller. This will erase all data. All recent controllers with Bootstrap V2.2 or higher support SD cards of 4GB or more. However, older controllers only support 1GB or 2GB SD cards.

2.4.2.6 Qbus Cloud



Via this tab you can activate the controller for Qbus Control, in order to control your installation from anywhere in an extremely easy way via any internet platform (Windows, Android, iOS) and to receive messages about your installation. If you also purchased a Ubie, this activation is not necessary. The Ubie will find all controllers in the local network. You can then activate a found controller via QbusControl.com. For further details see [chapter 5](#) of this manual.

2.4.2.7 Expansions for CTD10, CTD40

Unlike previous series of CTD controllers, the bus load limitation with these controller types is not measured by the power consumption on the bus but by the exact number of connected modules. The CTD is supplied as standard in 3 versions:

CTD10: maximum 10 modules

CTD40: maximum 40 modules

CTDmax: No limitation on number of modules. There is a maximum current consumption of 1000mA per bus


In terms of software, a CTD can be expanded per 15 modules. A CTD extended to 70 modules is equivalent to a CTDmax

When you have a network connection to the CTD, this can be done in two ways:

2.4.2.7.1 **Online by entering the code of a purchased expansion card (EXP15):**

You already have an account on Installer Dashboard or QbusControl:

From the setup screen in the System Manager III, click on the “Expansions” tab
Enter the case-sensitive code of the expansion card (3 times 4 characters)



CTD 020219 connected

Communicatie Logging

Read the settings

Status | Global settings | Connection | Heating/Cooling | Software | SD Card | SWC Colours | Qbus-Cloud | Expansions

CTD = CTDmax

	# modules	Installer ID	Date
1	10	ML0212	2022.06.07

Online add expansion via expansion card


1234 - aBcD - 5678

Activate

Add an expansion via phone

And click on “Activate”.

If you are not yet connected to the Installer Dashboard, you will first be asked for the username and password:



Installer Dashboard Login

Installer login

Username

Password


Save password

Connect

Cancel

If you already have an Installer Dashboard account, the CTD will be expanded immediately.

If you do not yet have an account on the Installer Dashboard, but do have an account on Qbuscontrol.com, this approval will be requested:



Qbus

Add your Qbus Control (ex UbieCloud of QbusCloud) account to Installer Dashboard?

OK

Annuleren

After entering your company name and VAT number, the Installer Dashboard is also activated and the CTD will also be expanded immediately.

Installer Dashboard account creation

Enter the VAT-number of your company

OK

Cancel

Installer Dashboard account creation

Enter the name of your company.

OK

Cancel

If you do not yet have an account on the Installer Dashboard nor on QbusControl

Then you can create an account via <https://installerdashboard.qbus.be>
Afterwards follow the steps as mentioned above.

2.4.2.7.2 **Offline: via telephone contact with a QBUS service employee**

From the setup screen in the System Manager III, click on the “Expansions” tab
Click on the button “Add an expansion by phone” and the following screen will appear:

Add an expansion via phone (+32 53 60.72.10)

Installer code

TT8769

Give CTD serial number, installer code and following key to the support person

223205

Received key to expand CTD

If you pass on your installer code from the Installer Dashboard together with the CTD serial number and the red key by telephone, the Qbus employee will provide you with a new 6-digit key. You will then receive an invoice for the requested number of licenses (15,30,45 or 60)

After entering the received key and clicking on “Activate”, the CTD will be expanded with the number of requested modules.

3. Taskbar Qbus System Manager

The task bar of the Qbus System Manager looks like this:




3.1 Open and Save

The first two keys on the left   serve to open and save configuration files (.qdb).

All taskbar options can also be started via the menu bar.

Since V3.25.00, the software will also check every 5 minutes if changes have been made and automatically save them in the \QBUS\TEMP\BACKUP folder.

The following screen appears via the menu option “Open automatic backup”:





After selecting the correct serial number of the controller and the desired time, this automatically stored QDB can be opened.

If you have not yet connected to a controller, the backups of the configuration can be found with serial number 000000.

NOTE: Only the five most recent backups per controller are kept in the \QBUS\TEMP\BACKUP folder

3.2 Extract data from the controller

The  key is used to read the configuration file backup, event logging or module scanning from the controller's SD card.




Download data

Restore QDB from SD

Restore QDB from SD

Events

Summer (B1) Current sector pointer: 4127

 ☐ Read ALL data on SD

Events already in buffer on this computer

from	to	Sector start	Sector end	Nr
13/01/22 08:18:16	13/01/22 09:02:16	31674	32767	47
13/01/22 09:02:20	20/04/22 10:21:32	1	3014	34

Export

All

From

8 /05/2022 0 :00:00


To

8 /06/2022 0 :00:00

Export Events to .CSV

Module scanning

Summer (B1) No Mod.Scan Sectors



3.2.1 Restore QDB from SD

The QDB file contains all data that can be configured by the System Manager III. This data is NOT necessarily used by the controller. For the operation of the system, the controller uses the data sent with the upload arrow! When closing or saving the QDB, you are asked to save this file (as a backup) on the SD card in the CTD.

With the button 'Restore QDB from SD' the backup of the configuration file from the SD card can be transferred to the computer. After this action, you will be asked to unzip and open this QDB. After saving the current data, the restored configuration will open immediately.


3.2.2 Events

In this frame you can already see which periods have already been read from this CTD on this computer.

When you click on the Events arrow and confirm with OK, the data from the last saved sector of the SD card will be read back in time and saved in the "TEMP" folder. And this up to and including the

time of the previous download. If you also want to read all previous data, you can check the box “Read ALL data on SD”.

You can follow the timestamp that is read in the frame “Connection” at the bottom right of the screen. When you have read the desired period, you can “Cancel” the download.



You can then “Export” the desired events from all I/O’s or from 1 I/O of the selected period to a CSV file.

Without I/O selection each event always contains the data of the entire address (4 sub-addresses). The status of each individual sub-address (1 to 4) can be found in the column “Status1” to “Status4” You can open this data file in a spreadsheet (e.g. MS Excel) for further processing or filtering.

Each SD sector contains 48 events. The CTD with firmware V3.10.1 or higher has a ring buffer of 32767 sectors. The old data will therefore be overwritten over time without warning.

If the firmware is still V3.10.0 or lower, the CTD will stop saving events when the last sector is reached. The “Clear ALL Events” button will then clear all events on the SD card, after confirmation. Previous saved data will be kept in the temporary folder on the computer!

More explanation about the content of the 4 statuses can be found in the following table:

Mode	State 1	State 2	State 3	State 4	Remark
BI (Bistable, Toggle)	0 = OFF; 255 = ON	0 = OFF; 255 = ON	0 = OFF; 255 = ON	0 = OFF; 255 = ON	1 I/O per status
T1 - T5 (Timer 1 - 5)	Time of the Timer; 255 = ON	Time of the Timer; 255 = ON	Time of the Timer; 255 = ON	Time of the Timer; 255 = ON	1 I/O per status
D1 - D2 (Dimmer)	State 0-255	-	State 0-255	-	Divide by 2.55 to convert into %
L1 - L2	CLC1 Set point	CLC1 Current value	CLC2 Setpoint	CLC2 current value	Divide by 2.55 to convert into %
RO (Roller shutter with position)	Position 0-255	Slat position 0-255	Position 0-255	Slat position 0-255	Divide by 2.55 to convert into %
U1-U2 (Updown/Roller Shutter)	0 = Stop; 1 = Up; 2 = Down	-	0 = Stop; 1 = Up; 2 = Down	-	
TH (Thermostat)	1 = Heating ON 2 = Cooling ON 3 = Boost ON 4 = Alarm ON Or combination	Set point in °C (without offset)	Current value in °C (without offset)	Regime: 0 = Manual 1 = Frost 2 = Economy 3 = Comfort 4 = Night	4 statuses for 1 thermostat
TH PID (Thermostat with PID control)	0 – 255 = analog value of heating or cooling	Set point in °C (without offset)	Current value in °C (without offset)	Regime: 0 = Manual 1 = Frost 2 = Economy 3 = Comfort 4 = Night	4 statuses for 1 thermostat
HV (HVAC)	0-4000 = CO2 value	0 – 100 = % Humidity	0 – 255: refresh value	Regime: 0 = Manual 1 = Night 2 = Boost 3 = OFF 4 = Auto	4 statuses for 1 HVAC address
EC (Energy Counter)	0 – 255 = Number of pulses measured during the last minute input 1	0 – 255 = Number of pulses measured during the last minute input 2	0 – 255 = Number of pulses measured during the last minute input 3	0 – 255 = Number of pulses measured during the last minute input 4	
UN (Universal)	0 – 7 = Sub-address of I/O	XH byte of the 24-bit value	H-byte of the 24-bit value	L-byte of the 24-bit value	

3.2.3 Module scanning

When you click on the 'Download Module scanning' arrow, you will see all saved logs. The module scanning, which you can activate via analog logic, not only checks whether the module is still responding, but it also checks whether all configuration data of the module is still correct.


3.3 Send data to the controller



Whenever you change something in the .qdb file in the System Manager, the arrow for sending data to the controller will turn red. This means that you need to send the changes to the controller. If you forget this, when you close the System Manager you will receive a message that you have not sent all the changes to the controller. You can then submit the changes or ignore the changes made.


Remark: After adding modules or programming changes, ALWAYS send the information to the controller so that any changes or additions are actually implemented. Once the components and I/O's have been entered, you must also send all data to the controller, otherwise no test can be performed for the I/O's. Always make sure that you are connected to the CTD via the Ethernet or USB port when sending data to the controller.

When you click the upload arrow, the following screen appears.



Select "All data" whenever you want to send a completely new .qdb file to the controller (e.g. when you first configure your system or when you want to send a new .qdb file to a new SD bank). After that first time, it is possible to only send "All unsent changes" after you have changed settings in your program.

With a CTD10 or CTD40 it is not possible to send data if you want to configure more modules than allowed. Following message will appear:




Expanding the CTD10 and CTD40 were explained in point [2.4.2.7](#)

Sending and verifying data takes place in various phases: When you click on "More detail" you can follow these steps nicely.

A first step is synchronizing the clock of the CTD with the time of the PC.

As mentioned above, you can send up to 10 configurations to different SD banks (e.g. a winter program, a summer program, a holiday program, an "early shift" program, a "late shift" program, etc.). see point [2.4.2.5](#) above for naming the various SD banks. Before pressing the "Send" button, make sure you choose the correct SD bank from the drop-down list in the window above.

After clicking the "Send" button, the data will be sent to the controller, together with the module data it will be saved to the selected SD bank and then all modules will be programmed.




If you receive error messages, this may mean that a module was not found: possibly because the concerned module is not correctly connected to the bus or the serial number has been entered incorrectly. Try using Utilities/Communication Test to see if that module is communicating perfectly. If it still gives an error, check the connection between the module and the bus.

3.4 Programming modules



This option opens the main programming window. When you select "modules", the following screen appears.



In the top left corner, type the serial number for the module you wish to program. Each module has a unique serial number consisting of either 6 digits or 10 hexadecimal characters. The "New Module Wizard" is described later.


Once you have entered the serial number, the corresponding module will appear, as shown in the following screen. The next screen contains more than one module.

It is also important that you type in ALL modules connected to the bus, even if they are not immediately used. A module can already contain a configuration. This 'old' configuration may conflict with the existing settings!

Possible modules are relay04, relay08, dimmer, thermostats, switches, etc.

If you want to delete a module, select it and click on the red "-" button (top right corner).


You can also enter the intelligent switches in a second way, without having to enter the serial numbers of the switches one by one. The "Search for modules" button in the lower left corner allows you to search for modules which, after clicking the switches one by one, are recognized and used in the program.





The “Wizard new module...” allows you to add a module without having to enter the serial number. The first free serial number is then chosen and the module is then set to n/a. This is shown in red in the treewview.

And as long as a module has not yet been sent correctly, the background of the serial number field will remain highlighted in orange.



The following wizard appears:



In a first screen you choose the type of module as shown in the figure above.
 When double clicking on the desired type, the next selection screen will appear where you can make the right choice from all possible module types.
 Before clicking on 'Finish', you can enter the number of modules to be created and, if desired, select the location of the modules.
 An example of the choice of relay modules and switches can be found in the two figures below.



In this last screen you can select the version: Niko, Bticino, Sumum, CJC, JUNG, Lithoss, Tastu (or Easywave if your installation has a QWI/EW module)

Properly naming the module names and locations is an ideal way to quickly find the modules in the list. When the tab "Location" is selected, the treeview will be sorted on location. Locations can be added and deleted using the   buttons. An example of such a list can be found below.

Modules

s/n: [REDACTED] Wizard new module...

Type Location

↑ +

All s/n:000059

- 1st floor
 - Bathroom
 - 650012: SWC04/G_16
 - MBR
 - Dressing
 - 650014: SWC04/G_17
 - B00006: DIS_26
 - 650016: SWC04/G_18
 - 650018: SWC04/G_19
 - Guestroom
 - 650010: SWC04/G_15
- 2nd floor
 - 050020: REL04SA_10
 - 650020: SWC04/G_20
- Groundfloor
 - Garage
 - B00001: CVD04SA_21
 - B00002: CVD04SA_22
 - B00003: CVD04SA_23
 - B00004: CVD04SA_24
 - 050002: REL04SA_1
 - 050004: REL04SA_2
 - 050006: REL04SA_3
 - 050008: REL04SA_4
 - 050010: REL04SA_5
 - 050012: REL04SA_6
 - 050014: REL04SA_7
 - 050016: REL04SA_8
 - 050018: REL04SA_9
 - Hall
 - 650008: SWC04/G_14
 - Kitchen
 - 650002: SWC04/G_11
 - Living
 - B00005: DIS_25
 - 650004: SWC04/G_12
 - 650006: SWC04/G_13
- Outdoor

Modules All s/n:000059

Nr.	Name	Serial number	Scan	n/a
1	CVD04SA_21	B00001		<input type="checkbox"/>
2	CVD04SA_22	B00002		<input type="checkbox"/>
3	CVD04SA_23	B00003		<input type="checkbox"/>
4	CVD04SA_24	B00004		<input type="checkbox"/>
5	DIS_25	B00005		<input type="checkbox"/>
6	DIS_26	B00006		<input type="checkbox"/>
7	REL04SA_1	050002	<input checked="" type="checkbox"/>	<input type="checkbox"/>
8	REL04SA_10	050020	<input checked="" type="checkbox"/>	<input type="checkbox"/>
9	REL04SA_2	050004	<input checked="" type="checkbox"/>	<input type="checkbox"/>
10	REL04SA_3	050006	<input checked="" type="checkbox"/>	<input type="checkbox"/>
11	REL04SA_4	050008	<input checked="" type="checkbox"/>	<input type="checkbox"/>
12	REL04SA_5	050010	<input checked="" type="checkbox"/>	<input type="checkbox"/>
13	REL04SA_6	050012	<input checked="" type="checkbox"/>	<input type="checkbox"/>
14	REL04SA_7	050014	<input checked="" type="checkbox"/>	<input type="checkbox"/>
15	REL04SA_8	050016	<input checked="" type="checkbox"/>	<input type="checkbox"/>
16	REL04SA_9	050018		<input checked="" type="checkbox"/>
17	SWC04/G_11	650002	<input checked="" type="checkbox"/>	<input type="checkbox"/>
18	SWC04/G_12	650004	<input checked="" type="checkbox"/>	<input type="checkbox"/>
19	SWC04/G_13	650006	<input checked="" type="checkbox"/>	<input type="checkbox"/>
20	SWC04/G_14	650008	<input checked="" type="checkbox"/>	<input type="checkbox"/>
21	SWC04/G_15	650010	<input checked="" type="checkbox"/>	<input type="checkbox"/>
22	SWC04/G_16	650012	<input checked="" type="checkbox"/>	<input type="checkbox"/>
23	SWC04/G_17	650014	<input checked="" type="checkbox"/>	<input type="checkbox"/>
24	SWC04/G_18	650016	<input checked="" type="checkbox"/>	<input type="checkbox"/>
25	SWC04/G_19	650018	<input checked="" type="checkbox"/>	<input type="checkbox"/>
26	SWC04/G_20	650020	<input checked="" type="checkbox"/>	<input type="checkbox"/>

For more details on programming modules, see the information later in this document ([Section 4](#)).


3.5 I/O's




You can create I/O's (dimmer, on/off, push button, timer, etc.) in two ways.

1. When programming switches, relay modules, dimmer modules, ... you can create I/O's for each key on the switch (see "Programming Switches," later in this document).
2. You can create all I/O's at once without immediately assigning them to a particular switch, detector or other module. This is what we will explain in this section.

When you click the I/O's (Lamp) button, the following screen is displayed.



Use the "Wizard new I/O..." button to create a new I/O. The following window is displayed.



In this window, select the type of I/O you wish to create. To select lighting, use the first option displayed and choose the type of I/O. Below you will find a list of I/O types that you can use in your Qbus system.

After selecting the desired I/O type, click "Next" and give the I/O a name, click on "Finish". If you wish to create several I/O's of the same type simultaneously, you can also enter the number here. The names are therefore numbered consecutively, starting from the entered name.

All I/O's will then be visible in the screen above.

The buttons on the right side of the list of I/O's (All, On/Off, Dimmers, ...) allow you to select which I/O's are displayed, so that you can find the desired I/O more quickly. For example, the "All" key displays all I/O's. With the on/off key only on/off contacts are displayed. With the "Dimmer" button, only the dimmer contacts, etc.

When you select one I/O and click the "Used in..." button, information is displayed about where in your program this I/O is used. In addition, you will be shown the serial number of the relay or dimmer component, the serial number of the switches, the scenes, clock times and logic rules where this I/O is used, ...

Finally, by selecting an I/O and clicking the "Read Values" button, you will see the current status of the I/O (on or off). Of course, this only works after you've also sent the changes to the system. The "Test" key can be used to (de-)activate this specific I/O.

3.5.1 Toggle (Bistable)

Toggle is the option called "on/off". Pressing it once switches the I/O on, pressing it again switches it off.

3.5.2 Push button

Only when the key is pressed is the I/O active - e.g. for a doorbell. Do not confuse the push button (input mode) on the switch with a push button I/O! The push button on the switch can be used for all modes (on/off, monostable, timer, ...), of which the push button mode (monostable) is one. Never use this type of I/O for long-term contacts on an input module. In that case, I would constantly occupy the bus with the input and thus put more strain on communication.

ATTENTION!!

A push button I/O CANNOT be controlled via the Cloud. To open a door or gate, it is better to use a Timer2 of, for example, 2 seconds.

3.5.3 Dimmer1B / Dimmer2B

Dimmer1B stands for Dimmer with one button (when the dimmer is off, press the button once to go to its start value depending on the day/night state (default 100%), press it again to go to 0%, or hold it down until the dimmer has reached the correct light level.

3.5.4 Shutter1B / Shutter2B

As with dimmers, there is a Shutter1B option (use one button) and a Shutter2B option (control the shutter/motor with two buttons – Up to open, Down to close).

For a Roller shutter 1B, you can open the roller shutter completely by pressing briefly. Pressing the button when the roller shutter is running will stop the action. Long press will lower the roller shutter.

3.5.5 Intermittent

With the "Intermittent" function you can switch an I/O on and off alternately (e.g. garden sprinklers). The on/off times are adjustable from 1 to 255 seconds or 1 to 255 minutes.

3.5.6 Intelligent Thermostat

When you select a thermostat in e.g. a DIS or SWC0xT or click on "properties" in a thermostat switch, the following thermostat screen will be displayed.

Thermostat | (A08)

Basic | Advanced

Range in Cloud 0°C 35°C

Programs

NO CLOCK	FREEZE	ECONOMY	COMFORT	NIGHT
<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
20°C	5°C	20°C	22°C	15°C

Time Off

Time to switch to program 'night' after manually put to

ECONOMY COMFORT N/A

SwitchTime

Put this output in a Switchtime

Display

Short Name THERMOST_001

Default

This screen shows 5 thermostat programs including manual control. By (un)checking the fields right below the program names, you can select which programs you want to control from the control on the switch.

The "Time Off" box can be used to have the system switch automatically from Economy or Comfort to Night after a number of minutes when selecting the program manually.

Via tab "Advanced" more additional parameters can be set.

Thermostat THERMOST_001 | (A08)

Basic **Advanced**

PID

☐ PID Heating/Cooling

Boost

2°C

Hysteresis

Heating 0.5°C

Cooling 0.5°C

Max. Setp. Offset

Maximum Setpoint Offset +/- 63.5°C

Alarm

Minimum 1°C

Maximum 63.5°C

Adjust temp.

0°C

Events

Save events for this output on SD Yes

Default

The "boost" option can be used if you have an additional valve or circuit that you can control to heat the room faster. In that case you may want to add heat from this second controlled heating unit (boost heating = heating coming from both units) if the difference in degrees between the set value and the measured temperature is greater than e.g. 2 °C.

The "hysteresis" refers to the difference in degrees required to turn on the heating system. This prevents the heating and cooling from switching on alternately when you control both heating and cooling. For example, if you want the heating to operate when the temperature is less than 20 degrees and the cooling is activated at a temperature above 20 degrees, it will continuously switch between cooling and heating. If you set the hysteresis to 0.5 degrees, the heating will start from 19.5 degrees and the cooling from 20.5 degrees.

With the "alarm" option, set the maximum and minimum temperatures and select whether you want to close a contact (this can be done via the relay) or create an alarm that you can send via your mobile phone (if you have an SMS module) or via ethernet (if you have an ethernet port on the controller).

From CTD FW3.09 you can also limit the set point. It is not possible to have the set point deviate further from the set point of that program. A setting of 5°C thus limits the set point between 17°C and 27°C when the Comfort regime of 22°C is active.

Intelligent Heating / Cooling (Qbus PID)

PRINCIPLE

The Qbus intelligent Heating / Cooling works on the basis of PID control. The controller calculates the difference between the desired temperature (set point) and the room temperature, and will control the heating depending on the magnitude of this difference. We call this Intelligent Heating / Cooling or Qbus PID control.

The Intelligent Heating / Cooling works as follows:

- 1) The difference between the room temperature and the desired temperature is calculated ("DIFF");
- 2) The time to change the temperature 0.5 degrees has been calculated (TIME)
- 3) The DIFF value and the TIME value are multiplied by the GAIN (see below) to calculate the proportional value that the heating system will control.




Figure 1: Representation of the proportional aspect of Qbus PID Control

During each proportional step, a fine-tuning mechanism based on the Integrator value will speed up or slow down the heating or cooling process. See below for more explanation about the integrator value.





Figure 2: representation of the acceleration/deceleration mechanism of Qbus PID control

The Qbus intelligent heating / cooling works as shown below. Both heating and cooling are activated when the room temperature differs 0.5 degrees from the desired temperature. A “dead zone” between heating and cooling must avoid continuous alternating between cooling and heating: when the room is heating and the desired temperature has been reached, cooling can only start when the room temperature rises above the dead zone (adjustable via the Qbus configuration software) has increased.



Room temp. has to decrease to Setpoint -0,5C before Heating Starts.
If new Setpoint (new program) is below minimum PID value, Cooling won't be activated

Figure 3: Principle Qbus Intelligent Heating / Cooling

CONFIGURATION OF THE QBUS PID CONTROL IN THE SYSTEM MANAGER

Once PID is selected the thermostat screen will change as shown below. CLICK THE “DEFAULT” BUTTON AT THE TOP RIGHT TO USE THE DEFAULT VALUES FOR THE QBUS PID CONTROL. IT IS RECOMMENDED TO USE THESE STANDARD VALUES DURING FIRST PROGRAMMING AND ADJUST THEM AS NECESSARY BASED ON THE EFFECTIVE RESULTS OF THE CONTROL.

Thermostat | (A03)

Properties...

Programs

Program	NO CLOCK	FREEZE	ECONOMY	COMFORT	NIGHT
Selected	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
Setpoint	20°C	5°C	20°C	22°C	15°C
Dead zone	.5°C	.5°C	.5°C	.5°C	.5°C

☐ Check on display

Time Off
Time to switch to program 'night' after manually put to

Program	ECONOMY	COMFORT
Selected	<input type="checkbox"/>	<input type="checkbox"/>
Time Off		N/A

Display
Short Name: TH Bathroom

SwitchTime
Put this output in a Switchtime

Events
Save events for this output on SD

Default

Range (MDO01/SEN0x/REL02T/INA02)
0 to 63.5°C

Range in Cloud
0°C to 35°C

PID (Advanced settings)

☒ PID Heating
Integrator: 15
Gain: 3°C

☐ PID Cooling

Relais
Delay: 3m

Button2 on DIS01
☐ Program selector ☒ Enable/Disable Cooling

Speed 2
2°C

PID
Minimum: 20°C
Maximum: 26°C

Adjust temp.
0°C

Max. Setp. Offset
Maximum Setpoint Offset +/-: 63.5°C

Yes PID Event Time: 2m

Integrator: both for the relay and 0-10V-based Intelligent Heating/Cooling. The integrator value is added to the control value (= calculated as $\text{DIFF} \times \text{TIME} \times \text{GAIN}$) to smooth the control. The higher the integrator value, the flatter the curve, causing the control process to react more slowly. We recommend that you do not change the integrator value at system start-up and only adjust this value if necessary after the system has been in operation for a while.

Gain: Used to calculate the heating/cooling proportional control value ($\text{DIFF} \times \text{TIME} \times \text{GAIN}$; see explanation above). The higher this value, the greater the jumps in the checking process will be to speed up this process). A gain that is too large can result in an overshoot. Again, we recommend using the default value of the gain in a first stage and only adjusting it after using the system for a while.

Ddelay: is only used with relay-based Intelligent Heating/Cooling. When relays are used to control heating and cooling, a 10-minute cycle is used to go through the process. Since a relay can only be

open or allowed, e.g. a relay that is 75% open is translated by opening this relay in the cycle for 75% of the cycle time (=7.5 minutes) and for 25% of that time (2.5 minutes). Since most electronic thermostatic valves have a delay from fully open to fully closed (usually about 3 minutes), the “delay” time indicated in the “delay” field is added to the 10-minute cycle time to minimize the effect of this “slow effect” to filter out thermostatic valves.

Button2 on DIS01: when the Qbus PID is active and this field is on, the second button on a DIS02IT can be used to switch the cooling off or on.

Speed 2: only when the difference between room and set temperature is higher than the number of degrees stated in “Speed 2” an extra relay can be switched on for additional heating or cooling. Speed 2 is an I/O that can be assigned to a relay or 0-10V control module.

PID Minimum / Maximum: describes the range that can be used for manual temperature control via touch screens or switches. When a temperature lower than the PID minimum temperature is selected in a thermostat program, the cooling will never be activated. This is to prevent, for example, the air conditioning being used to cool down a room during the night or when you are absent.

Dead zone: dead zone between heating and cooling: when cooling is off, the room temperature must be lower by at least the number of degrees stated in this field before the heating is switched on. Conversely, it should be that number of degrees warmer than the set point before cooling starts. See also figure 3 above for an example.

Events: The events are on by default. Next to this button is the interval at which these events can be forwarded. We recommend choosing an interval of no less than 2 minutes.

CONFIGURE I/O'S WITH QBUS PID

Configure relay outputs

By creating a Qbus PID thermostat, four I/O's are automatically created: Heating, Cooling, Speed 1 and Speed 2. These I/O's can be assigned to relays.

REL04SA module 050002

Location: REL04SA_1

Properties...: Controlled via bus

Read Values

Output 1 (A04.1)

Name: Living spots

Mode: Toggle

Properties...

Test

Push button

Output 2

Name: TH Bathroom (Heating)

Output 3

Name:

Mode:

Output 4

Name:

Mode:

Input A (All Off/On)

Name:

Push button

Input delay: 700ms

3s

Stand Alone

Delay before All OFF is activated: n/a

	All OFF	All ON
Living spots	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Output 2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Output 3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Output 4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>


Default

Heating and Cooling must be assigned to the relay to which the valve, controlling them, is connected. Speed 1 and Speed 2 must be assigned to a fan if there is one present. Speed 2 will only work if the

difference between the room and requested temperature is at least the number of degrees assigned to Speed 2 in the PID screen.

Configure analog (0-10V) I/O's


Since the Speed1 / Speed2 I/O's are ON/OFF contacts, they can only be assigned to relays, not analog I/O's. Only the Cooling / Heating contacts can be assigned to 0-10V I/O modules.



Configure an Air Quality Sensor (AIR01 with CO2 / Humidity / Temperature)


ATTENTION: INTELLIGENT HEATING AND COOLING IS SUPPORTED ONLY IN THERMOSTAT MODE, NOT HVAC MODE. WHEN THE TEMPERATURE SENSOR FROM AN AIR01 SENSOR IS USED TO CONTROL THE PID THERMOSTAT I/O (AND NOT THE HVAC THERMOSTAT I/O) MUST BE LINKED TO THIS AIR01 TEMPERATURE SENSOR.

This can be done via the TH Link button in the setup screen of the AIR01.




USING QBUS PID IN COMBINATION WITH ANALOGUE LOGIC

When a PID thermostat mode has been created you will find following I/O's in the list of I/O's that can be used in analogue logic:




Thermostat (Setpoint): Set point (requested temperature) of this thermostat; it can be used as a condition: (IF Setpoint = X degrees, THEN...) or as a consequence (If X is ON, then set Setpoint to X degrees)



Thermostat (RoomTemp.): Room temperature measured by the thermostat sensor; can only be used as a condition

Thermostat (Prog): Respective program (Comfort, Economy, Night, No Clock,...) of the thermostat mode; can be used as a condition or as a result.



Thermostat (TimeOff): the Time-Off function of the respective thermostat program; can be used as a condition or as a result.

Thermostat (Heating): if the "Heating" I/O of the thermostat mode is on (too cold) or off (warm enough); used as a condition

Thermostat (Cooling): if the "Cooling" I/O of the thermostat mode is on (too warm) or off (cold enough); used as a condition

Thermostat (Speed1): if the I/O "Speed 1" of the thermostat mode is on or off; used as a condition

Thermostat (Speed2): if the I/O "Speed 2" of the thermostat mode is on or off; used as a condition

Thermostat (HeatingPWM): if the "PID Heating" I/O of the PID control via RELAY is on or off; used as a condition

Thermostat (CoolingPWM): if the "PID Cooling" I/O of the PID control via RELAY is on or off; used as a condition

Thermostat (HeatingAnalog): if the "PID Heating" I/O of the PID control via ANALOGUE MODULES (0-10V) is on or off; used as a condition

Thermostat (CoolingAnalog): if the "PID Cooling" I/O of the PID control via ANALOGUE MODULES (0-10V) is on or off; used as a condition

3.5.7 Audio – Audiolink

With this selection you can choose between the old audio addresses (for use with SER10) or controlling audio interfaces via the Ubie (Sonos, Bose, ...)

The 'Wizard New Output...' dialog box is shown. Under 'Kind of output', the 'Audio' radio button is selected. To the right, a dropdown menu is open, showing three options: 'Audiolink (via Ubie)', 'Audiolink (via Ubie)', and 'Qbus audio address (EOL)'. The first two options are highlighted in blue. At the bottom, there are four buttons: 'Previous', 'Next', 'Finish' (highlighted in green), and 'Cancel'.


After changing the name, the I/O is created. Subsequently, this is composed of the On/Off(Play/Pause), Volume+, Volume- and favorites (next and reset). The first I/O is of the bistable type and can also be assigned in scenes. The others are monostable and have a multiple functions regarding short or long press. A short click on a volume key increases or decreases the volume by one step. Pressing longer increases or decreases the volume as long as you press. The favorites button takes the next favorite with each short click as set via QbusControl. A long press always activates the first favorite. You can assign all these functions to a specific key on a switch or display. An example of these settings in a switch (on page 2) can be found in the figure below:

The screenshot shows the 'SWC04 module 0022B11111' configuration window. The 'Global settings' section shows 'Location' as 'SwC04_7' and 'Type' as 'SwC04 Switch'. Below this, there are four button configuration panels labeled 'Button 1 (A15.1)', 'Button 2 (A15.2)', 'Button 3 (A15.2)', and 'Button 4 (A15.3)'. Each panel has a dropdown menu for the button name, a 'Push Button' dropdown, a 'Test' button, and checkboxes for 'Input connected', 'Colour On', and 'Colour Off'. The 'Audiolink_Ubie (Vol+)' button is configured with 'Audiolink_Ubie (Vol+)' as the name and 'Push Button' as the action. The 'Audiolink_Ubie' button is configured with 'Audiolink_Ubie' as the name and 'Toggle' as the action. The 'Audiolink_Ubie (Fav.)' button is configured with 'Audiolink_Ubie (Fav.)' as the name and 'Push Button' as the action. The 'Audiolink_Ubie (Fav.)' button is configured with 'Audiolink_Ubie (Fav.)' as the name and 'Push Button' as the action.

3.5.8 Sequencer

A sequencer uses scenes in a sequential order.

When you select a sequencer, the following screen is displayed.



Choose the first scene for choice 1. The 2nd will follow automatically as this is the next scene in the sequence you programmed. This means that the first press will activate the scene in position 1, and the next press will activate the scene in position 2. It is a looping process.

With the option "Number" on the right side you can select the number of scenes for this scene.

Choose the first, the rest will follow the scene set as primary, based on the order in which these scenes were created. When this sequencer is assigned to a key, each press of the key will I/O the following scene.

When pressed for a long time, the first scene is always activated.

3.5.9 Timers

In the Qbus software you can select 5 timer modes:

Timer 1 ("Forget timer"):

Each time the button is pressed, the timer is switched on or off. For example, in a hall, the button is pressed once to turn on the light for a certain period of time (set by clicking the "Properties" button and using the "Min" or "Sec" buttons to select the time in minutes or seconds), and a second time to extinguish the lights.

ATTENTION: work as long as possible in seconds (up to more than 4 minutes) to have an accuracy of 1 second. If you set the timer in minutes, the accuracy is 1 MINUTE.

Timer 2 ("Staircase timer"):

Each time the button is pressed, the timer is reset to the set value. For example, if your timer is set to 3 minutes, the timer will run for 3 minutes each time you press the button. This timer does not work with motion detectors - motion detectors can only control toggle I/O's and will continue to count down for the period set in the detector module.

From CTD FW3.08 the Timer2 has an extra parameter: When the "Automatic Reset" is turned on, this timer will be reset to its set value when it reaches 0. Such a timer can be useful for continuous testing in analogue logic.

Timer 3 ("lazy timer"):


The timer is activated the first time the button is pressed. Pressing the button a second time switches on/off mode - the value set in the timer is then no longer relevant. A third press of the button switches the I/O off. For the front door, for example, you can use a timer, but you also have the option of leaving the light on indefinitely without the timer turning it off automatically. If you have selected Timer 3 and set it to, for example, 3 minutes, and you press the button, the timer will be activated for 3

minutes, and the light will turn off at the end of that period. If you press the button twice, the light will stay on until you press it a third time - then the light will go out.


Timer 4:

This is a linked timer: an impulse (pressing a button, motion detection, ...) activates an I/O (e.g. I/O 1). After a certain period of time (can be set by the user), a second I/O is activated (e.g. I/O 2, selected by the user). When I/O 1 (the “master”) is turned off, I/O 2 (the “slave”) will also be turned off after a preset period. Example: When you come home in the evening, the motion detector outside turns on the front door lighting, and 1 minute later the hallway lighting.

To program this timer, you must assign the Timer4 master for the first I/O. When you click "enter", a drop-down screen will ask you to define the I/O that will be associated (with a certain delay) to this first I/O (will be defined as Timer4 slave). You can set the delay time by clicking "Properties".



The delay time can be set by pressing the “Properties” button.




Timer 5

With this timer you can link a manual input (switch) and a detector input. A detector activates an I/O only when it detects movement or when the light level falls below a set threshold (see below in MDI/MDO programming). In the Qbus system, a detector has priority over a switch. If you also want to control an I/O controlled by a detector with a switch, the I/O will not respond to the command of the switch if the parameters of the detector do not match (e.g. no movement detected or light level still too high - the detector turns your I/O off immediately after you command the switch to turn it on).

You can avoid this problem by using a Timer 5. A timer 5 is programmed as follows:

- Step 1: Create a new I/O (Timer 5 Manual) on the switch you want to use to control that I/O. When you click "enter", you will be asked to name the I/O that you want to control with the detector (you will have two names for the same I/O, one for the manual control, the other for the detector - add the I/O "manual" or "detector" so you can distinguish between the two).



- Step 2: You must also link Timer 5 Detector to the detector you want to use to control this I/O. If you program a SWC04M, you can link this Timer 5 Detector directly to first input key. However, if you use an MDI01 or SEN04 as a detector, you must create a fictitious bistable I/O, as an MDI01 or SEN04 can only control bistable I/O's (no timers). In this case, first create a fictitious bistable I/O, and link this fictitious I/O to Timer 5 Detector via logic
- Step 3: In the MDI01 or SEN04, use the fictitious I/O as one of the controlled I/O's: when the detector now detects something, it will switch on the fictitious I/O, which in turn activates Timer 5 Detector (both are linked via an internal logic function).

Detector module SEN04 s/n:969696

Location: Read Values

Triggers: First Keep Scan

Timers: extension Sec Lock Sec

LED: ☒ Movement ☐ Light ☐ 2s ☒ 5s

Input 1 (A11.1): Name: ☒ Movement ☐ Temperature ☒ Light Properties...

Input 2: ☒ Movement ☐ Temperature ☒ Light

- Step 4: In order to give priority to the manual control of the I/O over the Detector control, you must assign the manual I/O to the relay to which the I/O is connected. Your manual operation now takes precedence over your detector.

REL04SA module 050004

Location: Read Values

Properties...:

Output 1: Name: Mode:

Output 2: Name: Mode:

Output 3: Name: Mode:

Output 4: Name: Mode:

Input A (All Off/On): Name: Input delay:

3.5.10 (Energy) meter

A meter mode can be created in different ways

1. An energy meter can be created on the ECM04 module: By clicking on the function “New I/O” in the drop-down menu of input 1.
2. Wizard new I/O: In the I/O’s tab you have the function “Wizard new I/O”, by opening this you can create an ECM04 input via the option “Energy meter” or create a normal meter mode.

If you create an ECM04 input via one of these methods, the three other inputs of the ECM04 will automatically be created as meter inputs.

In our example, we have created and named 4 entries as follows: E-meter, Solar Energy, Gas Meter, Water Meter

ECM04 module 818181

Global settings

Location: ECM04_32

Update interval: 1m

Read Values

Input (A12)

Input	Name	Push button	Properties...	Reset
1.	E-meter	Push button	Properties...	Reset
2.	Solar panels	Push button	Properties...	Reset
3.	Gas counter	Push button	Properties...	Reset
4.	Water counter	Push button	Properties...	Reset

When we look at the properties of an (energy) meter input, we see several parameters:

Minimum: This is the minimum limit of the value that will be measured and can be displayed in EQOmmmand/Cloud.

Maximum: This is the maximum limit of the value that will be measured and can be displayed in EQOmmmand/Cloud.


Pulse value: This is the factor with which we have to multiply the measured pulse to get a correct value. For example, each pulse represents 100Wh, then the pulse value must also be 100 if we want to express it in Watthours, if we want to express it in kWh then the pulse value must be 0.1.

Unit: this is the unit in which we express the measured value.

Trigger: is a set point when an alarm I/O can be activated. The trigger can be set from 0 to 1,000,000,000 pulses.

Warning Address: This is the I/O that turns on when the number of pulses is equal to or greater than the trigger value.

If we want to read the number of pulses in the System Manager, it is sufficient to press the button "Read values". This data is synchronized every minute by default, but the update interval can be set from 1 to 255 minutes. The pulses can also be reset to zero for each input by clicking the "Reset" button.



ECM04 module 818181

Global settings

Location:

Update interval:

ECM04

Input (A12)

-
-
-
-

For more information about how to measure (energy) via Qbus, see [chapter 6](#) in this manual.

3.5.11 Universal function

A universal I/O can have a 24-bit signed value (-8,388,607 ... +8.388.607)

In the properties you can choose the type.

Univ.Mode Consumption heat pump | (A16.1)

Properties

Type: Power

Minimum: 0

Maximum: 100

Resolution: 0.001

Unit: kW

Events

Save events for this output on SD: No

The selected type also determines the icon in EQOmmmand and Cloud.

The minimum and maximum are used in EQOmmmand and Cloud to display the gauge nicely.

3.5.12 Stepper I/O

A stepper I/O can have any value from 0 to 254.

The minimum and maximum values can be set. In the following example an I/O was set to display (via MODBUS) the mode of a heat pump:

Stepper HP mode | (A38.1)

Minimum

Minimum level: 0

Maximum

Maximum level: 4

Reset

Automatic Reset (= Cycle): No

Labels

Step	Name
0	Off
1	Ventilate
2	Cooling
3	Heating
4	Dehumidify

Display

Short Name: HP mode

SwitchTime

Put this output in a Switchtime: [Clock Icon]

Events

Save events for this output on SD: Yes

When this I/O is assigned to a pushbutton, each pulse will always increase or decrease the stepper by the value 1.

A long press on the up button or down button will reset it to the value 0.


If the 'Automatic Reset' was switched on, the maximum level is reached and another short pulse is given 'up', the minimum level will be selected again.

This does not work in the reverse direction: when the I/O is already at the minimum, clicking the down button will NOT set it to the maximum level.


Via a scene, any value can be set.

3.5.13 I/O properties

A property window is displayed on the right side for each I/O.



You can also reach the properties directly from the switches, relays, dimmer modules, ...




Reload: Add a delay to turn on or off the selected I/O (period between when you press the switch and the corresponding relay I/O is turned on or off).

Display: the 'short' name (max. 12 characters) that will appear on a display (e.g. TSC5.8, ViZiR, Tastu Display, ...)

Display Warning: Warning on a display when the I/O is still active. On a TSC 5.8. you can -check the status- and you will get an overview of all I/O's that are still active and that have been selected via the properties screen

Simulation: Should this I/O be taken into account for the presence simulation tool, a standard part of the system? E.g. not helpful to have a thermostat outlet or a light in a hallway without outside windows as part of a simulation.



Switch Time: This graphical weekly overview provides an easy way to update the clock times of e.g. a thermostat.



An I/O can be turned on (Yellow) or off (Black) at a specific time. With a thermostat, the color of the regime is displayed.

Editing is possible via the grid. The name and time of the clock time can be changed. The desired status can be set, a weekday can be checked and unchecked. And in the last column, the full clock time can be temporarily switched on or off.

When a parameter is adjusted and there are other I/O's in this clock time, you will be asked to adjust the entire clock time or create a new clock time, so that the time of the other I/O's remains unchanged.

You can also remove or add a clock time with the   buttons, right above the table.


Logic / Link: used to create multilinks. A multilink is a setting where you can control several I/O's with one switch. This is not the same as a scene - a scene allows you to set various I/O's to a predetermined level. With a multilink you can control various I/O's together (e.g. adjust the setting of all dimmers in your living room together; with a scene you can only set them to 1 value). See point [3.6.2](#) for more information about working with multilinks.

Events: If you set the button under 'Events' in the Properties screen to "on", all status changes will be saved to the SD card in the controller. Reading the event data is described in [3.2.2](#)


3.6 Editing scenes



Qbus offers you the possibility to create scenes. An scene is a complete situation in which lighting, shutters, dimmer, etc. are controlled together so that you get a complete result in your zone. When you click the "scenes" button, the following screen appears.



The I/O's in your program are displayed on the right side of the screen. In the section on the left, select "new preset". Then, by double clicking or with the → and ← keys, move the desired I/O's to the scene you are creating. Change the values based on what you want to do by selecting the appropriate

I/O and using the up or down arrows  on the right side of the list. The "Set all values" option activates all selected I/O's while the "Clear all values" option places all I/O's in an off state.

If you are creating two opposing scenes, complete the first scene, then create a new one with the "Copy from ..." key and copy the previous scene; then use "Clear all values", "Set all values" or use the arrows, depending on the situation you want to assign to the new scene.

Remark: If you use thermostats in your scenes, they will not change to the requested program if it is in a non-"Changeable by clock time or scene" program. These settings can be adjusted in the setup screen (Utilities – Setup – Heating/Cooling) – see also "Thermostat settings" in point [2.4.2.2](#) of this manual.

The scenes can be activated in various ways.

1. Button on an intelligent switch
2. Pushbuttons or switches connected to the INPUT modules, with INP02, INP04, INP08, INP16 & INP08/230.
3. DIS02 module (DIS02 IT)
4. Touch screen module (TSC 5.8, ViZiR, DIS, ...)
5. Also from the System Manager with the TEST button in the "Scenes" window shown above.
6. Logic
7. ...


3.6.1 Simulation




This application can be used to give the impression that someone is at home when you are away. The Qbus system can be set up to record all events that occur on the bus. These events are then repeated on a weekly basis each time the simulation program is activated.

Step 1: Select I/O's

First you need to select which I/O's will be part of the simulation. For example, it makes no sense to include heating I/O's - after all, heating is not visible from the outside and switching them on would be a waste of energy.




For each I/O you can indicate in the properties whether it may be activated during simulation. Simulation is deactivated by default.




Step 2: Record Simulation

Now that you have selected all the I/O's that you want to use during the simulation, you need to record the events that occur over a period of time so that they can be repeated during the simulation. To record a simulation, you must assign one key of a switch or touch screen to "Record Simulation" or you can click the "Record" via Utilities – Setup:



Using a Smart Switch (SWC).

Click on a button of the specific switch you wish to use, click on "- Scenes -" on top of the I/O list and scroll through the list until you find "- Record sim. -" at the bottom. Click that button when you want to start recording.



Using a touch screen

You can assign the "Simulation Record" key to the touch screen. In the I/O's list of the control table, you can select Scenes and choose the desired simulation key.

Using the switches connected to the input modules

The "Record Simulation" key can be assigned to the switches connected to the input modules, including INP02, INP04, INP08, INP16, INP08/230. The allocation procedure is the same as that described in 6.5.1.1.

Comments:


- The recording of a simulation starts immediately. The system will continue to record until you stop recording by pressing the button again. If you do not interrupt the recording, the system will continue to record - when the end of the week is reached, the events recorded during this week will be gradually overwritten.
- The system can record at a maximum speed of 1 recording per 4 seconds, and up to 90 recordings per hour. When the recording function is stopped, the system will remember all events up to 1 minute before the recording stops.
- If the recording is stopped, then turned on again during the same hour, the events that were previously recorded during that hour will be erased (activating the recording will erase the events during the hour in which the recording is activated).
- To download the recorded events to your .qdb file, go to the menu item "Edit", "Simulation", and click on the down arrow. As a result, only the recorded events of the indicated weekdays will be downloaded from the controller. ATTENTION: BEFORE DOWNLOADING THE SIMULATION, RECORDING MUST BE STOPPED (Simulation off); THE RECORDED EVENTS WILL NOT BE SAVED ON THE CONTROLLER'S SD CARD WHEN RECORDING HAS STOPPED. If you changed certain events in the simulation list, you can send the modified simulation list to the controller by clicking the red upload arrow.
- Scenes are also fully recorded, but when the Simulation is played back, only those I/O's are used in a scene where those I/O's were specified to be allowed to be used in simulation.

Step 3: Activate the simulation

You can activate the simulation by clicking the "Simulation" button, which you can assign to a switch or control table as you did for the "Record Sim." button (see above). When you click on "Simulation", the simulation starts playing the next hour (Simulation ON at 1:26 PM, starts simulation at 2:00 PM).

The simulation repeats the events on the same day, and the same time in hours, minutes and seconds as the recording. You can check the list of events by day and time by clicking "Edit", "Simulation". In this screen, select the desired day to view the list of recorded events. You can change this list by adding events (click on "Insert line" and then on the I/O you wish to add). You can view the time in the list of I/O's (select an I/O in the list of simulations and change the time with the clock on the right), and the status of the I/O (click the up or down arrow to the right of the list of simulations).

Since the simulation program records all events per day, you must record an entire week to have a list of events for each day in the simulation program. If you have only recorded one day, the simulation will only be active during that day. However, you can add events to other days by copying days for which you have recorded events (use the button "Copy from .." in the list of simulations).



3.6.2 Multi-link


A multilink is a setting where you can control several I/O's with one switch. That's not the same as a scene - a scene allows you to set various I/O's to a predetermined level. With a multilink you can control various I/O's together (e.g. adjust the setting of all dimmers in your living room together; you can only activate them to a certain level with a scene).

Multilinks are generally used to control all dimmers or shutters in a room/building simultaneously. Multilinks are programmed as follows.

Step 1: Select the I/O that will be controlled (usually Dimmer or Shutter mode) or create a fictitious address, e.g. "AllDimmers" (go to "I/O's" in the System Manager and use the Wizard New I/O).

Step 2: In the "properties" screen of this I/O, click the "Yes/No" button next to Multi-Link

You can create a new multilink - e.g. "AllDimmers Multilink", and select from the list on the right all the I/O's you want to control with the same button (all the selected dimmers will follow the 1 button control - as if they were on the same circuit. Bistable I/O's are switched on if the 'client' is different from 0%).



Now you only need to assign the (fictional) I/O “Alldimmers” to a switch - with the push buttons on that switch you will be able to control all selected I/O’s simultaneously.


You can also apply a similar procedure for shutters. It can let 'follow' several roller shutters of the same type in the same way.

For shutters with positioning, the control must be assigned to an effective I/O. You have to take into account that the PERCENTAGE value is linked and shutters that 'follow' and that are longer or shorter can follow for a while or even return!

3.7 Setting time schedules (Clock times or Weekly program)



The Qbus controller has an integrated clock. When you click this button, the following screen appears.



The screen with all I/O's reappears on the right.

On the left you can edit (or add) a clock time and set the time and weekdays at which it should be activated. Then move all the I/O's you would like to include in the schedule and set the status you

want to give them when this schedule is called, using the arrows . The days of the week in green are the selected days, these are the days on which you want to activate the program during the selected period. If you do not wish to activate the time schedule on certain days, deselect these days.

Remark: Create 2 time schedules – one for switching certain I/O's on and the other for switching them off.

You will also find a nice graphic overview under 'SwitchTime' in the properties of an I/O; This is described in [3.5.11](#)

3.8 Control table selection



The Qbus control tables are essentially lists of I/O's that you wish to control with a DIS02, TSC5.8, ViZiR or SMS module. Also, if you want to use the EQOweb web server that is standard on a Controller with Ethernet port, you must create a control table for EQOweb. When selecting a new control table, you must also select which "type" of module you wish to use to establish the connection. The following screen is displayed when you select a control table.

The I/O's are displayed on the right side of the screen. The tables are on the left. Table on A01 is usually the first, and should always be used for the EQOweb web server if EQOweb is to be used. You can create up to 6 menus per operating table. Select Menu 1 and double click the menu key so you can change its name. When you have selected menu 1, move the desired I/O's to menu 1. Select menu 2, move the desired I/O's to menu 2, etc.

With the "insert line" and "delete line" keys you can insert a line between two I/O's if you have forgotten I/O's or delete what you will not need in the end. "Delete line" does not delete the corresponding I/O from the program itself, but only from the table or menu.

You also have the option of not using any menus, just the "All" list. When using menus, you must select the menu first and then the I/O when using the module to which the control table is linked (TSC, DIS02, SMS). If you only use the "All" list, you can go through all the I/O's directly without entering the menus first.


ATTENTION!! The EQOweb web server ONLY sees and serves the table at Address 1 (A01). This will also be marked as Type “Eqoweb” by default – the type cannot be changed here.

The EQOweb web server is NOT available on Ethernet Firmware 6.0.7! This has been replaced by the QbusCloud, UbieCloud or Qbus Control.

The EQOweb is available on each CTD10, CTD40 and CTDmax, even if you are not connected to the internet.

For these CTDs, the EQOweb is accessible via the standard HTTP port 80. For the older controllers, this control is accessible via port 8444. For more info, see point [5.2](#)

You can turn this option on or off via the setup screen. When you click on “Read settings” you can switch the EQOweb on or off in CTD10, CTD40 and CTDmax:



The screenshot shows a software interface for configuring the EQOweb. It features two main sections for connection type selection: Ethernet (selected) and USB (disabled). The Ethernet section includes fields for IP address (192.168.0.162), Port (8445), User, Password, and CTD Name. A 'Search for CTD's and settings...' button is also present. To the right, a panel titled 'EQOweb (poort 80)' contains a large red downward arrow and two buttons labeled 'On' and 'Off'.

Searching connection

1) ☒ Ethernet (ETH0x)

TCP/IP

IP address or host name for TCP/IP connection: 192.168.0.162

Port: 8445

User: [] Password: []

CTD Name: []

Default ports on LAN:
EQOweb: 80
SM III: 8445
EQOmand: 8446

Search for CTD's and settings...

EQOweb (poort 80)

On

Off

2) ☐ USB (Not available on CTD10, CTD40 or CTDmax)

3.9 Infrared samples

The infrared functions in the Qbus system can be used in two ways:

- 1) You can control I/O's of the Qbus system with one of your remote controls (e.g. press a number on your remote control to turn off all the lights). This is done via Qbus switches with infrared ports (SWC04I/XX or DIS02 IT).
- 2) You can use Qbus to control devices that you usually operate with a remote control (air conditioning, TV, audio,... - e.g. automatically switch on the air conditioning at a temperature higher than 24 °C.). This is done via an infrared transmitter IRG04 (Eol).

In any case, you must first "teach" your Qbus system the infrared codes of your remote control, choose a known type of code from the database or enter an RC5 or Pronto HEX code manually. You can do this by creating infrared samples as described below.

3.9.1 Creating infrared samples

With a SWC04I/XX

Step 1:

If you are using BTicino switches: Press the two upper or lower buttons on the switch simultaneously for about 5 seconds until all the LEDs on the switch are red and not flashing.

If you use Niko switches: simultaneously press the two buttons on the left side or the two buttons on the right side of the switch for about 5 seconds until all LEDs on the switch are red and not flashing.

Step 2:

Press any button on the remote control while pointing the infrared button at the SWC04I/XX. If this is a valid infrared code, the LEDs now turn yellow.

Step 3: Sampling the Codes

While sampling, you need to send the IR-signals for channels 1-12 (in that order) to the switch. On a universal remote control, you must select a "device" button (SAT2, AUX, ...) that you will only use to operate your Qbus system.

You will have to cycle through the 12 channels when sampling, even if you want to use less than 12. After you have sampled the codes, you can assign each code to a particular I/O (see below).

Press the button on the remote control twice for each channel. The key will henceforth be used to switch the corresponding Qbus I/O on and off.

e.g. Press "1" – the LEDs will turn blue, press "1" again the LEDs will turn green. Press "2" – the LEDs will turn blue, press "2" again the LEDs will turn green. Continue until you have done this for the twelve channels. When sampling is complete, the switch LEDs will blink for approximately 3 seconds.

Via a DIS02 ITX/XX

Start of sampling

1. Make sure the DIS02 ITX/XX is in channel mode (press IR button).
2. Press the "+" and "-" buttons simultaneously.
3. The display of the DIS02 ITX/XX shows "LEARN IR?". To confirm, press any key on the remote control while pointing the infrared light at the SWC04I/XX.

Procedure for sampling

Follow the instructions on the DIS02 ITX/XX

Explanation of the codes requested by the DIS02 ITX/XX:

- Press the "+" button: this will be the button on your remote that you use to turn on an I/O
- Press the "-" button: this will be the button on your remote that you use to turn off an I/O

- Press key ">": this will be the key on your remote that you use to go to the next I/O in the DIS02 ITX/XX table
- Press key "<": this will be the key on your remote that you use to go to the previous I/O in the DIS02 ITX/XX table
- Press button "M": this will be the button on your remote control that you use to select the desired menu.
- Press key 0-F: corresponds to numbers 1-16. These buttons on your remote control allow you to select the desired I/O.

End of sampling.


After sampling the last code (key F) the bottom line of your DIS02 ITX/XX will be filled with asterisks. This indicates the end of the sampling procedure.

3.9.2 Assign I/O's to the sampled infrared codes.


With a SWC04/XX

When you select the infrared switch in the Modules menu of the System Manager, go to the IR page. On this page you will see 12 IR fields. In these fields you can also select which I/O you want to activate with the concerned IR code. The first 4 automatically contain the 4 I/O's or scenes from page one of the IR switch. You can select I/O's 5-12.

Now you need to match the I/O's or scenes to the corresponding IR codes of the remote you want to use. You have already entered the 12 infrared codes into the Qbus system by following the steps described above. On the IR page, click the down arrow to download the samples already entered (see screenshot below).



You will see the date and time of the samples created. When you click on that date and time, you will see the 12 samples each appear individually in the "Sample" box on the IR page. By double clicking on a sample, you assign it to the I/O in the IR list marked green.




Send these new settings to the controller. You can now operate your Qbus system with your remote control.

Remark: You can name each sample (e.g. 1, 2, 3, ... FFW, Back, ...) and the range of samples by going to the Samples menu in the System Manager. If you downloaded the samples by clicking the arrow on the IR page of your IR switch as explained above, you will find the sample range "Other" in the Samples menu. Brand, Type and Sample names can be edited here.

Via a DIS02 ITX/XX

To link IR samples to I/O's via a DIS02 IT module, you must first create a control table (see [section 3.8](#)). Make sure to add all the I/O's you want to control with your remote to this control table; the maximum number of I/O's that you can control directly via a DIS02 IT with your remote control is 16. When you work via menus, you can control ten channels per menu ('M' key + number 0-9).

On the screen of the DIS02 module, you need to select the control table that you want to associate with the DIS02.



In the "mode" field you can choose how you want to operate your DIS02:


- "Menus as set in table": you can first choose between 10 menus, then between 10 I/O's that you can place in each menu
- "No menus max 16 channels": you can assign 16 I/O's directly to 16 channels on your remotes, and switch between all further, not directly linked I/O's using the up/down arrow keys on your remote.

By clicking the down arrow, you can download the IR samples you entered on the DIS02 as we described earlier in this section". When you download this list, you will see the date and time you samples; when you click on this date and time in the Device Type Menu, you will be presented with the list of samples in the "Sample" screen shown below.

Then you need to assign each sample to the IR list on the left (highlight the function in the IR list to which you want to assign the sample and double click on the corresponding sample). Keep the following in mind:


- "V+": this will be the button on your remote control that you use to turn on an I/O
- "V-": This will be the button on your remote that you use to turn off an I/O
- "CH+": this will be the key on your remote that you use to go to the next I/O in the DIS02 ITX/XX table
- "CH-": this will be the key on your remote that you use to go to the next I/O in the DIS02 ITX/XX table
- "R" or "M": This will be the button on your remote control that you use to select the desired menu.

When you have assigned all samples to the IR list and you chose the option "No menus", then you have to assign the desired channels to the samples.



3.9.3 Sending infrared code via the IRG04

When you are in the programming screen of an IRG, select “Universal IR TX”. You can select how many ports of the IRG04 you will use (e.g. use 1 port to send 64 codes, 2 ports to send 32 codes or 4 ports to send 16 codes each). Then you must create a new address per module - an IR list will appear corresponding to the number of ports you have selected and that you will use (if 4 ports are selected, you will receive an IR list with four times 16 codes - page 1/01 to page 4/15).



Then select the type of device you want to control (you must first sample the infrared codes to be used in the Qbus system according to the instructions in "Sampling IR codes"), and double click on the samples to assign them to a specific port and code. to link. You can enter a name in the IR function.

Now if you want to send these infrared ports through a Qbus input device, you will find these assigned IR codes at the Scenes or Clock Times button in the System Manager - under "Others" in the I/O selection screen. To associate these IR codes to a button on a switch or to a control table or a touch screen, you must first create a scene, select the corresponding code (play CD, next, volume up, ...), and in turn link the required scene to a switch or control table.


3.10 Creating Logical Functions



You can create logic functions in the System Manager by clicking the icon shown above in the taskbar. Before you can create logic functions, you must have available I/O's.


When you click on the "+" button next to the "Group" drop-down box, you can create a new logic group and enter the desired name.

When you click the "+" button next to the "Name" drop-down box, you will see a pop-up asking if you want to create binary or analog logic.



3.10.1 Binary Logic (If – Then – Else with ON/OFF)


Automatically an "if - then - else" logic will appear at random with a few I/O's you have created.



Double-clicking on the list of I/O's, overwrites the I/O concerned in the highlighted line in the field of the logic expression. You can add or delete lines by clicking the "Insert line" & "Delete line"-button. You can switch the logic between AND and OR conditions by clicking the AND/OR button when the AND/OR line to be changed is highlighted. Every time you change from AND to OR (or vice versa), parentheses will be added automatically. The position of the brackets cannot be changed. Outputs that are at the end of a logical expression will therefore have the most influence on the result. You can also change the desired status of the selected I/O by clicking the On/Off button.

Remark

If you have a long list of I/O's, you can use the "Filter" field in the list of I/O's. Placing a name in the filter will only show you I/O's that start with that name (if you marked the "Start"-option) or that have the letters involved in their names (if you marked the "Part"-key). You can also choose whether or not the word in the filter is case sensitive.




3.10.2 Analogue Logic (If – Then – Else with all values and operations x,/,+,-,<,>,=)

Analog logic allows you to activate I/O's based on the status of another I/O, more than one other I/O, a calculation that uses I/O's as parameters or is based on time. For example, it might only be possible to switch on the heating in one room if, between two times (e.g. 7:00 AM and 9:00 AM), the temperature in another room is < or = X degrees.

By pressing the "+" key next to the drop-down window in the Logic module, you can select the creation of analog logic. You will automatically get an IF - THEN - ELSE logic, with certain I/O's already created.

Remark: To create logic functions, I/O's must first be created.



Select I/O's

To use different I/O's in the logic expressions, first click on the I/O in the logic you want to change, then double click on the desired I/O in the list of I/O's on the right.

Select the calculation

When you highlight the characters (<,>=) in the logical expression, you can change them by clicking the desired character to the right of the logical expression window. You can change the value by pressing the up or down arrow on the right side of the logical expression box. By highlighting a calculation (x,/,+,-) in the logical expression, you can change it by selecting the desired calculation on the right side of the window.

Remark: use "> 0" in the logic expression to indicate that an I/O must be ON. If the I/O must be OFF, use "= 0".

The conditions change

AND/OR conditions can be changed by highlighting the AND/OR condition in the logical expression and clicking the inverse on the right. AND/OR conditions can also be deleted by clicking "Delete Line", and you can add conditions by clicking the "Insert AND/OR" button.

Any condition can also be used as a parameter in a calculation; highlight the I/O you want to use in the calculation and click the "Insert Edit" button.


Using the clock

Highlight an I/O in the logic expression, then click the "Time" button.

Highlight the value next to the clock, and select a combination of month/day/weekday/hours/minutes or any of these elements alone. In this way, an I/O can be activated at a specific time.

Example: Switching configuration files between summer and winter

As mentioned earlier in this document (2.4.2.3 SD banks), different configuration files (.qdb files) can be downloaded on different SD banks in the controller. Analog logic can be used to automatically switch between .qdb files based on time. For example, if you have a winter.qdb file (with heating controlled by clock times) and a summer.qdb file (without heating), you can automatically switch between winter and summer. Click on "Other" in the list of I/O's to be able to select SD banks.



How does Qbus analogue logic work?

Syntax:

In contrast to binary logic, you first determine the value that you will send as a result to one or more I/O's.

It is important to know that the calculation of the Qbus logic does NOT follow standard mathematical rules.

- In Qbus logic, all operations are calculated from left to right and everything is calculated immediately before moving on to the next operation. For example:

1+1x0 is executed in Qbus from left to right, or 1+1 = 2, 2x0=0 (mathematically, the multiplication is normally worked out first, before the addition, so that according to the mathematical operation the result would be: 1+ (1x0) = 1+0 = 1).
- Qbus logic counts within a range of 0 to 65535. But the result of any operation can never be more than 255 and never less than 0. For example:
255+255=255
255+255/4=127
0-255=0
In combination with the calculation that is done from left to right, and that every operation computed first before continuing, we get the following: 255+255/4 = (255+255)/4 = 510/4=127.
- If one logical operation contains both analog operations (%, volts, ...) and "binary" operations (ON/OFF, UP/DOWN), then all analog operations must be listed first followed by the binary operations. E.g.:
IF 0<1
THEN analog value 1 --> analog value 2
THEN analog value 3 --> analog value 4
THEN analog value 5 --> binary I/O 1

Addition and subtraction

An I/O that is ON is also represented as 255. In analog logic this means that adding up two I/O's that are both ON (ON+ON = ON) can also be shown as follows: 255+255=255.

Multiply

Since Qbus counts between 0 and 255, all percentage values are also reduced compared to 255. A dimmer that lights up 5% is shown in the Qbus protocol as 5% of 255 = 13 (rounded). If percentages are then multiplied, a different result is obtained than the mathematically calculated result. E.g. 5% x 5%: is first converted relative to 255 (so 13 x 13 = 169), and then this result is again displayed relative to 255 in percent (169/255 = 66.3%).

TIP: If you wish to multiply by an analog variable equal to 1, use 0.4% to multiply (0.4% of 255 = 1). For example, Light 80% x Presence 0.4% = 80%.


Also when multiplying, a value can never be less than 0 and never be more than 255. So if you multiply with an ON/OFF I/O, the result is always 0 (=OFF) or 255 (=ON). E.g.: Light 80% x presence ON (=255) = 100%. Light 80% x presence OFF (=0) = 0%.

The analog logic internally calculates all intermediate operations on 16 bits (0-65535) but the result is always a byte (0-255)

Depending on the mode, this is displayed correctly (dimmer 0-100%, TH 0-63.5°C +/- offset, ...)

When using universal I/O's in analog logic, the values are multiplied by a fixed factor (5). This gives a range of more than 10 bits.

A maximum value up to 1275 (255 x 5) can thus be tested. In the following example, where the multiplier is set to 0.01, a power can be tested up to a maximum of 12.75 kW




3.11 Choosing an alarm




Qbus gives you the option to receive alerts when certain situations occur. This can be done with the Alarm function. The type of warning can be virtual, e.g. by lighting up one or more LEDs, or written, in the form of a text message on a mobile phone.

When you select the Alarm menu of the program, the following screen will be displayed.



Giving a name to an alarm is essentially creating a new alarm. The screen above then takes the following form.



The selection used under the name is usually the one shown in the screen above.

An overview of the options depending on the priority:

Alarm code: (e.g. burglary)

It has the highest priority and will be displayed to the desired switches, regardless of their color setting, lock LEDs or pushbuttons. Flash LEDs with an adjustable rhythm and color pattern.

Blocking keys possible on one or more SWC's.

Unlock all SWC's by pressing key on unblocked SWC('s), via touch screen, logic, or PC.

The ratio of the flashing on/off can be set in the following ratios:

	Color 1	Color 2 (or off)
Slow 50/50	1.5s	1.5s
Slow 20/80	250ms	1.5s
Fast 50/50	120ms	120ms
Fast 80/20	300ms	60ms

Activating an external I/O: (e.g. door opener, mute audio, open garage door, etc.)

With certain actions, e.g. doorbell rings, garage door is open, heating is on with open windows, this 'alarm' can be shown to one or more SWCs in the form of flashing the LEDs. When pressing any key, one can control an I/O (e.g. door opener) regardless of the programming of that switch. When the button is released, the switch returns to its original functions.

Other switches, with the same alarm code, will also stop flashing.

Up to 4 arbitrary I/O's (or scenes) can be defined per SWC.

ATTENTION!

Please use a timer with a short reload (e.g. max. 2s) as an external I/O or only use scenes without delay! A pulse is given that simulates this input. For example, if the timer1 is still on, it will be turned off when the alarm stops!

LED intensity reduction:

When going to sleep or leaving a house, it may be desirable that all switches go into a standby mode: pressing a scene, (e.g. "All lights off") can also cause some or all switches to turn off their LEDs. (small power saving up to about 5W).

Global settings

Name

Go to sleep

Function

Led reducing

1st touch = normal, after 5s = reduce

Always reduced

1st touch = normal, after 5s = reduce again

Always normal on SWC0x

Always normal everywhere

With the first options, the LEDs remain off.

With the second option, the LEDs will return to their normal functions after a pulse on one of the push buttons and the LEDs are reduced again if there is no action on that switch for 5 seconds.

With the third option, the LEDs on that switch will revert to their normal color settings.

The fourth option will stop this alarm and turn the LEDs on ALL switches, where this alarm is still active, will return to their normal color settings.

The latter also applies when this alarm is stopped via logic, scene or clock time

Global settings

Name

Go to sleep

Function

Led reducing

1st touch = normal, after 5s = reduce

completely out

You can choose between LEDs completely off (both on and off status) or a value of 15 for the on position and 4 for the off position. These are values compared to the maximum color setting of 200

Change LED colors:

Would you like a different color on your switches without using a PC?

An evening with friends and create a different scene?

Simple: a single button on a selected switch can display different colors to all designated switches: red on/greenoff or blue on/purple off...

The composition of these 7 basic colors can be set via the SETUP screen – SWC Colours.

If you select one switch or multiple switches (via CTRL or SHIFT) in the list on the right hand side and then press the green arrow, you can transfer the selected alarm setting to the selected switches.

These settings can still be changed per switch. E.g. a useful example is to block all inputs. The alarm can then be modified in one switch to raise the alarm...

Go to modules, choose the desired switch and click on the Alarms button and adjust the desired setting. The alarm is therefore performed wherever it is set.


But the settings can have a different function per switch. In the list 'Used in...' one can see if the alarm has the general setting (=) or it has a custom setting (< >) or if the alarm is not set to that switch (blank)

Used in..	
454545	SWN04I_36
515151	SWN01_30
650002	SWC04/G_11
650004	SWC04/G_12
650006	SWC04/G_13
650008	SWC04/G_14
650010	SWC04/G_15
650012	SWC04/G_16
650014	SWC04/G_17
650016	SWC04/G_18
650018	SWC04/G_19
650020	SWC04/G_20
B00005	DIS_25
B00006	DIS_26

A maximum of 8 alarms and 4 external I/O's can be set per switch. By double clicking on a alarm it will be added or removed. Also selecting in group and clicking on the arrows is possible.

The alarm activation setting is made by means of logic functions. By logic functions we mean that when one or more events occur, the corresponding alarm will be triggered.

Setting the alarm for SMS, where the user also receives a warning in the form of a text message, is done as follows. Go to the SMS module via the "modules" option in the program's taskbar and choose the alarms tab; the following screen is displayed.



In the screen above, enter the SMS text, e.g. the text that will be sent to your mobile phone. In the right part of the screen, choose the phones for the people who should receive the notification of this particular alarm. If you create a second alarm, you will need to re-select the phone numbers of the people who should receive the message, as it may not be necessary for everyone to receive all alarms.

The options above the names allow you to set the repeat time if the alarm is not initially detected.


3.12 Conversion table



By clicking on icon above, you can enter a list of I/O values with correspond to different input values. In this way you can configure linear, logarithmic, reverse, ... curves. This conversion can be used in analogue logic to set an I/O to a value depending on the value of another I/O.


A simple example is a “heating curve”. Depending on the outside temperature another temperature in one zone can be set.

When choosing ‘Heating curve’ next screen will appear:




“TH input” is the thermostat I/O that measures the outdoor temperature. The desired temperature of “TH I/O” will be controlled. In the example above the offset of TH Outdoor was set to -20°C. Temperature ranges from -20°C to +43.5°C. When colder than -10°C the desired water temperature will be 60°C. This will linear decrease to 50°C for temperatures up to 10°C. A minimum temperature of 50°C will be set when warmer.

When both thermostat I/O's are set, an analogue logic was created:



An installer can change this logical expression via the “Professional service mode”

Conversion tables in ‘advanced’ mode can completely be set as desired.




Every input value (0 - 255) results in another I/O value (0 - 255)

Every intermediate I/O value will be divided linearly.

The number of divisions can also be set. Up to 32 divisions will be made visible graphically.

Next example shows a logarithmic conversion:




An input value of 20% will result in an I/O value of 39.2%

An input value of 40% will result in an I/O value of 62.7%

...

Remark: When a value is empty in the beginning or at the end of the table, this will result in a value of zero. The next example will give values between 39.2% and 78.4% if the input value is between 20% and 80%. Otherwise it will result in 0%!





3.13 Grid editor (Global editing)



Global editing makes it possible to change the properties of all selected I/O's simultaneously with the same action; this can range from setting the reload delay to turning the events on or off. Click on the shortcut or go to Edit – Grid editor. The following window will then be displayed:


The screenshot shows the 'Grid editor' window. On the left, there is a tree view under 'Kind of output' with categories like 'Switched', 'Dimmable', 'Shutters', 'Thermostats', 'Ventilation', and 'Special'. The 'Location' tab is selected. On the right, there is a table with columns: Name, Short Name, Mode, Events, Cloud, Status, and Counter. The table lists various I/Os such as '#Daytime', '#detector front door', '3 way valve', 'Aldimmers', 'Bathroom', 'Bathroom vent.', 'Bathroom ventilator', 'Consumption heat pump', 'Driveway button', 'Driveway detector', 'E-meter', 'EMM EI Consumption', 'EMM EI Day Consumption', 'EMM EI Day Injection', 'EMM EI Injection', 'EMM EI Night Consumption', 'EMM EI Night Injection', 'EMM EI Total Consumption', 'EMM EI Total Injection', 'EMM Gas Consumption', 'EMM Gas Total', 'EMM L1 Consumption', 'EMM L1 Current', 'EMM L1 Injection', 'EMM L1 Voltage', 'EMM L2 Consumption', 'EMM L2 Current', 'EMM L2 Injection', 'EMM L2 Voltage', 'EMM L3 Consumption', 'EMM L3 Current', 'EMM L3 Injection', 'EMM L3 Voltage', 'EMM Tariff Night (T2)', 'Garden light', 'Gas counter', 'HVAC Bathroom', 'HVAC_001', 'Kitchen', 'Living central', 'Living leds', 'Living spots', 'Office', 'Power consumption', 'Pump heating 2', 'SEQUENCE_001', 'Solar panels', 'Summer', 'TH Bathroom', 'TH Living', and 'TH MBR'. Each row has checkboxes for 'Events' and 'Cloud'.

In the left column at “Kind of I/O” all I/O's are displayed per kind, more specifically switched (bistable and timer functions), dimmers, shutters, thermostats, ventilation and other I/O's.

The second tab is the tab “Location”. Locations and rooms can be added here by means of the   buttons at the top of the list. By clicking on an I/O or location, they can also be dragged to another location.

In this way it is possible to assign all I/O's of an installation to their respective location, and to organize these spaces via a tree structure. It is perfectly possible to build an installation from this global edit screen.

By clicking on a group of I/O's of the same type, the main screen will display all these I/O's and their common properties.




If you now want to change the switch-on delay of a few I/O's, you can do this one by one or you can select and adjust the relevant I/O's as explained and illustrated below:

Step 1: Select the I/O's to be changed (bathroom, kitchen, office)

Step 2: Click on the "Overall edit" button, this button will now turn red.

Step 3: Now change the relevant parameters at the top of the gray title bar.

Note: if several I/O's are changed at the same time, this change will be carried out immediately. It is not possible to go back to the previous setting.



If you want to change all I/O's displayed in the main screen at the same time, the check box under "I/O's: On/Off" in the gray title bar must be checked.

By clicking on the "Read values" button located in the top right corner, the status of all I/O's in the main screen can be read. In the column "Counter" the number of hours that each I/O has been active, is shown.

Note: all I/O's must be reset before using the counter. A complete reset of all I/O's in the main screen can be done by clicking the Reset button in the gray title bar. More about counters can be found in the manual "Measuring (energy) via Qbus" on the Qbus website.

Outputs: On/Off											
Read Values											
<input checked="" type="checkbox"/>	Name	Short Name	Mode	On	Off	m/s	Warning	Events	Cloud	Simul.	Counter
<input checked="" type="checkbox"/>	#Daytime	#Daytime	Toggle	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	8085h54'15" a
<input checked="" type="checkbox"/>	#detector front door	#detector fr	Toggle	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1879h48'28" a
<input checked="" type="checkbox"/>	#detector garden	#detector ga	Toggle	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	OFF 0h00'00" as fric
<input checked="" type="checkbox"/>	3 way valve	3 way valve	Toggle	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	OFF 1486h47'09" a
<input checked="" type="checkbox"/>	Bathroom	Bathroom	Toggle	3	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	OFF 1550h27'05" a
<input checked="" type="checkbox"/>	Bathroom ventilator	Bathroom ven	Toggle	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	ON 2074h41'55" a
<input checked="" type="checkbox"/>	EMM Tariff Night (T2)	EMM Tariff N	Toggle	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	ON 1165h59'53"
<input checked="" type="checkbox"/>	Garden light	Garden light	Toggle	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	ON 529h51'14" as
<input checked="" type="checkbox"/>	Kitchen	Kitchen	Toggle	3	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	ON 1213h04'48"
<input checked="" type="checkbox"/>	Living spots	Living spots	Toggle	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	ON 385h20'34" as
<input checked="" type="checkbox"/>	Office	Office	Toggle	3	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	ON 1055h26'33" a
<input checked="" type="checkbox"/>	Pump heating 2	Pump heating	Toggle	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	ON 23h28'17"
<input checked="" type="checkbox"/>	Summer	Summer	Toggle	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	OFF 0h01'01"
<input checked="" type="checkbox"/>	TOGGLE_001	TOGGLE_001	Toggle	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	OFF 108h46'50" as

Below you will find an overview of the options that can be adjusted for each type of I/O

Bistable I/O

Naam	Korte naam	Mode	Vertraging aan	Vertraging uit	Tijdseenheid van vertraging	Waarschuwing op display	Events aan/uit	Opname in simulatielijst	Status van de uitgang	Bedrijfsurenteller
<input type="checkbox"/> Badkamer	Badkamer	Bistabiel	1	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Berging	Berging	Bistabiel	3	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Garage	Garage	Bistabiel	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Inkom	Inkom	Bistabiel	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Keuken	Keuken	Bistabiel	3	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Living	Living	Bistabiel	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Oprit	Oprit	Bistabiel	0	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Toilet	Toilet	Bistabiel	3	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		

Timer 1/2/3

Naam	Korte naam	Mode	Herlaadwaarde van de timer	Tijdseenheid van de timer	Waarschuwing op display	Events aan/uit	Opname in simulatielijst	Status van de uitgang	Bedrijfsurenteller
<input type="checkbox"/> Deurbel	Deurbel	Timer2	3	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Timer 1	Timer 1	Timer1	60	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Timer 2	Timer 2	Timer2	60	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Timer 3	Timer 3	Timer3	60	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		

Timer 4/5

Naam	Korte naam	Mode	Naam2	Korte naam2	On	m/s	Off	m/s	Warning	Events	Simul.	Status	Counter
<input type="checkbox"/> Timer 4.1	Timer 4.1	Timer4	Timer 4.2	Timer 4.2	60	Sec	60	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Timer 5 det	Timer 5 det	Timer5	Timer 5 man	Timer 5 man	0	Sec	60	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		

dimmer

Uitgangen: Gedimd

Naam

Korte naam

Mode

Minimum dimmer niveau

Startwaarde bij kort puls

Automatisch uitfaden korte puls

Tijdsseenheid uitfaden

Waarschuwing op display

Events aan/uit

Opname in simulatielijst

Status van de uitgang

Bedrijfsurenteller

Naam	Korte naam	Mode	Min.	Start	TimeOff	m/s	Warning	Events	Simul.	Status	Counter
<input type="checkbox"/> Living Spots	Living Spots	Dimmer1T	0%	100%	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> nachthal	nachthal	Dimmer1T	0%	100%	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Slpkmr 1	Slpkmr 1	Dimmer1T	0%	100%	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Slpkmr 2	Slpkmr 2	Dimmer1T	0%	100%	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Slpkmr 3	Slpkmr 3	Dimmer1T	0%	100%	0	Sec	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		

Blinds

Uitgangen: Rolliiken

Naam

Korte naam

Mode

Wachttijd manuele bediening

Wachttijd sfeer bij Up

Wachttijd sfeer bij Down

Tijdsseenheid vertraging

Looptijd rolluik

Tijdsseenheid looptijd

Events aan/uit

Opname in simulatielijst

Status van de uitgang

Bedrijfsurenteller

Naam	Korte naam	Mode	On	Off	Off	m/s	Off	m/s	Events	Simul.	Status	Counter
<input type="checkbox"/> Badkamer Rol 1	Badkamer Rol	Rolluik2T	1	2	2	Sec	30	Sec	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Keuken Rol 1	Keuken Rol 1	Rolluik2T(+Pos)	1	2	2	Sec			<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> keuken Rol 2	keuken Rol 2	Rolluik2T(+Pos)	1	2	2	Sec			<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Living Rol 1	Living Rol 1	Rolluik2T(+Pos)	1	2	2	Sec			<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Living Rol 2	Living Rol 2	Rolluik2T(+Pos)	1	2	2	Sec			<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Slpkmr 1 Rol	Slpkmr 1 Rol	Rolluik2T(+Pos)	1	2	2	Sec			<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Slpkmr 2 Rol	Slpkmr 2 Rol	Rolluik2T(+Pos)	1	2	2	Sec			<input checked="" type="checkbox"/>	<input type="checkbox"/>		
<input type="checkbox"/> Slpkmr 3 Rol	Slpkmr 3 Rol	Rolluik2T(+Pos)	1	2	2	Sec			<input checked="" type="checkbox"/>	<input type="checkbox"/>		

Thermostat

Uitgangen: Thermostaten

Naam

Korte naam

Mode

Regime temperatuur

Regime temperatuur

Regime temperatuur

Regime temperatuur

Regime temperatuur

Events aan/uit

Minimum temperatuur

Maximum temperatuur

Status van de uitgang

Bedrijfsurenteller

Naam	Korte naam	Mode	MANUE	VORST	ECONO	COMFO	NACHT	Events	Min.	Max.	Status	Counter
<input type="checkbox"/> TH Badkamer	TH Badkamer	Thermostaat	20°C	5°C	20°C	22°C	15°C	<input checked="" type="checkbox"/>	1°C	63.5°C		
<input type="checkbox"/> TH Keuken	TH Keuken	Thermostaat	20°C	5°C	20°C	22°C	15°C	<input checked="" type="checkbox"/>	1°C	63.5°C		
<input type="checkbox"/> TH Living	TH Living	Thermostaat	20°C	5°C	20°C	22°C	15°C	<input checked="" type="checkbox"/>	1°C	63.5°C		
<input type="checkbox"/> TH Slpkmr 1	TH Slpkmr 1	Thermostaat	20°C	5°C	20°C	22°C	15°C	<input checked="" type="checkbox"/>	1°C	63.5°C		
<input type="checkbox"/> TH Slpkmr 2	TH Slpkmr 2	Thermostaat	20°C	5°C	20°C	22°C	15°C	<input checked="" type="checkbox"/>	1°C	63.5°C		
<input type="checkbox"/> TH Slpkmr 3	TH Slpkmr 3	Thermostaat	20°C	5°C	20°C	22°C	15°C	<input checked="" type="checkbox"/>	1°C	63.5°C		

Ventilation

Uitgangen: Ventilatie
Naam
Korte naam
Mode
Events aan/uit
Status van de uitgang
Bedrijfsurenteller


	Naam	Korte naam	Mode	Events	Status	Counter
<input type="checkbox"/>	Badkamer HVAC	Badkamer HVA	HVAC	<input checked="" type="checkbox"/>		
<input type="checkbox"/>	Berging HVAC	Berging HVAC	HVAC	<input checked="" type="checkbox"/>		
<input type="checkbox"/>	Kookplaat	Kookplaat	Renson	<input type="checkbox"/>		
<input type="checkbox"/>	Slaapkmr 1	Slaapkmr 1	Renson	<input type="checkbox"/>		
<input type="checkbox"/>	Slaapkmr 2	Slaapkmr 2	Renson	<input type="checkbox"/>		
<input type="checkbox"/>	Slaapkmr 3	Slaapkmr 3	Renson	<input type="checkbox"/>		
<input type="checkbox"/>	Toilet ventilatie	Toilet venti	Renson	<input type="checkbox"/>		

Special


Uitgangen: Speciaal
Naam
Korte naam
Mode
Events aan/uit
Status van de uitgang
Bedrijfsurenteller

	Naam	Korte naam	Mode	Events	Status	Counter
<input type="checkbox"/>	E-meter	E-meter	Energimeter	<input checked="" type="checkbox"/>		
<input type="checkbox"/>	Gasmeter	Gasmeter	Energimeter	<input checked="" type="checkbox"/>		
<input type="checkbox"/>	Watermeter	Watermeter	Energimeter	<input checked="" type="checkbox"/>		
<input type="checkbox"/>	Zonne-energie	Zonne-energi	Energimeter	<input checked="" type="checkbox"/>		

This menu option also makes it possible to quickly change the names of I/Os (in group). This can be interesting if your configuration contains many similar spaces that you add one by one to your existing configuration via import qdb



The “Find and replace” button opens the following screen:



At the top you can set whether the replacement should be applied to ALL I/Os, to the current group (here the Switched outputs) or to the selected I/Os.

The search term that should be replaced by another text can be entered here.

When “Start” is selected, it will only perform the replacement if the name of the I/O starts with the search term.

When “Part” is selected, it will replace ALL search terms found in the name of the I/O with the text to be replaced.

If “Case sensitive” is checked, the search term must appear exactly as it was typed. If not checked, lowercase and uppercase letters are considered equal.

The “Find and Replace” button immediately shows the number of I/Os to which the replacement can be applied.

When you click it, the action will be performed immediately.


3.14 Importing a QDB

Via the main menu File / Import QDB it is possible to MERGE an existing QDB with the current database.

ATTENTION: It is recommended to save your current QDB first, so that in case of a wrong or unwanted import, you can return to the saved QDB

ATTENTION: Do not use this menu item to use a QDB of the Serial Manager II! You can simply open a configuration file of the older generation controllers via File/Open. This converts the old structure to the new one.

After selecting the file, the following selection appears:



An overview is shown of how many different items of each category are present in the selected QDB and are ready to be imported.

You can uncheck the unwanted items.

When you click on "Start import" and confirm the command, all items in the current configuration will be added. The same names will be changed to a unique new numbered name, serial numbers will also be uniquely generated.


On our website you can find many examples of QDB's of specific small configurations.

These are divided into the groups BASIS, STANDARD and ADVANCED.

You can even import these QDB's multiple times if a situation occurs multiple times.

The files are stored in zipped format on <https://www.qbus.be/en/support/support-service/qdb-files-configuration-files-examples>

After importing you can then scroll through the overview of all imported data. The newly generated names, scenes, clock times, modules, addresses and sub-addresses can then be seen:



4. Configuration of the Qbus modules




The configuration principles are the same for all Qbus modules. The difference is in the operation, which does not necessarily affect the logic of the program.

The system manager takes care of configuring the modules, rather than programming. The Qbus system was developed to make programming transparent for the user of the system; the user only needs to configure the system - select which input will activate which I/O - and adjust the settings as necessary to suit his or her specific needs.

Remark: it is recommended that you create all I/O's BEFORE configuring the modules, as this will make configuration faster and easier. See [chapter 3.5](#) to create the I/O's.

To configure modules, go to the Qbus System Manager and click on the modules option on the taskbar. The following screen is displayed. In the field beside "S/N:" you must enter the serial number of the specific module you are configuring.

Remark: Each Qbus module has a unique serial number which you will find on a sticker on the module itself. A CTD also has a serial number, but should not be entered in this list. The controller is automatically read by the System Manager when a connection is established between the System Manager and the Controller.



Once you type the serial number of the component in the "s/n:" field, another screen will appear on the right side of the programming screen showing this specific component.

4.1 Configuring Input Modules

In the upper part of the module programming screen, the location of the module can be entered (e.g. distribution board 2, row 1).

In each of the input fields, I/O's can be selected by clicking the drop-down field next to the "Name" field. If I/O's were created before, they will be listed in this drop-down list.


Selecting an existing I/O will automatically fill in the "mode" field (as the mode was selected when the I/O was created – see [chapter 3.5](#). If the "- New I/O -" is selected in the drop-down list of the module, a mode must be assigned; then an indicative name is immediately displayed for the concerned I/O, which you can change at that time. The "Properties" button next to each I/O allows you to check or assign the properties of the affected I/O.

See [chapter 3.5](#) to create an I/O.

4.1.1 INP02/04

This module can be used to connect an ordinary switch (without integrated Qbus PCB) or external contacts such as a solar/wind detector, a motion detector, door switches, magnetic contacts for doors and windows, etc.

4 input switches can be connected, which must be potential-free. Each module has a unique serial number for programming. After entering the serial number, the following window will appear:



The input contacts can be selected and set with the system manager as shown below.

- Push button = when you connect a push button to the input
- Normally open = contact open when not energized (for long contacts - see below)
- Normally closed = contact closed when not energized (for long contacts - see below)
- Switch = when you connect a switch to the input (2 positions – on & off).

ATTENTION: Always use Normal Open or Normal Closed when connecting inputs that give long contacts (e.g. magnetic contact for window, motion detector, smoke detector, ...). These inputs maintain the same state for a longer period of time and only activate the I/O when that state changes. If you use "push button" for those inputs, the bus will continuously send the status to the controller, resulting in poor communication. Only use push buttons for short contacts (= ordinary push buttons).

One module can control up to 4 I/O's, 4 scenes or 4x16 scenes via the sequencer function. The I/O's can also be activated from the system manager using the Test key in the programming window. The instantaneous status of the I/O's can be consulted by pressing the "Read values" key in the programming window of the INP04 module.

4.1.2 INP08/INP16

As far as programming is concerned, there is not much difference between INP04, INP08 and INP16; the only difference is the number of potential free switches that can be physically connected to the INPUT modules. INP04 provides capacity for 4 potential free switches, INP08 for 8 and INP16 for 16.

The other difference, in terms of programming, is that INP16 has 2 serial numbers. The first serial number refers to inputs 1 to 8. The second serial number refers to inputs 9 to 16.

The input contacts can be selected and set with the system manager as shown below.

- Push button = when you connect a push button to the input
- Normally open = contact open when not energized (for long contacts - see below)
- Normally closed = contact closed when not energized (for long contacts - see below)
- Switch = when you connect a switch to the input (2 positions – on & off).

ATTENTION: Always use Normally Open or Normally Closed when connecting inputs that give long contacts (e.g. magnetic contact for window, motion detector, smoke detector, ...). These inputs maintain the same state for a longer period of time and only activate the I/O when that state changes. If you use "push button" for those inputs, the bus will continuously send the status to the controller, resulting in poor communication. Only use push buttons for short contacts (= ordinary push buttons).

The same I/O's that can be activated by INP04 in 4.1.1 are also applicable for INP08 and INP16 modules. The I/O's can also be activated from the system manager by pressing the Test key, and the current status can be consulted by pressing the "Read value" key.

4.1.3 INP08/230

The INP08/230 is comparable to the INP08 module. Again, there is no difference in programming aspects. The only feature that sets this module apart from the other Input Modules is that the INP08/230 can switch up to 230 volts. (the switches do not have to be potential-free).

The same I/O's that can be activated by INP04 in 4.1.1 are also applicable for INP0/230. The I/O's can also be activated from the system manager by pressing the Test key, and the current status can be consulted by pressing the "Read value" key.

4.1.4 INA02 (module type 0013)

The INA02 is a module that can measure a voltage between 0 and 10V or a current between 0 and 20mA in a range of 12 bits via 2 inputs.

The screenshot shows the configuration window for the INA02 module (0013B00013). It features two input channels, Input 1 (A26.1) and Input 2 (A25.7).

Input 1 (A26.1) Configuration:

- Location: INA02_37
- Sensor type: 0 - 10V
- Name: DIMMER_001
- Error address: TOGGLE_002
- Properties: A graph showing a range from 0V to 10V. The 10V mark is at 100% and 0V is at 0%.
- Hysteresis: 1.96%
- Dead time (in sec.): 5

Input 2 (A25.7) Configuration:

- Sensor type: Qbus volume sensor (SENPACK LEVEL)
- Name: Waterlevel
- Error address: TOGGLE_001
- Properties: A graph showing a range from 4mA to 20mA. The 20mA mark is at 3 m and 4mA is at 0 m.
- Hysteresis: 0,05 m
- Dead time (in sec.): 5

An input can be of 3 types: Dimmer (0-100%), Thermostat I/O (with a range of 63.5°C) or a universal I/O (number of 24-bit with adjustable resolution)

The latter can therefore display large values as well as decimals. However, the measurement of the module is limited to 12-bit and will therefore be able to display the complete measurement in +/- maximum 4000 steps.

After selecting (or adding) the universal I/O, it is important to set the parameters correctly. Choose the correct type to get a correct display. The default parameters will then be suggested. You can then adjust this to your own liking.

Then choose the mode of the sensor:

The screenshot shows the 'Sensor type' dropdown menu. The selected option is 'Qbus volume sensor (SENPACK LEVEL)'. Other visible options include '0 - 5V', '0 - 10V', '0 - 20mA', and '4 - 20mA'.

Then click on "Default" to set the default conversion.

You can configure the settings of the first four types as follows:

Especially with a universal I/O, it may be necessary to adjust these default values. Enter the correct value at minimum (at 0V, 0mA or 4mA) and also the desired value that the sensor should give at maximum (at 5V, 10V or 20mA)

e.g. You want to visualize a temperature between 40°C and 100°C and according to the technical documentation the sensor gives 0°C at 4mA and 100°C at 15mA. Then you will need to use the following settings:

Input 1 (A25.8)

Sensor type
4 - 20mA

Name
Temperature Sauna

Properties...

Error address
TOGGLE_002

Properties...

20mA 133.3 °C

4mA 0 °C

Hysteresis 1 °C

Dead time (in sec.) 5

Default

Q Univ.Mode Temperature Sauna | (A25.8)

Properties

Type Temperature

Minimum 20

Maximum 100

Resolution 0.1

Unit °C

Events


Save events for this output on SD

The value 133.3°C is obtained by the following formula: $100\text{ °C} / 15\text{ mA} * 20\text{ mA}$

The result of the measurement is sent to the selected I/O in the controller when the “hysteresis” is reached and the “dead time” has elapsed. In this example there will only be a status update if the temperature difference compared to a previous measurement is greater than or equal to 1°C and this at the earliest 5 seconds after a previous update.

If a pressure sensor from Qbus (SENPACK/LEVEL) is connected, you can easily measure the contents of a tank.


For example, the I/O settings look like this:




At “Properties” you can set all parameters of your tank. The choice of tank type, maximum volume, height and type of liquid will provide a correct representation of the measured contents of the tank when the sensor is just above the bottom. The pressure sensor (SENPACK/LEVEL) can handle a maximum pressure of 0.3bar (20mA at 3m maximum depth in a tank filled with water)

For other liquids with a specific weight of less than 1000kg/m³, the volume of slightly deeper vessels can therefore be measured.

The liquids offered are water, diesel (fuel oil) and petrol.




If you want to measure another kind of tank/liquid or if the height of the vertical tank is e.g. 4 m and the sensor is 1m from the bottom, you can choose “Other (linear)” and set the value from 0 bar and from 0.3bar



The bistable error address will be turned on if, for example, there is a sensor break. At 0-5V the I/O will be switched on if a voltage is measured of more than 5.25V, at 0-10V more than 10.5V, at 0-20mA or 4-20mA more than 21mA and at 4-20mA also if less than 3.5mA

If you wish to test other threshold values, you can use analog logic or, better yet, set a trigger on the module itself.

E.g.:



Double click on the threshold value changes the test from >= to <= and to 'do not test'.

When a threshold value is set on both inputs, the result will be calculated as an "AND" condition.

4.2 Configure I/O modules

In the upper part of the module programming screen, the location of the module can be entered (e.g. distribution board 2, row 1).

In each of the I/O fields, I/O's can be selected by clicking the drop-down box next to the "Name" field. If I/O's were created before, they will be listed in this drop-down list.

If the "new I/O" field is selected in the drop-down list of the module, a mode must be assigned; then an indicative name is immediately displayed for the concerned I/O, which you can change at that time. The "properties" option next to each I/O allows you to check or assign the properties of the affected I/O.

Refer to section 3 for how to create an I/O.


4.2.1 Configuring Relay Modules (REL02SA/230, REL04(SA), REL08)

The REL04(SA) has 4 normally open contacts, on which max. 16 A and 230 V ($\cos\varphi=1$) can be connected. These are independently working contacts, each of which can be assigned a separate function by means of the system manager.

The REL08 has 8 changeover contacts (Normally open or normally closed contact can be connected as desired)

ATTENTION: The REL02SA/230, on the other hand, has two 230V I/O's

These modules have 1 unique serial number by which the system manager recognizes the modules. When you have entered the serial number in the modules window, the following window will appear. The following figure shows the programming window of a REL04SA.



As explained at the beginning of section 4.2, the I/O's can be created in the "modules" section of the System Manager or in the "I/O's" section. The Mode here refers to the various types of I/O's, bistable, thermostat, timer, etc.

ATTENTION: a REL04(SA) and REL02SA/230 only have make-contacts. For safety reasons, it is NOT recommended to control electric motors (for roller shutters, curtains, etc.); this requires a REL08, ROL01PSA, ROL02(P) or ROL04PSA.

When you set the properties of the module to "SA – xx I/O", you can prepare the module to work stand-alone. The following image shows these possible settings of a REL02SA/230

When you have entered the serial number of the REL08 modules, the following window will appear.

The relay module has no specific function. It can handle all switching functions: monostable (bell), bistable (on/off), timer, interval, thermostat I/O, etc. The I/O's can also be activated from the system manager by means of the Test key, and the current status can be consulted by pressing the "Read value" key.

4.2.2 Roller shutter module with positioning (ROL02P, ROL01PSA and ROL04PSA)


This is a special relay module that is only available for controlling and positioning 230Vac electric motors (shutters/blinds/curtains).

The roller shutter motors that are connected to the roller shutter modules must be 230V AC motors, with a minimum load of 40W and a maximum load of 500W. The roller shutter motors must also have limit switches; this is important when calibrating the roller shutters. These modules do not allow controlling an Up and a Down contact of the same roller shutter at the same time.

Each roller shutter on the ROL02P can be positioned between 0% and 100% of the running time. An internal calibration mechanism will calibrate the roller shutter each time it is fully raised or lowered (each time both limit switches are activated). This ensures that the desired position of the roller shutter remains accurate over time. With a shutter module it is possible to configure the shutters so that they would go to 0% (closed) when e.g. the light level outside falls below a certain value, or to set them to 42% when the temperature in the living room is more than 22°C and the light level outside is more than 1200 lux (meaning the sun is shining inside and the room is warming up), etc.

Remark: If there is no need to position the shutters, a REL08 or a REL04SA can also be used.

When you have entered the serial number in the modules window, the following window will appear.




As mentioned above under 3.5.4, only the Up/Down(+Pos) can be assigned to a roller shutter module.

The I/O's can be activated from the system manager by pressing the Up and Down keys, and the current status can be consulted by pressing the "Read value" key.

With the ROL02P it is possible to set your roller shutters to a desired percentage. In order to achieve this, the roller shutter must be calibrated.

Adjust the roller shutter's end of range contacts so that the upper and lower limits of the roller shutter are clearly defined. Then connect the module to the ROL02P module.



Note: Roller shutter motors may not be placed parallel to each other. This usually results in irreparable damage to the motors!

Via the module you can create a new I/O on the module or you can go via the I/O list to “Wizard New I/O” (mode = “Up/Down(+Pos)”). Our I/O that we are going to create is called “Sun blinds”.

When the I/O(s) have been created and placed on the module, we send this data to the controller. We then return to the shutters screen and click on the “Read value” button. The module will now indicate that it has not yet been calibrated.

You can choose either automatic calibration or the entry of fixed run times (only modules with 10-digit serial number). If automatic calibration has been selected and slats are present, you must first enter the time required to tilt the slats from 0 to 100%. Afterwards, on the first operation of the shutter, the module will move the shutter to the nearest end (0% or 100%) and then measure the time it takes from 0% to 100% and vice versa. The end of range contacts in the roller shutter motor ensure that the current is lost and the module will then reverse the direction. After the calibration is finished, the module can be operated normally.

After calibration, you can then press the "Read values" button where you can read the times. If these times differ by more than 2 seconds, it is recommended to reset the calibration and try the calibration again. If this does not help, you should check the limit switches of the motor.

When the roller shutter is sent to 0% or 100%, the up or down contact will always be activated until the power is lost. As a result, the roller shutter is synchronized with the real position every time.

The screenshot displays the 'Shutter module 0004B009F2' configuration window. It is divided into two main sections for 'Up/Down 1 (A04.1)' and 'Up/Down 2 (A68.3)'. Each section includes a 'Name' dropdown menu, a 'Properties...' button, and a 'Fix Time' button. Below these, there are 'Up Calibrate' and 'Down Calibrate' times displayed in red text. A 'Reset Cal.' button is also present. The 'Slats' section for each module includes a 'Time to rotate' dropdown (set to 1.50s), a '# Steps' dropdown (set to 5), and a 'Restore pos. after interrupt' checkbox (checked). There are also 'Up' and 'Down' buttons for the slats. At the bottom of each section, there is a 'Force Output' checkbox and a 'Default' button. The 'Up/Down 1' section has a '0%' position indicator, and the 'Up/Down 2' section has a '0%' position indicator. A 'Read Values' button is located at the top center of the window.

With new roller shutter modules with a 10-digit serial number starting with 0004,000F and 0010 these times can also be entered as a fixed value. This is necessary if you work with roller shutters or sun blinds with electronically controlled motors on which the current measurement does not work correctly. You can also control the position of the slats on these new modules. For these I/O's it is important that the tilting time is entered as precisely as possible.

A short pulse on a key will tilt the slats 1 step further.

Both the position of the roller shutter/screen and the position of the slats can be controlled via scenes. You can then operate the roller shutter I/O on any Qbus-controlled control panel or switch.

4.2.3 Dimmer modules (DIM02SA/500U, DIM04SA/500U)

The Dimmer Modules are used to control the input power for incandescent or halogen lamps, 230V LED lamps and energy-saving lamps. Each dimmer can be programmed as a 1 or 2 button dimmer. The one-button version allows you to reduce the number of control buttons, but remember that the dimming cycle must always be completed, from zero to maximum and back to zero. In the two-button version, you need a "+" and a "-" button, but you do not need to complete the full dimming cycle. When you hold down a key, the run time from 0 to 100% is 5.1sec. A short pulse (< 0.3 sec.) activates the dimmer in 2.5 sec. to 0 or to 100%. The minimum and maximum value can be set within a range from 0 to 100%, the start value if the "Dimmer-Daytime" is on and off from 5 to 100%. The start value must be 5% higher than the minimum value - that margin is automatically maintained when setting the minimum and start values. The lighting can also be dimmed automatically after a programmed period of 1 sec. up to 255 minutes (TimeOff). This automatic switch-off time only starts counting after activating the dimmer via a short pulse.

If the dimmers are controlled via an scene, the rise and fall time can be set independently between 0.3 sec. and 20 min. This descent time is also used with the automatic shutdown

DIM0xSA/500U (Universal Dimmer)

The DIM02SA/500U module can switch 2 circuits and the DIM04SA/500U module can switch 4 circuits from 10 – 500VA, and are suitable for dimming incandescent and halogen lamps, capacitive and inductive loads, dimmable energy saving lamps and dimmable 230V LED lamps. Mixed loads on the same circuit are not allowed. For more information about the type of lamps and loads that can be connected to this module, see the technical data sheet of the DIM04SA/500U on www.qbus.be.

DIM04SA module 114475

Location: DIM04SA_43

Properties...: Controlled via bus

Read Values

Output 1 (A13.3):

Name: Living leds

Conventional transformers

Electronic transformers

Incandescent and halogen lamps 230V

Retrofit LED 230V (Preferred)

Retrofit LED 230V (Alternative)

CFL with 100% startup (Preferred)

CFL with 100% startup (Alternative)

Output 2:

Name:

Output 3:

Name:

Output 4:

Name:

Input A (All Off/On):

Name:

Input delay: 700ms

3s

Stand Alone

Delay before All OFF is activated

All OFF: n/a

All ON: Default

	All OFF	All ON
Living leds	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Output 2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Output 3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Output 4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Push button

The I/O's can be activated from the system manager using the Up / Down keys, and the current status can be consulted by pressing the "Read values" key.

IMPORTANT: if a circuit dims dimmable energy-saving lamps, the option "CFL with 100% startup" must be selected in this window above. This ensures that the dimmable energy saving lamp is first ignited at 100%, and then dimmed to the requested percentage.

Properties:

When you click on the properties, the following window will be displayed.

Dimmer Living leds | (A13.3)

Icon
Select the icon for Tastu Display

DimMin
Minimum dimming level 10%

DimMax
Maximum level 90%

DimStart
☐ Memory function - Use last status (if greater than 20%)
 Level when pressed shortly or when activated in binary logic (Dimmer-Daytime=On) 90%
 Level when pressed shortly or when activated in binary logic (Dimmer-Daytime=Off) 40%

Fade In - Out
 Speed to fade in when executing via scene 5 sec
 Speed to fade out when executing via scene or TimeOff 5 sec

TimeOff
 Automatic fade out when pressed shortly 0 Sec

Display
 Short Name Living leds

Display Warning
 Warn on display 0 when this output is active? No

Simulation
 Can this output be activated in simulation? Yes

SwitchTime
 Put this output in a Switchtime

Multi-Link
 Logical instructions and links to other inputs and outputs No

Events
 Save events for this output on SD Yes

- Both the minimum, maximum and start value (If Dimmer-Daytime is ON and OFF) are adjustable. ATTENTION: SET A MINIMUM VALUE FOR DIMMABLE ENERGY LAMPS AND LED LAMPS (ADJUSTABLE FOR COLD LAMP). THIS MINIMUM VALUE DEPENDS ON THE TYPE OF LAMP AND THE WATTAGE - ENSURE THAT THE LAMP DOES NOT Flicker AT MINIMUM VALUE. TOO LOW DIMMING WILL REDUCE LAMP LIFE OR MAY CAUSE Flicker.
- Fade In / Fade Out: time it takes to go from 0% to maximum or from 100% to minimum when the dimmer is controlled via a scene or a TimeOff
- TimeOff: After briefly pressing the button, the time in seconds or minutes (click the "Sec" button to switch to minutes and vice versa) displayed under TimeOff, before the dimmer fades out (depending on the duration set for Fade Out).
- For more details on the other properties, see chapter [3.5.10](#).

4.2.4 Constant Light Control (CLC01)

The CLC01 is a decentralized module equipped with a light sensor that measures the light level in the room and which, based on the difference between the desired light level and the measured light level, dims the 0/1-10V ballast of a fluorescent fixture to achieve the desired light level. The CLC01 is connected decentrally to the bus and powered by the bus. The module has 6 wires, two yellow ones for the bus connection (no polarity), a gray (-) and a white (+) wire to connect the light sensor and a blue (-) and red (+) wire for the connection to the 0/1-10V ballast. A magnetic isolation between the bus and the I/O guarantees safe operation.

When you have entered the serial number in the modules window, the following window will appear.

CLC01 module 220002

Location
CLC01_44

Read Values

CLC Dimmer

Address Properties...

Up
Down

DimMin (FW v1.3)
Minimum dimming level 0%

Relais
Hysteresis Delay Off (/min) 10m

Integrator
Integrator Time Up (1-10) 2s
Integrator Time Down (1-10) 8s
Integrator Step (1-10) 1

Light
Range (80-127) 100

Default

A CLC I/O can be created from the module screen as shown above, or from the New I/O Wizard. The CLC01 can be programmed as a 1-button dimmer or as a 2-button dimmer. If the I/O is created via the module screen, it will default to a 1-key CLC. This can be adjusted to a two-button dimmer via the I/O screen.

By clicking on the “properties” button, the following screen will appear:

The required light level can be set via the DimStart %. Since a lux value depends on factors such as size and height of the room, color of the walls and furniture, reflection, etc., no lux values are set here, but percentages. We recommend setting a percentage of e.g. 70%, sending these settings to the controller and visually checking if the light level needs to be adjusted or not. For more light, the % should be higher, for less light, lower.

For more details on the other properties, see section [3.5.10](#).

When switching on the I/O linked to the CLC, the CLC will keep the value entered in the DimStart. The light sensor on the CLC will measure the light level, and the CLC will regulate the connected light circuits to achieve this requested light level. The lighting circuits in the room will therefore only be used as a complement to the available natural light.

When reading the status of the CLC, the requested value will therefore be returned on the one hand (in the example below 70%), and on the other hand the dim value of the CLC (here 47%). In this case, this means that there is sufficient natural light (or other light sources) in the room so that the lighting controlled by the CLC only needs to be on at 47% to reach the required light level of 70%.

The Hysteresis and the delay off are only used if the CLC is used in combination with a relay. The light circuit that is dimmed by a CLC must also be able to be switched on or off. This can be done by putting this circuit on a relay I/O: when someone is present in the room, the relay is switched on

(manually or via a detector), only then does the CLC start to dim the circuit in function of the available light.

To prevent the relay I/O from switching too quickly, the delay off time can be set. Only after this time will the relay be switched off if no more light is requested by the CLC module. The Hysteresis can be used to increase the enable level of the relays. For example, if the light level just fluctuates around the level at which the CLC will or will not request additional lighting, so that the relay is switched on again after each switch-off, increasing the hysteresis can also increase the requested light level. In this way a relay will only switch on again after it has been switched off if the requested light level is equal to the DimStart plus the hysteresis. This Hysteresis has a value between 0 and 19;

The CLC I/O's can of course also be used on the other Qbus control modules (switches, control tables, scenes,...). The automatic CLC function that will adjust the light based on the DimStart value can always be overruled by manual control via e.g. a switch (the CLC-controlled I/O can be controlled via a switch as a standard dimmer I/O). When the CLC01 is manually overruled, the I/O will remain in that position; turning the I/O off will cancel the overrule and the I/O will be controlled again by the CLC01 as soon as the I/O is active again.

4.2.5 Analog dimmer module (ANA04/ANR04SA)

The analog dimmer modules are used to control external dimmers with input voltages 0-10V /1-10V. The only difference between ANA04 and ANR04SA is that the former type contains no relays, while the ANR04SA has relays through which the loads connected to the external dimmer can be completely isolated when the I/O is set to 0%. In the case of the ANA04, the lamp connected to the dimmer may still be lit, depending on the minimum I/O of the dimmer. Bistable I/O's can also be used on the ANR04SA.

Both the ANA04 and the ANR04SA are recognized by the system manager by a unique serial number. The programming is similar. Both can be configured as a 1T dimmer or as a 2T dimmer. The following explanation of programming and operation applies to the two modules.

When you have entered the serial number of an ANA04 in the window of the modules, the following window will appear.

Dimmer module 250002

Location: ANA04_133

Type: ANA04 Analogue dimmer

Read Values

ANA04

Dimmer 1 (A79.3)

Name: Hall Ventilator

Mode: Dimmer1B

Up

Down

Dim Start: 100%

Time Off: 0 Sec

Fade in: 5 sec

Fade out: 5 sec

Properties...

Connections to...

Dimmer 2 (A85.3)

Name: Sales2 spots

Mode: Dimmer1B

Up

Down

Dim Start: 100%

Time Off: 0 Sec

Fade in: 5 sec

Fade out: 5 sec

Properties...

Connections to...

Dimmer 3

Name:

Mode:

Up

Down

Properties...

Connections to...

Dimmer 4

Name:

Mode:

Up

Down

Properties...

Connections to...

Mode: Can be a 1T dimmer or a 2T dimmer. The ANA04 can also control thermostat I/O's

Properties: similar to the properties of the dimmer module, described in section 4.2.3

For an ANR04SA the screen looks like this:

The screenshot shows the configuration interface for the ANR04SA module (0005B00001). The 'Location' is set to 'ANR04SA_132' and 'Properties...' is set to 'Controlled via bus'. The interface features four output sections (Output 1 to Output 4) and an 'Input 5 (All Off/On)' section. Each output section has a 'Name' dropdown, checkboxes for 'PWM' and 'Reversed', and a 'Push button' dropdown. The 'Input 5' section includes a 'Name' dropdown, a 'Push button' dropdown, and a table for configuring the 'All OFF' and 'All ON' states. The 'All OFF' state is currently set to 'n/a' with a delay of '700ms'. The 'All ON' state is set to 'All ON' with a delay of '3s'. The table below shows the configuration for the 'All OFF' and 'All ON' states:

Device	All OFF	All ON
Admin TL	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Admin ventilo	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Output 3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Output 4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

The same as the REL04SA and DIM04SA, this module can also work completely standalone. The settings as shown below are then also applied.

The screenshot shows the configuration interface for the ANR04SA module (0005B00001) in Stand-Alone mode. The 'Location' is set to 'ANR04SA_132' and 'Properties...' is set to 'SA - 4x Output'. The interface features four output sections (Output 1 to Output 4) and an 'Input 5 (All Off/On)' section. Each output section has a 'Name' dropdown, a 'Dimmer1B' dropdown, a 'Minimum dimming level' slider, a 'Level when pressed shortly or when activated in binary logic' slider, an 'Automatic fade out when pressed shortly' dropdown, and checkboxes for 'Memory function - Use last status (if greater than 20%)', 'PWM', and 'Reversed'. The 'Input 5' section includes a 'Name' dropdown, a 'Push button' dropdown, and a table for configuring the 'All OFF' and 'All ON' states. The 'All OFF' state is currently set to 'n/a' with a delay of '700ms'. The 'All ON' state is set to 'All ON' with a delay of '3s'. The table below shows the configuration for the 'All OFF' and 'All ON' states:

Device	All OFF	All ON
Admin TL	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Admin ventilo	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
DIMMER_001	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
DIMMER_002	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

As with the other Qbus Stand-Alone modules, if the module is used in Stand-Alone mode, the fifth input (Input 5 (All Off/On)) will act as an All Off button (press briefly), and as a Panic button at long push.

As soon as the module is no longer used in Stand-Alone mode, i.e. if it is connected to a controller and is supplied with voltage via the bus, the fifth input will work differently. Now a scene must be created via the System Manager and assigned to this input (on the field "Input 5"). This scene is then executed

with a short push. PLEASE NOTE, with a long press the next scene in the list of created scenes in the Qbus System Manager is automatically executed. So make sure to take that into account!

IMPORTANT:

- if several Stand-Alone modules are interconnected on this fifth input, only 1 module may be assigned a scene – for all other connected modules the scene input (Input 5) must remain empty!
- For the scenes used in the 5th entrance of SA modules, NO DELAY TIMES may be set at the scene level itself. The delay times are entered here in the module screen.

The I/O's can be activated from the system manager by pressing the Test or Up/Down key, and the current status can be consulted by pressing the "Read value" key.

See the corresponding sections on controlling the relay modules via various modules.


4.3 Configuring switches (SWC0X/XX and Tastu)

The switch is essentially the user interface of the system. As with a conventional switch, its operation is very simple.

Each switch can perform 4 + 4, so a maximum of 8 operations. These operations are simple toggles (ON/OFF), dimming, scene recall, central commands, and anything the system can handle.

To program a switch, follow this procedure:

When you have entered the serial number of a switch as mentioned above in this document, in 3.3, you will see the following screen appear:




It is important that you set the correct type for the Tastu switches. In the drop-down list you can choose from SWC01/G, SWC02/G, SWC04/G or, if equipped with a temperature sensor, SWC02T/G or SWC04T/G


The screen above is the programming screen of a switch, showing the 4 commands for the switch. These commands are placed so that the top left field (Key 1) corresponds to the top left of the switch when you are in front of the switch, etc.

Remark: You can verify that the position of the switch is correct by making sure that the serial number on the back of the switch is legible (not upside down).


To program the switch, click the drop-down box next to the first key; there you can select I/O's that you have already created, or create a new I/O. see point [3.5](#) in this document for creating I/O's.



In the drop-down box below the I/O selection window, you can select the mode of the new I/O you want to create. If you have selected an existing I/O, the mode will already be indicated in that box. see point [3.5](#) in this document for a description of the various I/O types you can select.




As you can see on the screen below, for each key you can choose the color of the standby LED (off color), as well as the color for the operating state (on color), or even disable all colors completely, with the option above each color. It is recommended to use different colors for different I/O's - e.g. blue for on/off, yellow for dimmers, green for scenes etc. This will make your system easier to use.



The UP/DOWN and TEST keys on each key next to the I/O allow you to verify that the selected I/O is operational and that it is indeed the one we want to illuminate on the key in question for this particular switch.

The properties option takes you to the I/O properties for this key. see point [3.5.10](#) - Properties - for more details about these properties.


As mentioned earlier, these switches have the capacity for 4+4 operations. The other 4 operations can be found on page 2, in the upper part of the window. When you go to this page, an identical screen is displayed with the four keys. The configuration method is exactly the same.



ATTENTION!!:

Switching between the pages is done by pressing 2 keys simultaneously. If you are using BTicino switches: Press the two upper or lower buttons of the switch simultaneously. If you use switches from Niko or the glass switches (Tastu): press the two keys on the left side or the two keys on the right side of the switch. Once this is done, the 4 keys on the 2nd startup page will be activated. The selection of the 2nd page takes 5 seconds, then the switch returns to the first startup page. You may want to use the second page of a switch for I/O's that you do not activate regularly (e.g. shutters).


Additional settings: with this option the following screen appears.

**Standard colors for this SWC0x:**

This option allows you to set the standby and operating colors for all LEDs on pages 1 and 2. If you click on "Use these colors as default", the chosen colors will now be used as default. So all switches set to - Default - will use these new colors. Clicking "Make this default for ALL SWC0x" will set these colors as default AND will also be assigned to all switches under this project.

If you want a different standard colour for each kind of I/O, the option "Colours / Mode" can be checked.

In next screen you can set the default colour/page or a specific colour for I/O's of type On/Off, Dimmer, Shutter, Other or Scene. When data is sent to the switches, default colours will be sent depending on these settings.



Low light

With this option the brightness of the LEDs at the OFF position can be adjusted by moving the bar left/right (position 2-10 is recommended).

With the “Short Flash on Page 2” option, when you use the 2nd page of the switch commands, the LEDs will flash to indicate that you are on page 2.


The option “TH status visible on LEDs” will reduce the brightness of the LED of the thermostat I/O when the requested temperature has been reached.

With the option “color/regime also on TH+/-” the color of the thermostat program (night, comfort, etc.) will also be visible on the thermostat + and - buttons.

Finally, you will be given the opportunity to select the colors of your choice and use them for the LEDs.

Thermostat switch


In addition to the simple switches, there are switches with an integrated temperature sensor, which also serve as a thermostat in addition to the normal functions. The following screen is a programming screen for such a switch.



Note that, under the two fields in the upper part of the screen (for the BTicino or Tastu switches) or between Button 3 and Button 4 (for the Niko switches), an extra field has been added that relates to the thermostat. That way you can add a new thermostat or use one of the thermostats already created. The thermostat settings are the same as those listed for the DIS02 .

4.4 Replacing a module


When you want to replace broken module or want to upgrade to a more recent type, you can do this very easily by changing the serial number. Maybe, for newer modules, it is necessary to enter the correct type. By clicking on the pencil beside the serial number, the following form will be shown:



When changing the serial number from an old 6 digit number to a new (hexadecimal) number which start with b, C, D, E or F, the same type of module will be chosen.

In the example above the Bticino switch will be transferred to a module of type “0028” and no parameters will be lost.

If you want to replace it with another type of module, the new type can be selected:



In the same way it is possible to replace a QDI01 with a QDM01, a ROL01PSA with a ROL02PSA or ROL04PSA, ...

Changing module to a completely different kind is not possible. Eg. Data from a REL04SA can not be transferred to a DIM04SA. In this case you have to add a new module by entering the serial number of the new module and assign the new I/O's.

4.5 DIS02IT (Eol 2017)

4.5.1 Configuring the DIS02 IT

DIS02 is a central control unit with an integrated electronic thermostat. It can control a number of I/O's or scenes. In addition, it has an integrated infrared receiver that can be linked to any remote control. It is initially programmed by entering the serial number of the DIS02, which you will find on the back of the device. The following screen is displayed.

In the first field (location), type the installation location of the controller.

In the second field, select the thermostat that you want to control with the DIS02. This can be a new thermostat that is only controlled by the DIS02, or a thermostat that you have already entered (e.g. for a switch or a touch screen with thermostat function). Refer to the point about the various I/O modes (3.5.6) for programming thermostats.

In the "control table" field you can select a control table that you assign to the DIS02. see point [3.8](#) to create a control table.

After selecting the control table that you want to control via your DIS02, the following screen will be displayed.

When you select the desired control table, the I/O's you selected in this control table are now automatically fed into the DIS02. Note that this list serves to show the link between the I/O's that you can control via the buttons on the DIS02, and the infrared samples that you have created to control

your Qbus installation with your remote control. Therefore it seems that the first 4 fields of the list are empty and you can only see 20 "samples". The first 4 fields (numbers 000-003) are not empty - if you click on these fields you will see that they are assigned to Volume Up, Volume Down, Channel Up and Channel Down (functions you will need when using the remote control). From field 004 you will see the I/O's you selected in the Control Table. In this specific list you only see the first 10 I/O's from the control table (ie up to field 013). However, if the control table contains more than 10 I/O's, the remaining I/O's are also automatically entered in the DIS02 (maximum 99 I/O's) and can therefore be controlled.

The other fields of the DIS02 screen (# Learn samples, IR sample timeout, Mode, ...) are required to use a remote control - see point [3.8](#) to read more about this.

4.5.2 Using the DIS02 IT



The temperature displayed on the thermostat's display in standby mode is the current room temperature, not the temperature you selected.

By pressing the IR key, you can scroll through the I/O's assigned to your DIS02 via the control table (see above). When you have briefly pressed the IR button, you can use both the IR button and the TH button to cycle through the I/O's, from high to low (using the IR button) or from low to high (using the TH -test). By holding down the "down" (IR) or "up" (TH) key, you scroll through the list in steps of 10 I/O's (from I/O 1 to 10 to 10 ...). When you see an I/O that you want to control, you can use the + or - keys to turn this I/O on or off. If you are operating a dimmer, set it to 100% by pressing the + button once or to 0% by pressing the - button once. Press and hold the button if you want to dim to a certain percentage.

On channel 0 you can check the status of the system (using + or -); you will then see the I/O's you have selected to be displayed on a screen when they are activated (see [3.5](#) Select I/O's - where we discuss the properties of the various I/O modes).

If you do not press the IR button again, the screen will return to the default setting (displaying the local temperature) after 5 seconds.

In the standby status of the DIS02, pressing the TH button allows you to select the programs "Manual", "Freeze", "Economy", "Comfort and "Night" You can change the requested temperature for each program in steps of 0.5°C with the +/- button of the DIS02.


4.6 ViZiR Room Controller (Eol 08/2019)

4.6.1 Configuring the ViZiR Room Controller

The ViZiR Room Controller is a control panel for a Qbus installation consisting of an OLED screen with a capacitive cover plate around it. The screen can be operated by touching this cover plate. The ViZiR also has a digital temperature sensor on board so that this module can also serve as a thermostat. The ViZiR Room Controller is clicked into a Niko® frame (included) and is equipped with a bus connector (no polarity). The bus that is connected to the bus connector provides the ViZiR with power and control.

A control table for the ViZiR Room Controller can be compiled in the Qbus System Manager III (minimum version 3.2.22). Up to 10 menus can be used, which can be selected by sliding the finger up or down on the cover frame on the left side of the screen.

When the serial number of the ViZiR is entered in the module field, the following screen is displayed:




Up to 10 different menus can be created in the “Controls” field (in the example above, these are the menus “ambience”, “lights”, “heating” and “TV”), and in turn can be assigned up to 10 different I/O’s to each menu (in the “I/O list” 0 to 9).

The I/O’s are displayed on the right side of the screen. Select Menu 1 and double click the menu key so you can change its name. When you have selected menu 1, move the desired I/O’s to the list of I/O’s in menu 1. Select menu 2, move the desired I/O’s to menu 2, etc.

The “Insert line” and “Delete line” keys allow you to insert a line between two I/O’s if you have forgotten I/O’s or delete what you will not need in the end. “Delete line” does not delete the corresponding I/O from the program itself, but only from the table or menu.

An image can be chosen per menu that will be displayed on the ViZiR when that specific menu is selected. Click the up and down arrows next to the displayed icon at the bottom of the screen to cycle through the different images. You can also set the icon per I/O in the same way.

The “Settings” field displays the following screen:




On the thermostat field you can choose which thermostat the ViZiR should function as (has built-in temperature sensor). If the ViZiR is to be used as a thermostat to control the temperature of the specific room, the checkmark next to “TH ->CTD” must be checked. If this is not checked, the ViZiR will only show the temperature measured by the temperature sensor of the ViZiR on its “home screen”, but this temperature will not be sent to the Controller to be used as room temperature for the regulation of the temperature.

In the Scroll Menu you can choose whether to scroll vertically (slide from top to bottom on the cover frame to the left of the ViZiR screen) or horizontally (slide from left to right on the cover frame below the ViZiR screen) between the menus. WE RECOMMEND CHOOSING THE VERTICAL SCROLL MENU.

The language in which commands from the ViZiR are displayed can also be selected in this screen.

A shortcut can be programmed in the ViZiR via the “CH on wake-up” link. Touching the blanking frame on the left side of the screen with two fingers at the same time will immediately activate the I/O selected in the “CH on wake-up” field. To do this, the checkmark next to Direct Control must be checked.

The Screen Properties field displays the following screen:



The brightness of the screen can be updated via the Brightness buttons. The Low brightness appears after the number of seconds defined in the “Reduce Brightness after” field. After the number of minutes defined in the “Go to sleep after” field, the ViZiR enters an energy-saving sleep mode.

The screen saver can also be selected:


- None = no screen saver (so completely black screen in sleep mode which may be appropriate in a bedroom)
- Black = screen saver shows date, time and temperature.
- Image = a screen saver that displays images (Images 1-8). Images can also be uploaded via the Upload button. The font size can be adjusted via the “Size RTC” buttons.

We recommend using the Default settings.

IMPORTANT: IF THE SCREENS ON THE VIZIR LOOK WRONG, CLICK ON THE “PREPARE FULL TX” BUTTON ; THE DISPLAY WILL BE FULLY REPROGRAMMED WITH THE REQUESTED CHANGES AT THE NEXT UPLOAD TO THE CONTROLLER.

Adjust control sensitivity

In the configuration screen of the ViZiR there is a button “Sensitivity”. Clicking this button displays the following screen:




Press the “Start” button at the bottom right, then touch the eight keys of the ViZiR (on drawing 1 to 8) one by one for a minimum of 2 seconds in the same way as they will be operated. The red orb above the appropriate key will move and then turn green. After all keys have been calibrated in this way, you can confirm them by clicking on “Update sensitivity”.



4.6.2 Using the ViZiR Room Controller

The cover frame of the ViZiR is capacitive; ie by pushing or sliding the finger on the cover frame you can scroll between menus or control I/O's. As indicated in the image above, 8 capacitive keys are incorporated under the cover frame; the ViZiR can only be operated by touching the places where these buttons are located; by touching the ViZiR in the corners (where there are no buttons) the ViZiR cannot be operated.

TOUCH THE COVERING FRAME WITH THE ENTIRE SURFACE OF THE FINGER - NOT JUST WITH THE TIP OF THE FINGER - TO GET OPTIMUM OPERATION.




A maximum of 10 I/O's can be assigned per menu. Within the same menu, you can choose between these I/O's by pressing the left or right area below the screen. We recommend using the menus for functionalities (e.g. lighting, heating, ventilation, scenes,...) and grouping I/O's with this functionality in these menus.



If more than one I/O is assigned to a menu, you can choose between these I/O's by touching the areas below the screen. The vertical area to the left of the screen can be used to scroll between menus if more than 1 has been assigned.

All I/O's that can be switched on or off (lamps, shutters, dimmers, ...) can be controlled by touching areas above the on/off symbol (I / O). I/O's that can be positioned (roller shutters with positioning, dimmers) switched on or off completely by touching these surfaces, and can be positioned by sliding the finger down on the cover frame on the right side of the screen.

For heating and ventilation I/O's, the areas above the screen can be used to choose between regimes. The vertical plane on the right side of the cover frame can be used to determine the regime set point (heating) or the exhaust flow rate (ventilation).



choose
always
menu

the
also be
are
up or

the


4.7 Touch Display (DIS/Gx) Module type 0008

4.7.1 Configuring the Tastu display

The Tastu Display is a control panel for a Qbus installation consisting of an OLED screen with a capacitive glass cover around it. The screen can be operated by touching this cover plate. The Tastu display also has a digital temperature sensor on board so that this module can also serve as a thermostat. The Tastu display is clicked into a Niko® frame (included) and is equipped with a bus connector (no polarity). The bus that is connected to the bus connector provides the Tastu display with power and control.


In the Qbus System Manager III (minimum version 3.16.11) 4 direct controls and a table for the Tastu display can be composed. Up to 16 channels can be used.

When the serial number of the Tastu display is entered in the module field, the following screen is displayed:



In this screen the 4 I/O's or scenes can be set that will work as direct control on the Tastu display. Same configuration parameters as with an intelligent switch (SWC04) can also be set here. See section [4.3](#)

When you select the second tab "Channels", the following screen appears:




The I/O's are displayed on the right side of the screen. Select the desired I/O line and double click the I/O to use it on the selected line

The "Insert line" and "Delete line" keys allow you to insert a line between two I/O's if you have forgotten I/O's or delete what you will not need in the end. "Delete line" does not delete the corresponding I/O from the program itself, but only from the table.

An image can be selected for each I/O that will be displayed on the Tastu display. Click on the up and down arrows next to the displayed icon to cycle through the different images.

The "Settings" tab displays the following screen:



On the thermostat field you can choose which thermostat the Tastu display should be controlled (it has built-in temperature sensor). If the Tastu display is to be used as a thermostat to control the temperature of the specific room, the checkmark next to “TH ->CTD” must be checked. If this is not checked, the Tastu display on its “home screen” will only show the temperature of the selected thermostat I/O, but will not transmit the temperature from its own sensor to the controller to be used as room temperature for the regulation of the thermostat.

The brightness of the screen can be updated via the Brightness settings. The ‘Sleep’ brightness will appear after the number of seconds defined in the “Go to sleep after” field.

IMPORTANT: IF THE SCREENS ON THE TASTU DISPLAY LOOK WRONG, CLICK ON THE “PREPARE FULL TX” BUTTON ; THE DISPLAY WILL BE FULLY REPROGRAMMED WITH THE REQUESTED CHANGES AT THE NEXT UPLOAD TO THE CONTROLLER.


4.7.2 Using the Tastu display

The glass of the Tastu display is capacitive; ie by pushing or sliding the finger on the cover frame, you can scroll between I/O's or control I/O's. The keys are NEXT, BELOW, and ABOVE the screen. You can operate the direct channels by pressing the hole/led at the bottom or top. The status of the LED indicates the status of the I/O.

The slider on the left takes you to the channel list. You can slide up and down. You can turn an I/O ON and OFF by pressing the hole/led at the bottom, or dimmers can be dimmed up and down by pressing the top or bottom half on the right-hand side.

4.8 Configure 5.8" touch screen (TSC5.8)

The TSC5.8 is a monochrome touchscreen that can be connected directly to the bus (it receives all the power from the bus), or via an external power supply (so less power is drawn from the bus).



In the Location field, select what name you will give the TSC5.8 - usually the location where it is installed. As with a DIS02, a control table must be selected. This control table is the menu structure of your touch screen. See point 3.8 for how to create a control table.

On the same screen, you can select the language for the default touch screen text. Since the TSC5.8 is also equipped with a temperature sensor, you can select a thermostat to pair with the touchscreen. see point [3.5.6](#) for configuring thermostats.

In "Display text" you can enter the text you want to display on the bottom of the TSC5.8.

The number of menus used can be adjusted with the up and down arrows.

If the box next to "Enable Setup" is checked, you will be able to perform the following operations on the TSC.

- Enable/Disable the buzzer (buzzer may or may not work when the touch screen is used)
- The colors change from positive to negative
- Set up the touch screen
- Cleaning Mode: During this cleaning mode, the touch screen is inactive for 1 minute. During this period it can be cleaned.

If the box next to "Enable Check Status" is checked, you can check the status of certain I/O's on the TSC. To select the I/O's that can be monitored, go to the properties of the I/O and set the "Display Warning" key to Yes.

Activating "Screen saver to clock" means that after the set number of seconds, displayed on the right, the TSC will not return to the screen saver (lower power consumption by reducing the backlight), but will show the clock and measured temperature.

4.9 Configure motion detector (MDX01 or SEN04MLT)

4.9.1 Specifications

- The MDI01 is an INDOOR detector with an adjustable angle and an internal light sensor.
- The MDO01 or SEN04MLT is an OUTDOOR detector with an adjustable angle, and an internal light and temperature sensor.
- The detection range is 7 m at an angle of 110°
- Ability to recognize the origin of the movement, in particular to determine whether the movement comes from the right or the left in the detection zone.
- The MDI can be programmed taking into account the ambient light - it then only works if the ambient light is below a certain threshold value.

4.9.2 Configuration parameters

The following screen is displayed when the properties of a component are selected.

Detector module SEN04 s/n:963002

Location: SEN04_48 [Read Values]

SEN04MLT TH: [Properties...]

Triggers: First 25, Keep 12 [Scan]

Timers: extension 60 Sec, Lock 0 Sec

Led: ☒ Movement, ☐ Light, 2s 5s

Input 1: Name [], ☒ Movement, ☐ Temperature, ☒ Light, ☒ Input connected, [Properties...]

Input 2: Name [], ☒ Movement, ☐ Temperature, ☒ Light, ☒ Input connected, [Properties...]

Input 3: Name [], ☒ Movement, ☐ Temperature, ☒ Light, ☒ Input connected, [Properties...]

Input 4: Name [], ☒ Movement, ☐ Temperature, ☒ Light, ☒ Input connected, [Properties...]

ATTENTION!!!! : Only bistable type inputs can be controlled


4.9.2.1 Triggers

The parameters of these fields are for setting the trigger sensitivity.

First: The level of motion must be higher than this set value to activate the I/O

Keep: The level of motion must be higher than this set value to maintain the state of the I/O.

Scan: A visualization of the detector is shown. The I/O will be activated when the level is higher than the green line and will time out if it stays below the yellow line:



4.9.2.2 LED field

You can select when the built-in red LED will be activated, based on the motion or light level or both.

4.9.2.3 "Timers" field

Extension: Corresponds to the extension of the period during which the I/O's remain activated. The smallest possible timer value is 2 seconds.

Lock: This sets the period of time the sensor will lock (and will not activate the I/O) after the I/O has become inactive.

4.9.2.4 Fields "Input x"

Movement (right/left): Activation of the sensor due to the movement reaching the detection range from the left or right side. If you choose both, the sensor will scan both the left and right sides. With the SEN04MLT/OUT there is no choice between left and right

Light: If 'Movement' is checked, this additional option "light", will only activate the I/O if the light level is lower than the set value. This is useful to prevent the I/O from being activated during the day. The threshold value can be set with the buttons or slider. When only this option is checked (without 'Movement'), the I/O will only be activated if the measured light value is HIGHER than the set threshold value.

The current light value will be displayed with a yellow or black bar via the "Read values" button. When the threshold value is in the colored bar, the I/O will be activated.


4.10 Configure SMS module – SMS01 (Eol 2017)

First connect the 230 VAC power source and the bus communication cables.

4.10.1 Install SIM card

Install the SIM card on a mobile phone and deactivate the PIN. If you are using a new SIM card, make a call and send an SMS to test the SIM card. Then insert the card into the SMS unit. **DO NOT FORGET TO PLACE THE SMS CARD IN THE SMS MODULE BEFORE PROGRAMMING.**


After installing the SIM card, go to the device properties in the Qbus program and check whether the device has a signal by pressing the option "Read signal strength, network, Error, ...". This option is displayed under the first tab of the device properties. Then you need to enter the table you want to control with the SMS unit in the option "control table" as shown below.



Continue if everything is in order, otherwise you will have to check that no wrong actions were taken in the previous steps.

4.10.2 Install Phone Numbers


Click on the tab "Phone numbers", and install the telephone number that can be used to control the Qbus system. **ONLY** with the installed numbers commands can be given to the system. If a third party knows the reporting number, he or she **CANNOT** give a command because the system does not recognize the number.



ATTENTION: For each phone number entered (mobile phones only), you must enter the country code preceded by the + sign.

4.10.3 Configuring Commands

When you're done entering phone numbers and the associated names that you want to see displayed, go back to the first "SMS Commands" tab and choose from the "Control Table" the I/O's you want to control by SMS. Thus, the selection of I/O's is done through the table, by double clicking, and is automatically entered in the table of SMS commands as shown above.




You can change the names of the commands that should be sent to the system.

In the "Who must also have reply" boxes you can select who – in addition to the sender of the message – should also receive a confirmation message that an instruction has been executed. The sender of the message will always receive a confirmation message if the instruction has been carried out correctly. If you also want to receive messages that an instruction was not executed correctly (e.g. because the instruction does not match what was written in the Status Interpreter) in the Alarm tab, check the box "Send debug report if no match".

ATTENTION: DO NOT USE SPECIAL CHARACTERS OR LETTERS (é, ã, ç,...) IN ANY TEXT CONFIGURED IN THE SMS (NEITHER IN THE NAMES NEXT TO THE TELEPHONE NUMBERS NOR IN THE MESSAGES TO BE SENT.) !!!!!


Finally, go to the "status interpreter" tab and click on "Default", so that the commands appear as shown in the following screen.



The commands shown above are defined as follows. If you want to energize a relay contact (on/off), you only need to enter the name of the contact as it was entered under the "SMS Commands" tab. Then, insert a space and type ON or 1 or YES, as shown in the previous table. Similar procedures are used for dimmers, blinds, etc. Make sure that the same instructions as listed in the Status Interpreter Tab are used when sending an instruction. If you want to request a current status of an I/O, you have to send a message with only the name of the I/O in the text (eg. TH Living) – you will then receive a feedback with the current status (e.g. TH Living Comfort).

In addition, you can be warned if there is a failure on the bus or in the event of a power failure. You can do this by going to the "Alarms" tab and selecting "Check the external power" and "Check the bus", so that the power of the system and the operation of the bus signal are checked respectively, as shown in the next screen. Via the option "Send a debug report if no match", the SMS unit informs you whether the message was not delivered or whether the command was not executed.

Setting the alarm for SMS, where the user also receives a warning in the form of a text message, is done as follows. Go to the SMS module via the "modules" option in the program's taskbar and choose the alarms tab; the following screen is displayed.



In the screen above, enter the SMS text, ie the text that will be sent to your mobile phone. In the right part of the screen, choose the phones for the people who should receive messages from this particular alarm. If you create a second alarm, you will need to re-select the phone numbers of the people who should receive the message, as it may not be necessary for everyone to receive all alarms.

The options above the names allow you to set the repeat time if the alarm is not initially detected. Please note that the SMS module can only send out two alarms at the same time.

DO NOT ACTIVATE I/O'S (DO NOT PRESS ANY KEY/ DO NOT ACTIVATE MOTION DETECTOR/ DO NOT ACTIVATE INFRARED PORT /....) DURING SENDING THE SMS CONFIGURATION TO THE CONTROLLER. UPLOADING WILL TAKE ABOUT ONE MINUTE. CLICK ON "TRY AGAIN" IF YOU GET A TIMEOUT (MODULE NOT FOUND).

4.11 Configuring the Audio Module - SER10 (Eol)

The SER10 is a serial port that fits into a standard built-in socket and is connected to the bus. This SER10 can be connected via the supplied cable to the serial port of one of the following audio systems:

- Apart Zone4
- artsound art2.4
- artsound art 5.4/8.8
- Niko Allegretto
- Nuvo Essentia/Grand Concerto

The SER10 is available in Niko versions (100, 101, 121, 122) and in BTicino versions (Light, Light Tech, Living).

Via a SER 10 you can select up to 4 sources and configure up to 8 zones. Obviously, no more zones and sources can be used than what is offered by the respective audio system.

4.11.1 Select audio system

Open the System Manager III and enter the serial number of the SER10 in the module list. The serial number of a SER10 always starts with 99XXXX.

If desired, enter the location of the SER10 module. Then select the audio device. This can be a Nuvo Essentia or Gran Concerto, an artSound art2.4, 5.4, 8.8, Niko Allegretto or an Apart Zone4.

4.11.2 Assign Sources and Zones

Enter maximum 4 sources in the SER10 module, this can be for example "CD", "Radio", "MP3".

The next step is to create the audio I/O's, depending on the type of the audio module. We do this, for example, via the "Wizard new I/O" in the I/O list of the System Manager III. In the Wizard we select the Audio I/O. Then click on next, now enter the name of the audio zone. This can be the name of the room. Then press the finish button. Repeat this process as many times as the number of sources your audio device can handle.

ATTENTION: the order in which the audio zones are connected to the audio device will be the same as the order in which the audio zones should be created in the system manager. E.g. if on your audio device the first zone is Living and the second is Kitchen, the System Manager must also first create the Living zone and then the Kitchen zone.

4.11.3 Assigning I/O's





a) on a SWC

Select the SWC where you want to control the audio I/O's. For a user-friendly operation for both the installer and the customer, it is recommended to use the layout below.





"Zone" (Vol +)	"Zone" (Source)
"Zone" (Vol -)	"Zone" (IR)

The visualization of the source selection on the SWC switch is done via LED coding visible on the two right buttons ("Source" and "IR") of the SWC.





Source 1:

"Zone" (Vol +) 	"Zone" (Source) 
"Zone" (Vol -) 	"Zone" (IR) 





Source 2

"Zone" (Vol +) 	"Zone" (Source) 
"Zone" (Vol -) 	"Zone" (IR) 

Source 3


"Zone" (Vol +) 	"Zone" (Source) 
"Zone" (Vol -) 	"Zone" (IR) 

Source 4

"Zone" (Vol +) 	"Zone" (Source) 
"Zone" (Vol -) 	"Zone" (IR) 


b) on a TSC5.8

Create a new control table, give the desired name to the table.
Then name one of the submenus audio, then add the audio I/O's in the control table.



4.10.4. Audio I/O's in scenes

Like all I/O's that can be created in the System Manager III, the audio I/O's can also be assigned in an scene. In this scene you can then choose to switch the zone on or off (IR I/O), change the source (Source I/O) and adjust the volume (Volume I/O).



4.12 Configure the SER485/DMX module (module type 0002)

With the Qbus-DMX interface (SER485/DMX), it is possible to control DMX lighting fixtures via the Qbus control points (switches, screens, Qbus Cloud) (fixed colours, color transitions, switching via clock times or scenes, ...)

Global settings

Location: SER485/DMX_46

0002

Memory Outputs: 0% Seq. 0%

RS485/DMX BBB002

RGB+

Fix	Seq.1	Seq.2	Seq.3	Seq.4
Dimbaar				
0 - None -	RGBW			
1 Red	RGBW	255	0	0
2 Colour 2	RGBW	255	85	0
3 Orange	RGBW	255	170	0
4 Colour 4	RGBW	255	255	0
5 Colour 5	RGBW	170	255	0
6 Colour 6	RGBW	85	255	0
7 Green	RGBW	0	255	0
8 Colour 8	RGBW	0	255	85
9 Colour 9	RGBW	0	255	170
10 Cyan	RGBW	0	255	255
11 Colour 11	RGBW	0	170	255
12 Colour 12	RGBW	0	85	255
13 Blue	RGBW	0	0	255
14 Colour 14	RGBW	85	0	255
15 Colour 15	RGBW	170	0	255
16 Purple	RGBW	255	0	255
17 Colour 17	RGBW	255	0	170
18 Colour 18	RGBW	255	0	85
19 White	RGBW	0	0	0

Default

Possibility to set 20 'fixed' colors with default values as shown above.

Data1 to Data4 are the settings for RGBW


If the DMX fixture requires RGB values, Data1 to Data3 contains the R, G and B values.

Data4 to Data8 can then be used for other data for the fixture.


When WWCW is chosen, Data1 contains the red 'warm' value and Data2 contains the blue 'cold' value

The 'dimnable' box determines whether this value is dimmed linearly according to the set dimming value of the RGB(W) I/O. If not, the value will simply remain fixed as set.

By clicking on the checked box you can also set the desired color. See next figure:




Setting a WWCW color via 'bar':




With the + and – button you can add and remove fixtures. In the right window you determine the start DMX address and the number of channels. The channel name can also be edited. The memory of the module is limited to a maximum of 48 links. For the use of an RGB+ I/O, 2 links are used internally. The free space can be seen at the top of the pie chart.

An I/O can be a QBUS I/O:




Or a fixed value (e.g. to have the lamp of the fixture give the maximum power)




There is also a possibility to make 'Sequences'. The desired color can be set, the transition time to reach this color and also the time that this color must be maintained. Both times are adjustable from 20msec to 20min.

A maximum of 4 sequences are possible with a combined maximum of 80 color transitions. The free space in the memory can also be seen at the top in the right pie chart.



Via the diskette button you can save a sequence on the computer and via the 'open folder' icon you can add the saved sequences to the same or another sequence. By default, some examples are already supplied with the System Manager III, which you can use via the 'open folder' button. The new DMX module with new DualCore Chip (Module type 0002 – from SM 3.13) has the same function as the previous module but with an extra simple test button. Existing colors can be loaded ("Load 'color'"), with the sliders the RGB(W) values can be adjusted live and also saved to the same or a different color. The set fixed value can also be saved by clicking on "Save 'color'".





DMX controlled dimmers


In this example we are going to use a DUP-600. This is a dimmer pack with 6 channels that can be controlled via DMX. From now on we will work with 2 DMX devices.

- ☐ Device 1: DMX RGB
- ☐ Device 2: DMX Dim pack DUP600

Our RGB DMX is a lamp that continuously needs a high signal on the 4th channel to work. We can set this by selecting the I/O “** Value **” in the list of I/O’s. This is an I/O that is automatically created when creating a DMX I/O. We choose the value 255 on channel 4.



By clicking on the  sign we can add an additional DMX lamp to our driver. The DUP-600 has 6 dim channels, so we also create 6 channels in our software. The RGB lamp uses address 1-4, so we set the DUP-600 to work from channel 5 to 10. On the I/O's we don't put DMX mode this time, but for channels 1-5 we choose a 1Button dimmer and for channel 6 a bistable I/O.



Setting the DUP-600

By pressing the “menu” button 3 times you get to the above menu. There you can set the start channel with the Up/Down button, in our example channel 5. By confirming with “Escape” you set the dimmer that Channel 1 has DMX address 5, Channel 2 DMX address 6, etc.

By assigning different addresses you can therefore control several light points with 1 DMX module.

You can see from the red color of the DMX-LED that a DMX signal is coming in.

With the sliders you can manually control each I/O. If you do this, the DMX signal will be overruled and you will no longer be able to control this channel. To make the I/O listen to DMX you have to press the CH1 button, then the I/O takes over the set value.




4.13 The QDI01 (Dali 1): Configure module type 0006 (Eol 2021)

This module has been replaced by the QDM01 since 2021. See [4.19](#)


These modules can configure the electronic ballasts themselves.
Via the tab “Setup” one can assign addresses and change settings in the ECGs.

The button “Clear all addresses”, after confirmation, will delete all addresses in all connected ECGs! The “Assign Addresses” button first scans for the addresses that are already in use and then assigns the free addresses (from smallest to largest, 0 to 63) to new ECGs that do not yet have an address. After this command, the addresses in use are shown in **green**. Addresses set as “input” will be highlighted in **blue** and addresses to which more than 1 ECG is responding (garbled data is being received) will be displayed in **orange**. An address displayed in **red** shows a 'failure'. The same data is read when you click on the 'down arrow'. Groups that are in use somewhere are also shown in **green**. When clicking on an address, this address will flash. The commands 'go to minimum' and 'go to maximum' are then repeated every second.



The number of the address or group to which a qbus I/O is linked is underlined. Addresses that are added to a group are shown in italics.


A label can also be assigned to an address or group:



Such an address or group number is then marked in bold.

From FW V9.0 you can also read and adjust the parameters of a dimmer and detector via the System Manager.

When clicking the arrow down, all parameters will be read and, for example, the following information will be displayed for an I/O of the Dali Type 6 (Control Gear for LEDs):




You can turn off the flashing by unchecking the first box.

The status shows more info about the ECU. When you move the cursor over this field, you will see the declaration of this status byte.


All messages that this status byte can show are:

- Control Gear Failure
- Lamp Failure
- Lamp On
- Limit Error
- Fade Running
- Reset State
- Short Address
- Power Cycle Seen



Some notifications (such as “Power Cycle Seen”) are only shown once!

The up arrow sends the parameters to the selected dali module.




When “Broadcast” is checked and up arrow is clicked, all parameters will be sent to ALL connected modules!

The groups to which an address belongs are framed with a blue square.

When you click on a group, this group will also blink (controlled with minimum and maximum). All set addresses (also framed with a blue square) then flash along.


After this 'scan' you can link the correct Qbus I/O address per address.

It is also possible to put the addresses in the desired order. This can be done by exchanging the addresses 2 by 2.



Select the first address and then the second address. After confirmation, the 2 addresses in the ECGs are swapped. In this way the ECGs can be arranged in a logical order.

In a next step you can add addresses to a group or add groups to an address.




When assigning addresses to a group, it is possible to click on the first address and to indicate the last address together with the shift key. All addresses from the first to the last are added to or removed from the group according to the status of the first clicked address. Assigning addresses to a group or groups to 1 address can also be done offline. These settings take effect immediately in the ECGs. Later, when sending this module, these parameters will also be stored permanently in the QDI01 module.

At the top, you can also set a bistable I/O. It will scan every set time if a failure occurred somewhere. This I/O will turn on when a failure occurs somewhere. After clicking the download arrow, the defective address or addresses will be displayed in red. After repairing the lamp/ballast and operating that address again, the bistable I/O will be turned off again.

A last button is "Delete address x". After confirmation, this address is removed from the connected ECG.

4.14 SER485/Modbus interface: Module type 0003



The SER485/Modbus module can link up to 127 Modbus registers at different slave addresses to a qbus I/O. Known types are preconfigured in the file "ModbusTypes.Json". This file can be customized to your preference. When one of these types is selected, the registers, function codes and conversions are fixed. Only the correct Qbus I/O has to be selected. If you choose the – Custom – all settings are completely free.

The name of the slave address can be changed at the top of the Tab, as well as copying the settings from another slave address is possible.

4.15 SER485/APIEN: Weather station module type 0001

SER485/APIEN 0001B00445

SER485/APIEN

Read Values

Location

SER485/APIEN_52

Outputs

Light

SER485/APIEN_52 Light

Light (East)

SER485/APIEN Light (East)

Light (South)

SER485/APIEN Light (South)

Light (West)

SER485/APIEN Light (West)

Daylight

SER485/APIEN_52 Daylight

Temperature

SER485/APIEN_ Temperature

Wind

SER485/APIEN_52 Wind

Twilight

SER485/APIEN_52 Twilight

Rain

SER485/APIEN_52 Rain

Output

	Name	Status	Temperature	Daylight	Light (East)	Light (South)	Light (West)	Twilight	Wind	Rain
1	WS TH < 21°		<= 21°C							
2	# Too much sun				>= 20klx					
3	#Too much wind and rain								>= 40km/h	<input checked="" type="checkbox"/>
4										
5										
6										
7										
8										

The weather station can display temperature, light values, wind and rain detection.

The twilight value and rain are I/O's of the Bistable type. All others are 'universal' I/O's. When creating the I/O's, these parameters are set correctly.

The daylight value ranges from 0 to 999lx. The light values per wind direction range from 0 to 99klx (= 99000lx).

In the bottom table it is possible to set different 'triggers'.

For example, in the figure above, the I/O '#Too much wind and rain' will be on if it rains AND there is more wind than 40 km/h.

A double click on a cell changes the test from 'greater than or equal to' to 'less than or equal to' and vice versa.

Testing for 'No rain' is represented by an empty (unchecked) square. A completely empty box means this field is not checked.


The current values from the weather station are displayed via 'Read values'. The triggers are also immediately recalculated with the exact values. However, minor changes are not immediately sent to the controller (or to the Cloud).

4.16 SEN01X modules

4.16.1 SEN01T: serial numbers 700300 to 704999

This temperature sensor can trigger up to 4 separate bistable I/O's. Each test can be greater or less than a selected temperature. Minimum -27°C, Maximum 100°C with a resolution of 1°C

Temperature module SEN01T s/n:700300

Location: Read Values  SEN01T

TH Sensor

Properties...

Scan Speed:

Input 1 (A52.4)

Name: Properties...

☒ Input connected

Input 2 (A54.1)

Name: Properties...

☒ Input connected

Input 3

Name: Properties...

☒ Input connected

Input 4

Name: Properties...


☒ Input connected

4.16.2 SEN01NTC: serial numbers 705000-708999

This module can switch up to 4 I/O's in the same way.

But this module has a black NTC sensor as standard. If different, the parameters of this sensor can be entered at the top via the specified "B-value" or if available via the more accurate Steinhart-Hart method.

Temperature module SEN01NTC s/n:705055

Location: Read Values  SEN01NTC

TH Sensor: Properties...

Scan Speed:

NTC parameters:

- ☐ NTC Qbus White
- ☒ NTC Qbus Black (103AT)
- ☐ User NTC via Steinhart-Hart
- ☐ User NTC via B value

Beta:

Ohm @

9999 ohm @ 25°C

Ohm @

Input 1 (A52.4)

Name: Properties...

☒ Input connected

Input 2 (A54.1)

Name: Properties...

☒ Input connected

Input 3

Name: Properties...

☒ Input connected

Input 4

Name: Properties...

☒ Input connected

4.16.3 SEN01M: Serial Numbers 710000-749999

The SEN01 can switch a bistable I/O according to the set values.

Extension: is the time the I/O will remain on when no more motion is detected.

First: The magnitude of the movement necessary to activate the I/O. A larger value will therefore trigger the I/O a little later.

Keep: The amount of movement necessary to keep the I/O active. Values greater than or equal to the "First" option are excluded.

Light level: If 'Only if "Dark"' is checked, the I/O will be activated if the measured light value is lower than the set threshold value.

The current light value will be displayed with a yellow bar via the "Read values" button. When the threshold value is in the colored bar, the I/O will be activated upon movement.

SEN01M

Global settings

Location: SEN01M_56

Type: SEN01M Switch

Read Values

SEN01M


Input 1 (A54.2)

Toilet ground floor

Test

☒ Input connected

Properties...

 ☒ Only if "Dark"

extension: 60 Sec

First: 20

Keep: 10

Light level: 41

Scan

4.17 Dali broadcast module QDBC02SA module type 0009

The Dali broadcast module controls 2 Dali buses on the basis of 2 qbus I/O's. All Dali luminaires, regardless of their set address, will follow the status of the Qbus I/O. Usually a Qbus dimmer I/O is used for this. All parameters of a dimmer can be found in section 4.2.3

QDBC02SA module 0009B0000B

Location: QDBC02SA_57

Properties...: Controlled via bus

Output 1 (A55.1): Name: DIMMER_002

Output 2 (A54.3): Name: TOGGLE_005

Input 5 (All Off/On):

Name: [dropdown]

Push button: [dropdown]

Stand Alone: Delay before All OFF is activated: [dropdown]

Input delay: 700ms

All OFF: [dropdown]

All ON: [dropdown]

DIMMER_002: [checkbox] [checkbox]

TOGGLE_005: [checkbox] [checkbox]

Read Values

You can read the current value of the I/O's via the “Read values” button.

You can control the I/O's online via the Up/Down buttons. A short click up or down will bring the I/O to the start value and off state respectively.

If you wish to pre-configure this module to work Stand-Alone, you can select this at the top of the screen. You can then easily set all parameters like this:

QDBC02SA module 0009B0000B

Location: QDBC02SA_57

Properties...: SA - 2x Dimmer

Output 1 (A55.1): Name: DIMMER_002

Output 2 (A54.3): Name: DIMMER_003

Input 5 (All Off/On):

Name: [dropdown]

Push button: [dropdown]

Stand Alone: Delay before All OFF is activated: [dropdown]

Input delay: 700ms

All OFF: [dropdown]

All ON: [dropdown]

DIMMER_002: [checkbox] [checkbox]

DIMMER_003: [checkbox] [checkbox]

Read Values

4.18 Constant Voltage Driver CVD04SA module type 000C

The Constant Voltage Driver sends a PWM signal to the 4 channels.

The module can control the following types of I/O's in standalone mode:

- 4 separate dimmers
- 2 WWCW LED(strips)
- 1 RGB LED strip + 1 dimmer
- 1 RGBW LED strip

In the selection you can also indicate that the module is controlled via the QBUS bus. Other combinations of I/O types are also possible in this way.

In the properties it is also possible to choose the desired PWM frequency (500Hz, 1000Hz or 2000Hz. And per channel you can set whether it is dimmed according to a linear or a logarithmic curve. The module window looks like this:

The configuration of the RGB+ colors and sequences (via the button at the top right) is done in an identical way as described for the SER485/DMX module in chapter [4.11](#).

4.19 Configure Wireless Interface QWI/ZB (Zigbee®) Module Type 0047

This Qbus Wireless Interface provides wireless communication between Qbus and all Zigbee® wireless Qbus modules.


First of all, add the serial number of this module in the list of modules. If this module has already been programmed in another project, it is important to clear the module's memory first. When you send the data from this (empty) module, all previously registered wireless modules will be deleted from memory.

You can add the new wireless modules via the green + button or via the New Module Wizard. These are also divided into the categories Relay, Sensor and Energy.

Because each Zigbee® module can and may only communicate with its own wireless network, all ZigBee® wireless modules must be addressed to the wireless interface.

When replacing a QWI/ZB with a new one, it is not possible to continue using the existing configuration. ALL wireless modules will have to be re-addressed into the network.

After assigning the wireless interface, the QWI/ZB screen will look like this:




4.19.1. QWZ-REL02/230

QWZ-REL02/230 wireless module A00001

Global settings

Location:



QWZ-REL02/230

Module not connected

I/O 1


I/O 2

Adding a new Zigbee® module to the network is done by clicking the “Address this device” button. The Wireless interface then goes into 'commissioning mode' and waits for a module to register. This action is different for each type of module. This is clarified in the text on the next screen:

QWZ-REL02/230 wireless module A00001

Global settings

Location:



QWZ-REL02/230


Module not connected

Assign code...

Press program button for 5 seconds on QWZ-REL02/230 (4701 A12345)
The green led on module shall be flashing rapidly. Addressing can take up to 1 minute!

After operating the module, as mentioned in the text above, it will attempt to pair with the wireless interface. So make sure that it is within the transmission range of the interface or other powered wireless module that is already in the Zigbee® network!


After a while the following screen will appear:




This shows the short address as well as the signal strength (RSSI, which is expressed in dBm). Larger negative numbers indicate a worse signal. Communication is guaranteed between 0dBm and -60dBm. Signals between -60dBm and -80dBm are weaker and signals smaller than -80dBm should be avoided.

When “(---)” is displayed, it means there is no reception.

As long as no I/Os have been assigned to the module and this data has not yet been sent, the test buttons will send a toggle command. With this first test you can check whether both relays switch on and off smoothly.




After you have assigned the outputs and sent all the new data, the test buttons will operate the I/O in the controller. The controller then forwards the data to all linked modules.




After confirmation, the 'Remove from network' button will send the command to the wireless network to disconnect the module from the wireless interface. Even if the module could not be reached, the short address will be removed from the list of connected modules so that the I/Os on that module can no longer be controlled.


4.19.2. QWZ-PPE01




Likewise as the QWZ-REL02/230, this module can be connected in a similar way.



This module controls the I/O assigned in the first frame and will also transmit its power measurement to the I/O (universal type) assigned in the second frame. This has a measuring range of up to 3.8kW with a resolution of 0.1W.




If the device that is plugged into this has a much smaller maximum power and if you wish to adjust the graph on the Cloud, you can do this via the 'Properties' button:




After confirmation, the 'Remove from network' button will send the command to the wireless network to disconnect the module from the wireless interface. Even if the module could not be reached, the short address will be removed from the list of connected modules so that the I/Os on that module can no longer be controlled.

4.19.3. QWZ-RAD



Likewise as the QWZ-REL02/230, this module can be connected in a similar way.




In the example above, the module was linked perfectly and was assigned address 0x5B98. Unfortunately, the RSSI value is sometimes incorrectly displayed for this type of modules. “(---)” will sometimes be shown incorrectly.

When assigning a Thermostat I/O, it is important to also indicate whether this thermostatic valve should work as a temperature sensor.

When you check the “TH -> CTD” button, this module will transmit its measured temperature to the controller. This option may only be enabled on 1 module!

A Thermostat I/O may be assigned to different thermostatic valves. These will all follow the same temperature setting.


Please note: If the thermostatic valve is manually set to the 'OF' position, it will no longer listen to new desired temperatures.



As shown in the figure above, “Read values” displays the measured temperature as well as the current program, the desired temperature and the status of the thermostat outputs.

After confirmation, the 'Remove from network' button will send the command to the wireless network to disconnect the module from the wireless interface. Even if the module could not be reached, the short address will be removed from the list of connected modules so that the I/O on that module can no longer be controlled.

4.19.4. QWZ-TH




Likewise the above QWZ modules, this module can be linked in a similar way via the “Address this device” button.

When assigning a Thermostat I/O, it is also important to indicate whether this thermostat should work as a temperature sensor.

When you check the “TH -> CTD” button, this module will transmit its measured temperature to the controller. This option may only be enabled on 1 module!

A Thermostat I/O may be assigned to multiple thermostatic valves. These will all follow the same temperature setting.




As shown in the figure above, “Read Values” displays the measured temperature as well as the current program, the desired temperature and the status of the thermostat outputs.


After confirmation, the 'Remove from network' button will send the command to the wireless network to disconnect the module from the wireless interface. Even if the module could not be reached, the short address will be removed from the list of connected modules so that the I/O on that module can no longer be controlled.

4.19.5. Zigbee® Niko 552-7200x switches

Niko's wireless Zigbee® switches can also be linked to the QWI-ZB.




By analogy with the above QWZ modules, this module can be linked in a similar way via the “Address this device” button:




After addressing the wireless switch, an I/O or a scene can be assigned to each key.

After confirmation, the 'Remove from network' button will send the command to the wireless network to disconnect the module from the wireless interface. Even if the module could not be reached, the short address will be removed from the list of connected modules so that the I/Os on that module can no longer be controlled.

4.19.6. Zigbee® Niko 552-7210x relay with push button



By analogy with the above QWZ modules, this module can be linked in a similar way via the “Address this device” button:



On the module, an I/O with ON/OFF operation or a heating contact of a thermostat address can be assigned to each relay.


After confirmation, the 'Remove from network' button will send the command to the wireless network to disconnect the module from the wireless interface. Even if the module could not be reached, the short address will be removed from the list of connected modules so that the I/Os on that module can no longer be controlled.

ATTENTION:


If you use a push button from this module, it will immediately switch the corresponding relays and also transmit this status to the CTD. I/Os of the Timer type (1, 2 and 3) are also turned ON or OFF.

When the I/O controls an output contact of a thermostat address (heating, cooling, etc.), the button on the module may not be used. This will damage the thermostat setting!


4.19.7. Zigbee® Niko 170-33505 socket




By analogy with the above QWZ modules, this module can be linked in a similar way via the “Address this device” button:



This module then controls the I/O assigned in the first frame and will also transmit its power measurement to the set I/O (universal type). This has a measuring range up to 3.68kW.



If the device that is plugged into this has a much smaller maximum power and if you wish to adjust the graph on the Cloud, you can do this via the 'Properties' button:



After confirmation, the 'Remove from network' button will send the command to the wireless network to disconnect the module from the wireless interface. Even if the module could not be reached, the short address will be removed from the list of connected modules so that the I/Os on that module can no longer be controlled.

4.20 Configure Wireless Interface QWI/EW (Easy Wave) Module Type 000A

The Qbus Wireless Interface provides wireless communication between Qbus and all wireless Qbus modules.


First of all, add the serial number of this module in the list of modules. If this module has already been programmed in another project, it is important to clear the memory of the module first. When you send the data of this (empty) module, all previously registered wireless modules will be deleted from the memory.

You can add the new wireless modules via the green + button or via the Wizard new modules. These are also divided into the categories Relay, Switch, Input and Sensor.

Since each module transmits a unique transmission code, all wireless modules must be enrolled to the gateway. In order to cause the least problems, we recommend that you enroll this code before mounting it in its final location. We also recommend that you first enroll all sensors (see menu [4.18.9](#)), because they will send out their code when they detect motion. Once this code is known, it will be ignored when enrolling the next module.

You can select or add a bistable I/O as an error address. This will be switched on by the module as soon as an error is reported on one of the wireless modules. Any module that runs on battery will be able to report a low battery. An additional error message will also be generated if a magnetic contact has not sent its status within 24 hours.


After assigning the wireless gateway, the screen of the QWI/EW will look like this:



After 'Read values', when clicking on a module, the low or completely empty battery status may be shown.


If the battery has been replaced, this error will not disappear automatically. Resetting this individual error is only done by clicking the “Reset Error” button.

4.20.1 QWE-REL01/230 and QWE-REL01/230PF relay module




For each wireless module it is important that it is enrolled to the gateway (QWI/EW)
An I/O module receives a code from the QWI/EW, an input module sends its code to the QWI/EW.

When you click on “Assign new code”, you will be asked to put the module in programming mode and then click on OK:



When OK is pressed, the QWE-REL01 is assigned a transmission code by the QWI/EW. The module may now return from programming mode. You can do this by briefly pressing the programming button on the module 3 more times. The programming LED will stop flashing.




By using the “On”, “Off” buttons you can perform a first test to check if the code has been programmed correctly. To test this new module via the qbus I/O’s, it is important that the data is first sent to the controller via the normal way (red upload arrow).

4.20.2 QWE-PP01/BE power plug


In an identical way to the QWE-REL01 module as described in 4.18.1, you can add a QWE-PP01/BE. Unlike the QWE-REL01, this module will automatically exit programming mode after assigning the transmission code.

4.20.3 QWE-SWC04/55 4-way push button

Assigning an input module is done in a slightly easier way. When you click on the “Assign/test wireless module” button, the following screen appears:



When you press one of the push buttons, it will send its transmission code and store it in a free place in the QWI. The transmission code is shown at the top and the key pressed is shown in green.




It is not necessary to teach each key separately, but you can do this to verify the operation of each key.


With the option “Always ON” and “Always OFF” you can make sure that the buttons at the top always turn on the I/O and the buttons on the bottom row will always turn off the selected I/O. If this option is not checked, these inputs will always change the status of the I/O like a normal Qbus Toggle I/O.

4.20.4 QWE-INP04/bat 4-way input module

In an identical way to the QWE-SWC04 module described in 4.18.3, you can add a QWE-INP04/bat. However, with this module you can select whether you connect 4 push buttons or 2 long-term contacts. This requires a different wiring. A long-term contact can act as “normally open” (The I/O follows the status of the input) or “switch” (the I/O reverses with every change on the input)




Or e.g.




4.20.5 QWE-INP02/230 2-way input module

In an identical way to the QWE-SWC04 module as described in 4.18.3, you can add a QWE-INP02/230. However, with this module you can select whether you connect 2 push buttons or 2 long-term contacts to the 2 inputs. If long-lasting contacts are used, a wire bridge between L and F is necessary. A long-term contact can act as “normally open” (The I/O follows the status of the input) or “switch” (the I/O reverses with every change on the input)




If long-term input contacts are used, it is necessary to assign the codes of both inputs with this module! The first learned code will be named as “Input 1”, the second learned code as “Input 2”



4.20.6 QWE-PB/button and QWE-PB/wrist and QWE-PB/neck and QWE-RC01 1-button pushbuttons


In an identical way to the QWE-SWC04 module as described in 4.18.3, you can assign a QWE-PB and QWE-RC01 module.

When you briefly press the push button, it will send its transmission code and store it in a free place in the QWI. The transmission code is displayed and the key pressed is displayed in green.




4.20.7 QWE-RC04/metal 4-button hand-held transmitter

In an identical way to the QWE-SWC04 module as described in 4.18.3, you can assign a QWE-RC04 module.




4.20.8 QWE-SWC01/call and QWE-SWC01/reset 1-key pushbuttons

In an identical way to the QWE-SWC04 module as described in 4.18.3, you can assign a QWE-SWC01 module. However, both modules have a different function. The QWE-SWC01/call module can only turn an I/O ON.



The QWE-SWC01/reset, on the other hand, can only turn an I/O OFF.




4.20.9 QWE-SEN01MW motion detector with light cell

Assigning a wireless motion detector can be a little more difficult.

It will only enroll when there is movement and the light level is below the set value. So make sure that these settings are correct or test with a darkened motion detector.

Depending on the set time, it will re-transmit the movement every 5-10 seconds so that it can register its transmission code to the gateway after clicking "Assign/test wireless module".




The transmission code is shown at the top and the key pressed is shown in green.

4.20.10 QWE-MC01/white window or door contact

Assigning a window or door contact is done in an identical way to the QWE-SWC04 module as described in 4.18.3,

Both when making contact and when breaking contact, this module will send its key.

In addition to reporting a low battery status, this module will also be marked as an error if it has not reported its status within 24 hours. The battery of this module is then completely empty or the wireless signal is too weak.




4.21 QDM01 Configure Dali1 and Dali2 module (Type 0011)

The QDM01 module has a built-in Dali power supply and can address both modules with the Dali1 protocol and the Dali2 protocol.

The Dali1 modules are configured in the same way as the QDI01. See point [4.12](#)

The configuration of the Dali2 modules is done via the fourth tab:



With the download arrow the Dali2 bus will be scanned. Addresses that respond will be marked green. If the address is orange, more than one module is responding. If the address is in red, the module will indicate a failure. If the address is still greyed out or not in the list, this address will no longer be found on the Dali2 bus.

Idem as on Dali1, when clicking on an address or instance, the relevant module will blink (set to minimum and maximum). Most detectors will have a built-in LED flashing on and off.


You can assign a Qbus I/O to the selected Dali2 instance by selecting or creating a new I/O on the right side of the screen.

By clicking on the plus sign above the list, the Dali2 bus is scanned for newly connected modules. After possibly assigning new addresses, the scanned bus will be shown again.

By clicking on the minus sign above the list, the selected Dali2 address will be deleted from all modules assigned to this address.

In addition to the current status of the I/O's from the controller, the "Read values" button will also display the current voltage and current consumption of the Dali bus.

With Dali2 motion detectors it is possible to set the 'hold time'. When clicking on the instance of this detector, an extra screen appears:



This parameter is read out with the arrow down. By default, this is set to 90 (x 10s = 15min.). This means that the module passes on the movement and will only do this again if there has been no movement for 15 minutes.

It is better to set this as short as possible and to adjust the 'delay off' of the bistable I/O to your own liking. So set the hold timer to 1 (10 seconds) and forward it by clicking the up arrow.

4.22 QDG04SA Configure Dali1 module (Type 0012)

The QDG04SA module has a built-in Dali power supply and can control up to 64 Dali1 I/O's via 4 groups. This module can be controlled via the bus or Stand-alone via the inputs on the module itself. The configuration can be set via the buttons on the front panel. For this configuration we refer to the technical data sheet of the module.

The groups can also be set via the System Manager: Assigning Dali addresses to a driver, configuring groups, setting parameters, etc. is done in the same way as with the QDI01. See point [4.12](#)

When entering the serial number and assigning the I/O's, you will see, for example, the following screen:

0012 module 0012B00001

Global settings

Location: QDG04SA_1

Properties...: Controlled via bus

Read Values

QDG04SA

Lees continu

5s

Test...

Outputs | Dali Setup

Output 1 (A03.1)

Name: DIMMER_001

Properties...

Up

Down

Output 2 (A03.3)

Name: DIMMER_002

Properties...

Up

Down

Output 3 (A04.1)

Name: DIMMER_003

Properties...

Up

Down

Output 4 (A05.1)

Name: Forget timer

Properties...

Test

Input 5 (All Off/On)

Name:

Push button:

Input delay: 700ms

3s

Stand Alone

Delay before All OFF is activated: n/a

All OFF

All ON

DIMMER_001	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
DIMMER_002	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
DIMMER_003	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Forget timer	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Default

The 4 assigned I/O's will control the 4 preset groups.

The same as the other SA modules, this module can also work completely standalone. The settings as shown below are then applied.

0012 module 0012B00001

Global settings
 Location: QDG04SA_1
 Properties...: SA - 4x Dimmer
 Read Values
 QDG04SA

Outputs | Dali Setup

Output 1 (A03.1)
 DIMMER_001
 Minimum dimming level: 10%
 Level when pressed shortly or when activated in binary logic: 100%
 Automatic fade out when pressed shortly: n/a Sec
☐ Memory function - Use last status (if greater than 20%)

Output 2 (A03.3)
 DIMMER_002
 Minimum dimming level: 10%
 Level when pressed shortly or when activated in binary logic: 100%
 Automatic fade out when pressed shortly: n/a Sec
☐ Memory function - Use last status (if greater than 20%)

Output 3 (A04.1)
 DIMMER_003
 Minimum dimming level: 10%
 Level when pressed shortly or when activated in binary logic: 100%
 Automatic fade out when pressed shortly: n/a Sec
☐ Memory function - Use last status (if greater than 20%)

Output 4 (A06.1)
 DIMMER_005
 Minimum dimming level: 10%
 Level when pressed shortly or when activated in binary logic: 100%
 Automatic fade out when pressed shortly: n/a Sec
☐ Memory function - Use last status (if greater than 20%)

Input 5 (All Off/On)

Input delay: 700ms / 3s

Stand Alone: All OFF / All ON

Delay before All OFF is activated: n/a

DIMMER_001	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
DIMMER_002	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
DIMMER_003	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
DIMMER_005	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Push button

As with the other Qbus Stand-Alone modules, if the module is used in Stand-Alone mode, the fifth input (Input A: All Off/On) will act as an All Off button (press briefly), and as a Panic button at long push. As soon as the module is no longer used in Stand-Alone mode, i.e. if it is connected to a controller and is supplied with power via the bus, the fifth input will work differently. Now a scene must be created via the System Manager and assigned to this input (on the field "Input 5"). This scene is then executed with a short push. **PLEASE NOTE, with a long press the next scene in the list of created scenes in the Qbus System Manager is automatically executed. So make sure that this is taken into account!**


IMPORTANT:

- if several Stand-Alone modules are connected to each other on this fifth input, a scene may only be assigned to 1 module – the scene input (Input 5) must remain empty for all other connected modules!
- For the scenes used in the 5th entrance of SA modules, NO DELAY TIMES may be set at the scene settings itself. The delays are entered in this module screen.

4.23 Configuring module SenMoLi (type 0045) and SenMax (type 0046)

The SenMoLi is the successor to the SEN01M and the SenMax combines the capabilities of the AIR01(CTH) with the SEN01M.

After entering the serial number of a SenMax module, the screen appears with the five possible I/O's that update their values every 5 seconds by default:



Temperature:

The first I/O displays the measured temperature. This I/O can have the “thermostat” or “universal” mode. If you choose a thermostat I/O, it will work like any other temperature sensor. This has a resolution of 0.5°C. You can assign this I/O directly to relays, push buttons, scenes, ... More information about the mode thermostat can be found in section [3.5.6](#). If you choose a universal I/O, it has an accuracy of 0.01°C. This I/O has a range of 0 to 40°C. What needs to be switched can then only be done via analogue logic. More information about logic can be found in section [3.10.2](#).

Humidity:

The second I/O measures the relative humidity in the room (0 – 100%). You can assign this to a dimmer or to a universal I/O. You can also assign a dimmer I/O directly to an I/O module, but it will usually be used to control other I/O's via analogue logic. More information about logic can be found in section [3.10.2](#).

As a universal I/O, this works identically. The latter does have a resolution of 0.01% but relative humidity is normally not treated so critically.

Light level:

The third I/O measures the light level in the room. If you use a universal I/O here, this I/O will give the measured lux value between 0 and 2000lx. If you choose a dimmer I/O here, it will give a value between 0 and 100% (0 to 1275lx). The I/O will show 100% if the measured value is greater than or equal to 1275lx.

Eg: 640 lx. will give a dimmer value of 50%.

You can also assign a dimmer I/O directly to an I/O module, but this I/O will usually be used to control other I/O's via analog logic. More information about logic can be found in section [3.10.2](#).

VOC:

The fourth I/O measures the air quality in the room. If you use a universal I/O here, this I/O will give a measured value between 0 and 1000ppb (parts/billion). If you choose a dimmer I/O here, it will give a value between 0 and 100% (0 to 1000ppb).

Eg: 500ppb will give a dimmer value of +/-50%.

You can also assign a dimmer I/O directly to an I/O module, but this I/O will usually be used to control other I/O's via analog logic. More information about logic can be found in section [3.10.2](#).

Motion:

The last selected I/O must always be of the “toggle” type. It will turn on when motion is detected in the room. By default, it will keep the I/O on for another 60 seconds after no more motion is detected.

Additional features:

The scan buttons show the measured values of the selected I/O in real time. This can be especially useful for movement. The sensitivity can be adjusted by the installer via the extra parameters that one can set via the “professional service mode”

SenMoLi:

The SenMoLi is a limited version of the SenMax. It will only be able to control the “Light Level” and “Motion” I/O's.

5. Remote connection

5.1 Qbus Control

By connecting the Ethernet port of the Controller CTD01Em, CTD01E, CTD01E+, CTD02E, CTD03E, CTD10, CTD40 CTDmax to the router in the local network, this controller will connect itself to the Qbus Cloud when it is properly activated. Once logged in, the connection between the Qbus installation and the Qbus Cloud will continue to exist, so that the user can log in to the Qbus Cloud via a mobile device, tablet or PC with internet access and thus operate and visualize his installation. In the future, additional services will also be offered via the Qbus Cloud, such as SMS, e-mail, linking controllers, etc.


This manual describes how a Qbus installation can become Cloud-compatible.

Step 1: Install the correct software on the Controller.


In order to use the Qbus Cloud, at least System Manager III version 3.5.6 is required. This can be downloaded from the Qbus site:

<https://www.qbus.be/nl-be/support/software/system-manager-iii>

Install the new System Manager, click on Utilities - Setup and you will see the screen below. Click the Connection tab to connect to the Controller.




Once this upload is done, click on “Read Settings” in the Setup Screen and you will be notified that the Controller is connected to the computer.




Step 2. Register the Controller to the Qbus Cloud

Now click on the “Qbus Cloud” tab. Select the stable Version 6.0.9 for older CTD’s and click the upload arrow next to it. After that you can enter an e-mail address - once this is filled in click on the button “CTD -> Cloud” and the Controller is registered in the Qbus Cloud. An activation code will now appear on the screen. You can copy this code when you add your controller in the QbusControl app or website!!! If you want to add the CTD later to the account of the customer, the activation code will also be sent by e-mail to the specified e-mail address.




Step 3: Register yourself on the Qbus Cloud

Go to the site www.qbuscontrol.com and click the “Register” button.



Now fill in your personal details, including the password with which you want to log in to Qbus Control. Click on “Create account”. You can now open your account on Qbus Cloud.



Step 4: Add your CTD to your account

In the settings screen, click on “ADD INSTALLATION” and type in the Serial number of the CTD and the activation key just just received.

Step 5: Configure the Qbus Cloud

The Qbus Cloud still needs to be configured, press the wheel at the top left in the Menu bar

In the Controllers field, additional controllers under the same account can be added by serial number and activation code. Different I/O's from different controllers can thus be displayed on the same Cloud account.

By clicking on “Groups” you can create groups. Click on “Add group”, then a choice can be made between adding a Manual or an Automatic group.

Note: To return to the previous step, click on the arrow at the top, or to exit the configuration and go to the main screen of the Qbus Cloud, click on the cross in the top left.


To add a manual group you first have to give the group a name, and then choose the I/O's that belong to that group.

The screenshot shows the 'Settings' window with a sidebar on the left containing 'Installations', 'Groups', 'Clock', 'Actions', 'Scenes', 'Shop', 'Shared accounts', 'My account', 'Guide', and 'Info'. The 'Groups' section is selected, showing 'Groups > Demo'. The main area has a 'Group type' dropdown set to 'Manueel'. Below it is a 'Name' input field containing 'Demo'. Under the 'Outputs' section, there is a blue button labeled '+ ADD OUTPUT'. In the bottom right corner, there is a red button labeled 'REMOVE GROUP' with a close icon.


An automatic group is a group that will be created automatically based on location or based on the type of I/O. To create an automatic group based on location, the locations must be assigned to the I/O's in the configuration of the System Manager. In the automatic group based on the type of I/O you can choose between the different types such as dimmers, on/off, CO2, scenes, thermostats,... The advantage of an automatic group is that, if an extra I/O is ever created of the same type or to which same location is assigned in the System Manager, it will automatically appear in the correct group in the Qbus Cloud.

The screenshot shows the 'Settings' window with the same sidebar as the previous image. The 'Groups' section is selected, showing 'Groups > New group'. The main area has a dropdown menu labeled 'Create a group based on the type of output' with 'Co2' selected. Below the dropdown is a blue button labeled 'ADD GROUP'.


An existing group can also be modified: in a manual group, I/O's can be added and removed, given a different order, or other icons can be assigned. Click on the name of the I/O in the group to change it. By clicking and holding on the yellow square to the right of the I/O, the order of the I/O's can be changed.



In an automatic group you cannot add or remove I/O's yourself - this is automatic depending on location or type. You can change the icon to a new available icon by clicking on the I/O



Clocks can also be set in the Qbus Cloud. These clocks are run at the selected times so that you can use the Qbus installation as an alarm clock, for example: shutters on, lights on 20%, coffee on, heating to comfort.



Settings

Installations

Groups

Clock

Actions

Scenes

Shop

Shared accounts

My account

Guide

Info

Clock ▶ New action

A clock action will automatically execute the chosen output at the chosen time.

Output

Use the timezone of?

Ubie (Romance Standard Time)

What Time?

16 : 37

When do you wish to apply this output?

Once

ADD ACTION >

Settings

Installations

Groups

Clock

Actions

Scenes

Shop

Shared accounts

My account

Guide

Info

Clock ▶ New action

A clock action will automatically execute the chosen output at the chosen time.

Output Option Option

020012 - TH SWC demo (thermo) Regime COMFORT

Use the timezone of?

Ubie (Romance Standard Time)

What Time?

16 : 00

When do you wish to apply this output?

Repeated

Which day?

☒ Monday
☒ Tuesday
☒ Wednesday
☒ Thursday
☒ Friday
☐ Saturday
☐ Sunday

ADD ACTION >

You are logged in as
Qbus Showroom

Log out

195

A clock can easily be turned on or off by clicking on the clock and dragging between 1 and 0.

Clock ▶ Action

Output:
020012 - Random 100% (scene)

Option
Status

Option
On

Switch on / Switch off
1


Use the timezone of?
Ubic (Romance Standard Time)

What Time?
08 : 35

When do you wish to apply this output?
Repeated

Which day?
☒ Monday
☒ Tuesday
☒ Wednesday
☒ Thursday
☒ Friday
☐ Saturday
☐ Sunday

Now click on the cross at the top left, your Qbus Cloud is configured and you are ready to use it. Have fun!




5.2 EQOweb web server

All CTD controllers with an Ethernet Port (CTD01E, CTD02E, CTD03E, CTD10, CTD40 and CTDmax) have a web server on the Ethernet interface. This means that it is possible to remotely control this CTD via a browser on an iPhone, smartphone, tablet, laptop, Mac, ...

To be able to use EQOweb you must first create a control table (see chapter 3.8.) Make sure to use the first control table (address A.01 - the type will default to "EQOweb" and cannot be modified) as the EQOweb control table.

In order to use the EQOweb web server, the firmware on the Ethernet port must be at least version 5.0.5. The version of that firmware can be checked as follows: open the System Manager III, click on Utilities, click on Setup, click on Search for CTD's and Settings...



Q Setup

CTD not connected

☐ Communicatie Logging

Read the settings

Status | Global settings | **Connection** | Heating/Cooling | Software | SD Card | SWC Colours | Qbus-Cloud | Expansions

Current communication status
.....

Searching connection

1) ☒ Ethernet (ETH0x)

TCP/IP

IP address or host name for TCP/IP connection
192.168.7.62

Port
8445

User
[]

Password
[]

CTD Name:
[]

Default ports on LAN:
EQOweb: 80
SM III: 8445
EQOmmmand: 8446

Search for CTD's and settings...

EQOweb (poort 80)

On

Off

2) ☐ USB (Not available on CTD10, CTD40 or CTDmax)

Qbus controllers are now being searched (via UDP network packets). Select your CTD controller – in the screen where your controller is located you will first see the Mac address and name (default serial number) of the controller and then the version of the Ethernet port. If you do not have minimum version 5.0.5 you need to upgrade the Ethernet port: click on “Upload Firmware V XXX”. This will upgrade the Ethernet Port firmware (differs from the Firmware of the CTD itself which can be upgraded via setup/software).

TCP/IP Properties X

Double click to select the device

Search for CTD's

Search on network interface with local ip address G

s/n	Name	Fix	IP	MAC	Type	Eth.	Auto Upgr.	Auth.Key
000059		Fix	192.168.20.62	00:20:4A:BD:2C:D1	CTD	V.6.0.9		4a6dec64b3e0427881543bb3b

Connections
Reset Ethernet Port
Upload firmware V6.0.9

MAC (2 Ist) - IP . . . Repair Eth. in CTD V3

Properties | **Password**

IP setup

☐ Automatically obtain an IP address

☒ Use the following IP address

IP address . . . Ping

Subnetmask . . .

Gateway . . .

☐ Automatically Obtain DNS server address


☒ Use the following DNS server address

DNS address . . . Set IP / Gateway / DNS

Cancel

The upgrade of the Ethernet firmware at CTD0xE is done via the TFTP protocol. For this, UDP packets must also be allowed on the network (adjustment or temporary disablement of Firewall may be necessary for this). With the CTD10, CTD40, CTDmax this is done automatically via the internet. Once the EQOweb control table has been uploaded to the controller, you can control this control table via the EQOweb web server by typing the IP address of the Controller in your browser (<http://192.168.X.XXX:8444> for the older CTDs and <http://192.168.X.XXX:80> or simply <http://192.168.X.XXX> for the CTD10, CTD40 and CTDmax). See Chapter [2.4.1](#) to assign a static IP address to your controller.

You will now see the following login screen




Make sure Login and Password are the same as those set through the System Manager III. For this, see the topic “Setting password for Ethernet connection” under chapter [2.4.1](#). Communication with the Controller. In the login screen you can check Save Password so that Login and Password do not have to be entered again and again.

By pressing the Login button you enter the menu of the web server that has been compiled via the operating table. Each menu now shows the different I/O's that can be operated separately.

ATTENTION:

- EQOweb is a polling-based system. This means that the status must always be requested – there is no real-time feedback of changed statuses of your installation.
- Each thermostat I/O has two versions: an I/O to control the thermostat programs (I/O NAME (Prog.)) and an I/O to adjust the set temperature per (half) degree (I/O NAME (T°)). If the latter is set in the EQOweb control table, this I/O will return you the room temperature of the location where the thermostat is located - so you will not be able to use this I/O to indicate the desired temperature. You can indicate the desired temperature by setting the Prog. to adjust the I/O's (Economy, Comfort, Night...).



5.3 Port Forwarding

In order for the Ethernet device to establish remote connections through the router, some ports must be forwarded to the local IP address. This is called “Port forwarding” or “Virtual server”; Using an internet browser (MS Internet Explorer, Mozilla Firefox, Google Chrome, etc.), navigate to the router's address (e.g.192.168.2.1) and follow the router's instructions. Basically what you are doing is pairing the ports 8444 and 8445 of the router and entering the IP address assigned to them. From now on, the Ethernet interface can be reached via the external IP address.

Certain providers may change the available external IP (especially for ADSL users). It is not easy to remember 4 numbers. Therefore, there are certain services that can convert an IP address into a name (e.g.<http://www.dyndns.org>) By surfing to this site, you can activate a name, e.g. MYOWNNAME.DYNDNS.ORG. Of course, you need to register on the site first, so you don't need codes to sign up later. You can then link the name of your choice to the IP via the site.

6. Measuring (energy) via Qbus

All bus events are kept on the SD card of the Qbus controller: from this the average temperature in a room, how much the light has been on in the hall, how much energy, water or gas was consumed last winter, etc. can be calculated. This data is collected from the Qbus modules, or is read from a non-Qbus meter module via an input module. The data on the Qbus SD card can then be exported from the controller in Excel, or can be displayed on the Eco Dashboard (part of the Qbus EQOmmmand software).

For reading data from non-Qbus meters, we have designed the Energy Counter Module or ECM04.

6.1. Energy Counter Module

The ECM04 or energy counter module is a module that adds up the pulses it receives from a meter. It does not matter from which meter type these pulses come as long as the contacts are voltage-free. The ECM04 can receive and add a pulse every 250ms. The system can also create an alarm at a certain number of pulses, for example for a green power certificate for solar panels.

Step 1: Insert Serial Number

The ECM04 has the serial number range 81xxxx. In our example we now use 810001, the following screen will appear.

ECM04 module 810001

Global settings

Location:

Update interval:

Input

1.

2.

3.

4.

Step 2: create I/O's and assign them

This can be done in 2 ways:

1. On the module itself: By clicking on the function “- New I/O -” in the drop-down menu of input 1.
2. Wizard new I/O: In the I/O's tab you have the function “Wizard new I/O”, by opening this you can create an ECM04 input via the option “Energy meter”.

If you create an ECM04 input via one of these methods, the three other inputs of the ECM04 will automatically be created as meter inputs.


In our example, we have created and named 4 entries as follows: E-meter, Solar Energy , Gas Meter, Water Meter

ECM04 module 810001

Global settings

Location

Update interval

 ECM04

Input (A12)

1.
2.
3.
4.

When we look at the properties of the ECM04 input we see several parameters:

Minimum: This is the minimum limit of the value that will be measured and can be displayed in the EQOmmmand and Cloud.

Maximum: This is the maximum limit of the value that will be measured and can be displayed in the EQOmmmand and Cloud.

Type: Energy (in kWh), gas (in m³), water (in l) or 'Other'

Puls value: This is the factor with which we have to multiply the measured pulse to get a correct value. For example, each pulse represents 100Wh, then the multiplier must also be 100 if we want to express it in Watthours, if we want to express it in kWh then the multiplier must be 0.1.


Unit: this is the unit in which we express the measured value.

trigger: is a set point where an alarm I/O can be created. The can be set from 0 to 1,000,000,000 pulses.

warning address: This is the I/O that turns on when the number of pulses is equal to or greater than the trigger value.

If we want to read the number of pulses in the System Manager, we can press the button “Read value”. This data is synchronized every minute by default, but the update interval can be set from 1 to 255 minutes. Each interval the number of pulses counted is reported, but also when the counter reaches 255, this is reported to the controller.

The pulses can also be reset to zero by clicking the “Reset” button.



ECM04 module 810001

Algemene instellingen

Plaats:

Update interval:

Ingang (A20)

1.	<input type="text" value="E-meter"/>	<input type="text" value="136235"/>	<input type="button" value="Reset"/>
	<input type="text" value="Normaal open"/>	Reset: mei 25 13:47	
	<input type="button" value="Eigenschappen..."/>		
2.	<input type="text" value="Zonne-energie"/>	<input type="text" value="0"/>	<input type="button" value="Reset"/>
	<input type="text" value="Normaal open"/>	Reset: mei 25 13:47	
	<input type="button" value="Eigenschappen..."/>		
3.	<input type="text" value="Gasmeter"/>	<input type="text" value="0"/>	<input type="button" value="Reset"/>
	<input type="text" value="Normaal open"/>	Reset: mei 25 13:47	
	<input type="button" value="Eigenschappen..."/>		
4.	<input type="text" value="Watermeter"/>	<input type="text" value="0"/>	<input type="button" value="Reset"/>
	<input type="text" value="Normaal open"/>	Reset: mei 25 13:46	
	<input type="button" value="Eigenschappen..."/>		

Step 3: Logic


The ECM inputs can be used in analog logic as a condition. For each ECM input there are 4 parameters in the logic that we can use. In the Counter tab we see these I/O's. We see there Last Count, Counter L, Counter H, Counter XH and Counter XXH.

The counted value on the ECM04 is divided over these 4 parameters. Each parameter can go up to 255. When Counter L(ow) becomes greater than 255 we increase Counter H(igh) by one and reset Counter L, when Counter H exceeds 255 we increase Counter XH by 1 and reset Counter H. If Counter XH is higher than 255 then we will increase Counter XXH by 1 and we will reset Counter XH. Counter L counts in multiples of 1 (0 to 255), Counter H counts in multiples of 256 (0 to 65280), Counter XH in multiples of 65536 (0 to 16,711,680) Counter XXH in multiples of 16,777,216 (0 to 4,278,190,080)


The 'Last Count' contains the number of pulses of the last measurement (default is the last minute).

Note: if there are NO new pulses, this value will not return to zero, but will remain at the last value (0 – 255).

An example: We want the Alarm 1 I/O to turn on when the ECM has counted 3547 pulses. The 4 parameters will then have the following values as a condition: Counter L = 219 and Counter H = 3328. The logic then looks like this:




If we want to reset the counters, this can also be done via logic. We create a bistable (or timer) I/O (_reset) for this, which we set as a condition for resetting the counter.



A counter value can also be used as a condition for a reset function. A practical example: A green electricity certificate is issued for every 1000 kWh; via the ECM module we can easily demonstrate this via an I/O.

We write in the logic the following (we assume that 1 pulse represents 1kWh)



In this way an I/O is switched on when the number of pulses is reached and we immediately reset so that we do not miss any pulses. The I/O _Certificate can then be sent via an SMS module to a mobile phone or displayed on an EQommand, or to investigate further, the LEDs of the switch can flicker via an alarm.

6.2. EMM03 (Module type 0017)


The EMM03 or energy management module is a DIN rail module that can read the data from the P1 port of a digital energy meter (BE and NL) and visualize it on universal I/O's. Triggers can also be set that turn an I/O on and off according to a certain level.


After entering the serial number (in our example 0017B00017) the following screen appears:

In the setup box in the top right corner you can set whether you have a single or multiple hourly rate (also called day-night rate), whether there is also injection (solar panels, battery, ...), whether there is also a gas counter is connected, whether you have a 1-phase or 3-phase network and whether the EMM03 is connected to a Belgian or Dutch P1 port.

After checking the correct parameters and clicking on the “Read values” button, you will see all the values from the smart meter. Values in red are consumptions and values in green are injections into the grid.


To see these values in the Cloud, you need to assign I/O's to any desired parameter:

When you click on it  sign, the following question appears:



When you click on “No” you can create or assign an individual I/O to the selected parameter.


If you answer “Yes” here, the following window will appear:



Check whether all setup parameters are correct, adjust the desired beginning of the names if necessary and then click on “Create I/O’s”.

All individual I/O’s that were not yet assigned in module will be created with the correctly set type, minimum, maximum, multiplier and unit for a normal house.


The screen of the purchase for a two-time hourly rate then looks like this:



All energy values are displayed by the EMM03 with a resolution of 0.1kWh, the instantaneous power has a resolution of 0.001kW (= 1 Watt). Voltages are accurate to 0.1V and currents to 0.01A.


Every time the difference with a previously sent value is greater than the set hysteresis and the “Dead time” has elapsed, the new value will be sent to the controller. These values can also be visualized on the Cloud, EQOMmand, ...

The powers are standard set to a maximum of 10kW, the currents to 40A.




If your installation has larger (or smaller) consumers than normal, you can still adjust the minimum and maximum value for each I/O so that the indicator on the cloud looks better.

If you wish to switch I/O's when a value reaches a certain level, you can set this by clicking the "Triggers" button. Following window appears:



The EMM03 can internally switch up to 8 I/O's and will always be triggered by the instantaneous values received from the P1 port. The "hysteresis" and "dead time" therefore have no influence on this.

In the first row you select which I/O should be switched. Only I/O's of the type 'Bistable' can be selected here:



On the desired row, select the condition to turn the I/O ON. The condition \geq can be changed to \leq by double clicking on the cell. Double clicking again removes the full condition. You can set up to a maximum of 8 conditions per trigger that will be tested together with an AND condition.

In the following example, the I/O “Boiler” is turned on when there is more than 0.7kW (700W) injection.

Triggers		
Triggers	Trigger 1	Trig
Uitgang	Boiler	
Tarief Nacht		
Afname Totaal		
Afname Dag		
Afname Nacht		
Afname Ogenblikkelijk vermogen		
Injectie Totaal		
Injectie Dag		
Injectie Nacht		
Injectie Ogenblikkelijk vermogen	>= 0,7kW	
L1 Spanning		
L1 Stroom		

NB! When a boiler of e.g.2kW is switched on here, the trigger will no longer be sufficient and the I/O will be turned OFF because the injection is less than 700W.

So always set the delay on and/or off of the bistable I/O and/or use a fictitious I/O that switches on a timer via logic.

6.3 Configuring Luqas, the smart energy management module (LQS06SA) type 001B

Identical to the EMM03 module, the module and the QBUS I/O's can be added.

A full description can be found in chapter [6.2](#)

In addition, additional parameters can be set for controlling the heat pump and/or charging station.

The two relay I/O's can be used in two ways:

6.3.1 Controlling a Smart Grid heat pump

When you check the button in the “I/O” tab, you can select your device type and enter the power values:

The screenshot shows the configuration window for the LQS06SA module. The 'Setup' tab is selected. Under 'Smart Grid heat pump', the 'Smart Grid heat pump' checkbox is checked. Below it, there are input fields for power values: 'Power in Normal mode' (2kW), 'Power in Comfort mode' (4kW), and 'Power in Boost mode' (6kW). To the right, there are two sections for relays: 'Relais 1 (SG0)' and 'Relais 2 (SG1)'. Both sections contain the text 'Relais is controlled by Luqas'. The 'Tariff Day / Night' dropdown is set to 'LQS Tarief Nacht (T2)'. The 'Setup' section on the right has checkboxes for 'dual hourly rate', 'Injection', and 'Gas', all of which are checked.

Depending on the power of injection, the 2 relays will set the heat pump in the correct mode by means of the 2 relay I/O's. Some types of heat pumps do not support every mode. New known and supported types will later be automatically added online. If your heat pump type is not in the list, do not hesitate to inform Qbus, so that common types can be supported more quickly.

6.3.2 Controlling 2 relay I/O's

When you uncheck the button in the "I/O" tab, you can set which I/O you want to switch with relay 1 and relay 2.

Here you can also enter the power in kW that this I/O consumes. The relay will switch on when there is more injection than this set power and will turn off as soon as the consumption is more than 50% of the set power.


6.3.3 Charging station setup

You can set your charging station(s) via the next Tab.

Give it a name, select the correct brand and type, maximum power, minimum charging current, IP address or host name to which the charging station is set up and the connected phase(s). The LQS06SA will then control the charging according to the settings. You can also find more information in the online guide.

6.3.4 Setup

In the last Tab we can adjust some settings:




The screenshot shows the 'Setup' tab for the 'LQS06SA module 001BB00001'. The 'Name' field is 'LQS06SA_3'. There are buttons for 'Read Values', a small device icon, and a download arrow. The 'Tariff Day / Night' section shows 'LQS Tarief Nacht (T2)' with a dropdown and a 'Properties...' button. On the right, the 'Setup' section has checkboxes for 'dual', 'Injec', and 'Gas', all of which are checked. Below this is a tabbed interface with tabs for 'Current values', 'Consumption', 'Injection', 'L1', 'L2', 'L3', 'Gas', 'Inputs', 'Output', 'Charging station', and 'Setup' (which is active). The 'Module setup' section contains:

- 'Circuit breaker: maximum current' set to '40A'.
- 'Injection: Maximum power' set to '10kW'.
- 'Power control' section with 'Minimum' set to '0kW' and 'Maximum' set to '20kW'. Below these is a slider and the text 'Desired maximum power: 10kW'.

Enter the maximum power of the main circuit breaker, the maximum power of your solar panels/battery/wind turbine, and the maximum power you wish to obtain. The latter values therefore depend on your consumers and can be set realistically by the installer. More information about this can be found in the online guide.


6.4 Counters

From System manager 3.4.0 it is possible to visualize the operating hours of each I/O in the System manager. The operating hours can be viewed in the global edit tab by pressing the “Read value” button, or you can have certain actions performed via logic when a certain time is reached



Logic

The operating hours counter can also be used as a condition in an analog logic. The counters can be found in the Counter tab. The 3 counters (Counter sec, Counter min, Counter hr) each go from 0 to 255, Counter hr_high goes from 0 to 65280 (in steps of 256). For example, if we have 2 groups of lighting that are allowed to turn on for 1000 hours each, we have to build such a logic.



Remark:

A reset of the operating hours counter must be done manually via the System Manager, this can be done via the global Change tab, select the relevant I/O and then click on the Reset button.

Gloobaal editeren

Soort uitgang | **Locatie**

Alles

- Geschakeld
 - Aan/Uit
 - Zaal groep 1
 - Zaal groep 2
 - Zaal groep manueel
 - Timers1/2/3
 - Timers4/5
 - Andere
- Gedimd
- Rolluiken
- Thermostaten
- Ventilatie
- Speciaal

Klik hier om de teller van de geselecteerde uitgang te resetten

Controleer algemeen gebruik

Filter

Reset

Start

Deel

Hoofdletter-gevoelig

Uitgang

Gebruikt in.

Reset

Lees stand

Test

Uitgangen: Alles

Naam	Korte naam	Mode	Events	Cloud	Status	Counter
<input checked="" type="checkbox"/> Zaal groep 1	Zaal groep 1	Bistabel	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
<input type="checkbox"/> Zaal groep 2	Zaal groep 2	Bistabel	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
<input type="checkbox"/> Zaal groep manueel	Zaal groep m	Bistabel	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		

Gloobaal editeren

Soort uitgang | **Locatie**

Alles

- Geschakeld
 - Aan/Uit
 - Zaal groep 1
 - Zaal groep 2
 - Zaal groep manueel
 - Timers1/2/3
 - Timers4/5
 - Andere
- Gedimd
- Rolluiken
- Thermostaten
- Ventilatie
- Speciaal

Gloobaal editeren

Controleer algemeen gebruik

Filter

Reset

Start

Deel

Hoofdletter-gevoelig

Uitgangen: Alles

☒ Lees stand

Reset

Naam	Korte naam	Mode	Events	Cloud	Status	Counter
<input checked="" type="checkbox"/> Zaal groep 1	Zaal groep 1	Bistabel	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	ON	963h03'56"
<input checked="" type="checkbox"/> Zaal groep 2	Zaal groep 2	Bistabel	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	OFF	1011h01'07"
<input checked="" type="checkbox"/> Zaal groep manueel	Zaal groep m	Bistabel	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	ON	1102h07'09"

Klik hier om de tellers van ALLE geselecteerde uitgangen te resetten